

# XL15 Prime OCS User Manual



HG-668

MAN1485\_00\_EN\_XL15P\_UM

XL15 Prime Part Numbers	North America	Europe
Model 0	HE-XP15E0	HEXP751C100
Model 2	HE-XP15E2	HEXP751C112
Model 3	HE-XP15E3	HEXP751C113
Model 4	HE-XP15E4	HEXP751C114
Model 5	HE-XP15E5	HEXP751C115
Model 6	HE-XP15E6	HEXP751C116

## LIMITED WARRANTY AND LIMITATION OF LIABILITY

Horner APG, LLC, ("HE-APG") warrants to the original purchaser that the XL15 Prime (HE-XP15) OCS module manufactured by HE-APG is free from defects in material and workmanship under normal use and service. The obligation of HE-APG under this warranty shall be limited to the repair or exchange of any part or parts which may prove defective under normal use and service within two (2) years from the date of manufacture or eighteen (18) months from the date of installation by the original purchaser whichever occurs first, such defect to be disclosed to the satisfaction of HE-APG after examination by HE-APG of the allegedly defective part or parts. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES AND HE-APG NEITHER ASSUMES, NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR HE-APG, ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THIS XL15 Prime OCS module. THIS WARRANTY SHALL NOT APPLY TO THIS XL15 Prime OCS module OR ANY PART THEREOF WHICH HAS BEEN SUBJECT TO ACCIDENT, NEGLIGENCE, ALTERATION, ABUSE, OR MISUSE. HE-APG MAKES NO WARRANTY WHATSOEVER IN RESPECT TO ACCESSORIES OR PARTS NOT SUPPLIED BY HE-APG. THE TERM "ORIGINAL PURCHASER", AS USED IN THIS WARRANTY, SHALL BE DEEMED TO MEAN THAT PERSON FOR WHOM THE XL15 Prime OCS module IS ORIGINALLY INSTALLED. THIS WARRANTY SHALL APPLY ONLY WITHIN THE BOUNDARIES OF THE CONTINENTAL UNITED STATES.

In no event, whether as a result of breach of contract, warranty, tort (including negligence) or otherwise, shall HE-APG or its suppliers be liable of any special, consequential, incidental or penal damages including, but not limited to, loss of profit or revenues, loss of use of the products or any associated equipment, damage to associated equipment, cost of capital, cost of substitute products, facilities, services or replacement power, down time costs, or claims of original purchaser's customers for such damages.

**To obtain warranty service, return the product to your distributor with a description of the problem, proof of purchase, postpaid, insured and in a suitable package.**

## ABOUT PROGRAMMING EXAMPLES

Any example programs and program segments in this manual or provided from Horner's website, Cscape, or on YouTube, are included solely for illustrative purposes. Due to the many variables and requirements associated with any particular installation, Horner APG cannot assume responsibility or liability for actual use based on the examples and diagrams. It is the sole responsibility of the system designer utilizing the XL15 Prime OCS module to design the end system, integrate the XL15 Prime OCS module, and make safety provisions for the end equipment customary to industrial applications as defined in any codes or standards which apply.

**NOTE: The programming examples shown in this manual are for illustrative purposes only. Proper machine operation is the sole responsibility of the system integrator.**

## **PREFACE**

This manual explains how to use the XL15 Prime OCS.

Copyright (C) 2024 Horner APG, LLC, 59 South State Avenue, Indianapolis, Indiana 46201. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior agreement and written permission of Horner APG, Inc.

All software described in this document or media is also copyrighted material subject to the terms and conditions of the Horner Software License Agreement.

Information in this document is subject to change without notice and does not represent a commitment on the part of Horner APG.

Cscape, SmartStack, SmartStix, SmartRail, and CsCAN are trademarks of Horner APG.

## **North America**

Tel: (317) 916-4274

Fax: (317) 639-4279

Web: <http://www.hornerautomation.com>

Email: [APGUSATechSupport@heapg.com](mailto:APGUSATechSupport@heapg.com)

## **Europe**

Tel: (+) 353-21-4321-266

Fax: (+) 353-21-4321-826

Web: <http://hornerautomation.eu>

Email: [technical.support@hornerapg.com](mailto:technical.support@hornerapg.com)

# Table of Contents

<b>Chapter 1: Safety and Compliance</b>	<b>9</b>
1.1: Warnings	9
1.2: FCC Compliance	10
1.3: Safety Precautions	10
<b>Chapter 2: Intro to the XL15 Prime</b>	<b>12</b>
Visual Overview	12
Where to find more information for the XL15 Prime	13
Connectivity to the XL15 Prime	13
Features of XL15 Prime OCS	14
<b>Chapter 3: Mechanical Installation</b>	<b>16</b>
Mounting Requirements	16
Mounting Orientation	18
XL15 Prime OCS Mounting Clip	18
XL15 Prime OCS Mounting Orientation	18
Panel Cut-Out	19
Dimensions	19
Installation Procedure	21
Factors Affecting Panel Layout Design and Clearances	22
Clearance/Adequate Space	22
Grounding	22
Temperature/Ventilation	22
Orientation	22
Noise	22
Shock and Vibration	22
Panel Layout Design and Clearance Checklist	23
<b>Chapter 4: Electrical Installation</b>	<b>25</b>
4.1: Ground Specifications	25
4.2: How to Test for Good Ground	25
4.3: Primary Power Port	26
4.3.1: DC Input/Frame	26
4.3.2: Power Up	26
<b>Chapter 5: System Settings</b>	<b>28</b>
Fail- Safe System	28
Clone Unit System	28
System Menu Indicator Lights	28
System Menu – Navigation and Editing	30
System Menu Map	31
Set Networks	32
View Status & Diags	33
I/O Slots & Protocols	35
Set Fkeys Mode, Serial Ports, Ethernet, Time/Date, Beeper & Screen	37
Removable Media	43
WebMI License Details	44
Touch Screen Calibration	45
<b>Chapter 6: Register Mapping</b>	<b>47</b>
Register Definitions	47
%S Registers	48
%SR Registers	49
I/O Register Map for XL15 Prime	56
XL15 Prime Resource Limits	57
<b>Chapter 7: Cscape Configuration</b>	<b>59</b>
Cscape Status Bar	59
Establishing Communications	60
Communicating via MJ1 Serial Port	64
Communicating via On Board Ethernet Port	66

Cscape Configuration .....	68
<b>Chapter 8: General I/O Configuration .....</b>	<b>70</b>
Built-in Digital and Analog I/O Overview .....	70
Removing the Back Cover .....	71
Digital / HSC Input Configuration .....	72
Digital / PWM Output Configuration .....	75
Solid State Digital Outputs .....	75
Relay Outputs .....	77
Analog Input Configuration .....	81
Scaling Analog Inputs & Examples .....	88
Analog Outputs .....	88
<b>Chapter 9: High Speed I/O (HSC/PWM) .....</b>	<b>91</b>
9.1: Overview .....	91
9.2: High Speed I/O Glossary .....	92
9.3: High Speed Counter (HSC) Functions .....	93
9.3.1: Frequency .....	93
9.3.2: Totalize .....	93
9.3.3: Pulse Width Measurement .....	94
9.3.4: Period Measurement .....	95
9.3.5: Quadrature .....	95
9.3.6: Register Match .....	95
9.4: HSC Functions .....	96
9.4.1: Status Bits .....	97
<b>Chapter 9: XL Series Only .....</b>	<b>98</b>
9.5: HSC Functions Register Maps .....	98
9.5.1: I/O Mapping 2-Counter Mode (XL Series Only) .....	98
9.5.2: I/O Mapping 4-Counter Mode (XL Series Only) .....	100
9.5.3: I/O Mapping 4-Counter Mode (XL Prime Series only) .....	103
9.6: High Speed Output Functions .....	107
9.6.1: Normal .....	107
9.6.2: PWM .....	107
9.6.3: PWM Output Waveform .....	108
9.6.4: High Speed Counter Match .....	108
9.6.5: Stepper Function .....	109
9.7: High Speed Output Functions Register Map .....	110
9.7.1: I/O Mapping 2-Counter Mode .....	110
9.7.2: I/O Mapping 4-Counter Mode .....	111
9.7.3: PWM Examples .....	112
9.7.4: STP Examples .....	113
9.8: HSC I/O Filtering .....	114
<b>Chapter 10: Serial Communications .....</b>	<b>117</b>
Port Descriptions .....	117
Wiring .....	118
DIP Switches .....	119
RS-485 Termination .....	119
RS-485 Biasing .....	119
Cscape Programming via Serial Port .....	119
Ladder-Controlled Serial Communication .....	119
Configuration with USB Type C .....	120
<b>Chapter 11: CAN Communications .....</b>	<b>122</b>
11.1: Port Description .....	122
11.2: CAN Port Wiring .....	122
11.3: Cscape Programming via CAN .....	123
11.4: Ladder-Controlled CAN Communication .....	123
11.5: Using CAN for I/O Expansion (Network I/O) .....	123
11.6: OCSIO-I/O Expansion Port .....	123
<b>Chapter 12: Ethernet Communications .....</b>	<b>125</b>
Ethernet Module Protocols and Features .....	125

Ethernet Module Specifications .....	125
Ethernet Module Configuration .....	126
Ethernet Configuration – IP Parameters .....	129
Ethernet Module Protocol Configuration .....	129
<b>Chapter 13: Protocol Configuration .....</b>	<b>131</b>
13.1: Overview .....	131
13.2: Protocol Device Driver Selection .....	131
13.3: Network Configuration .....	133
13.4: Device List and Device Configuration .....	134
13.4.1: Device List .....	134
13.4.2: Device Configuration .....	135
13.5: Scan List .....	136
13.5.1: Menu .....	137
13.5.2: Buttons .....	137
13.5.3: Display Control .....	137
13.5.4: Data Mapping Configuration (Scan List Entry) .....	138
<b>Chapter 14: User Interface .....</b>	<b>142</b>
Screen Specifications .....	142
Displaying and Entering Data .....	143
Alpha-Numeric Keypad .....	144
Screen Navigation .....	146
Ladder-Based Screen Navigation .....	147
Beeper Acknowledgement .....	147
Touch (Slip) Sensitivity .....	148
Alarms .....	148
Removable Media .....	150
Screen Saver .....	152
Screen Brightness .....	152
Touch Screen Pressure .....	153
<b>Chapter 15: Audio Playback .....</b>	<b>155</b>
15.1: Audio Specifications .....	155
15.2: Audio Configuration .....	156
15.3: Audio Files .....	157
<b>Chapter 16: Video Object .....</b>	<b>160</b>
16.1: Video Object Overview .....	160
16.2: Opening Video Object in Cscope .....	161
16.3: Video Properties Configuration .....	162
16.3.1: Video Type .....	162
16.3.2: Control .....	163
16.3.3: Configuring Display Properties .....	164
16.4: Video Object Performance .....	164
16.5: Web Cameras .....	164
<b>Chapter 17: Removable Media .....</b>	<b>166</b>
17.1: microSD Cards .....	166
17.1.1: microSD File System .....	167
17.2: Using the Removable Media Manager .....	167
17.3: Log Data .....	168
17.4: View and Capture Screens .....	168
17.5: Removable Media Object .....	168
17.6: Function Blocks in Cscope .....	169
17.6.1: Program Features .....	169
17.6.2: Graphic/Screen Editor .....	169
17.6.3: Additional Configuration .....	170
17.7: Filenames .....	170
17.8: System Registers used with RM .....	170
<b>Chapter 18: Clone Unit .....</b>	<b>173</b>
18.1: Make Clone .....	173
18.2: Load Clone .....	176

<b>Chapter 19: Fail-Safe System for the XL Prime Series</b>	<b>179</b>
19.1: For the XL Prime Series	179
19.2: Fail-Safe System Overview	179
19.3: Settings	180
19.4: Backup/Restore Data	180
19.4.1: Backup OCS Data	181
19.4.2: Restore OCS Data	181
19.5: Clear Backup Data	182
19.6: AutoLoad	184
19.7: AutoRun	186
<b>Chapter 20: Modbus Communications</b>	<b>188</b>
Modbus Slave Overview	188
Modbus Master Overview	189
Modbus Addressing Table	190
<b>Chapter 21: Prime OCS Battery</b>	<b>192</b>
21.1: Safety	192
21.2: Replacing the Battery	193
<b>Chapter 22: Firmware Updates</b>	<b>195</b>
Check for Current Firmware Revision	195
Firmware Update Details	196
Download Firmware	196
<b>Chapter 23: Troubleshooting</b>	<b>198</b>
23.1: Connecting to the OCS	198
23.1.1: Serial Port – MJ1 Programming	199
23.1.2: USB Port - Type C Programming	199
23.1.3: ETN Port Programming	199
23.2: Local Controller and Local I/O	200
23.2.1: Local I/O Troubleshooting Checklist	200
23.3: CsCAN Network	200
23.3.1: CsCAN Network Troubleshooting Checklist	201
23.4: USB Interfaces	201
23.5: Basic Troubleshooting	202
23.6: Technical Support Contacts	202

# Safety and Compliance



## Chapter 1: Safety and Compliance

### 1.1: Warnings

When found on the product, the following symbols specify:

**WARNING:**  Consult user documentation.

**WARNING:**  Electrical Shock Hazard.

**WARNING: EXPLOSION HAZARD** – Substitution of components may impair suitability for Class I, Division 2.

**WARNING: EXPLOSION HAZARD** – Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

1. To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.
2. To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse the voltage measurement inputs. Be sure to locate fuses as close to the source as possible.
3. Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.
4. In the event of repeated failure, do not replace the fuse again as a repeated failure indicates a defective condition that will not clear by replacing the fuse.
5. Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

**WARNING: BATTERY MAY EXPLODE IF MISTREATED. DO NOT RECHARGE, DISASSEMBLE, OR DISPOSE OF IN FIRE.**

**WARNING: BATTERIES MUST ONLY BE CHANGED IN AN AREA KNOWN TO BE NON-HAZARDOUS.**

**WARNING:** The USB parts are for operational maintenance only. Do not leave permanently connected unless area is known to be non-hazardous.

**WARNING:** If the equipment is used in a manner not specified by Horner APG, the protection provided by the equipment may be impaired.

**NOTE:** All applicable codes and standards need to be followed in the installation of this product.

**NOTE:** For I/O wiring (discrete), use the following wire type or equivalent: Belden 9918, 18 AWG, or larger.

**NOTE:** See the "Electrical Installation" on page 25 for more details.

## 1.2: FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.


## 1.3: Safety Precautions

Adhere to the following safety precautions whenever any type of connection is made to the module:

If applicable codes and standards need to be followed in the installation of this product. Adhere to the following safety precautions whenever any type of connection is made to the module:

1. Connect the safety (earth) ground on the power connector first before making any other connections.
2. When connecting to the electric circuits or pulse-initiating equipment, open their related breakers.
3. Do **NOT** make connection to live power lines.
4. Make connections to the module first; then connect to the circuit to be monitored.
5. Route power wires in a safe manner in accordance with good practice and local codes.
6. Wear proper personal protective equipment including safety glasses and insulated gloves when making connections to power circuits.
7. Ensure hands, shoes, and floor are dry before making any connection to a power line.
8. Make sure the unit is turned OFF before making connection to terminals.
9. Make sure all circuits are de-energized before making connections.
10. Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.
11. Use copper conductors in Field Wiring only, 60/75°C.
12. Use caution when connecting controllers to PCs via serial or USB. PCs, especially laptops may use “floating power supplies” that are ungrounded. This could cause a damaging voltage potential between the laptop and controller. Ensure the controller and laptop are grounded for maximum protection. Consider using a USB isolator due to voltage potential differences as a preventative measure.

# Introduction to the XL15 Prime



HG-668

## Chapter 2: Intro to the XL15 Prime

Visual Overview .....	12
Where to find more information for the XL15 Prime .....	13
Connectivity to the XL15 Prime .....	13
Features of XL15 Prime OCS .....	14

### Visual Overview



HG-669

1. Virtual Function Keys Slide in from the Right Upon Touching Top Right Corner of the Screen
2. Optional Built-In I/O
3. High Capacity microSD Slot
4. USB C Port
5. CAN 1 Port
6. USB A Port
7. Mic Input / Audio Output
8. Dual Ethernet LAN Ports
9. DIP Switches
10. Power
11. MJ 1/2
12. MJ 3
13. CAN 2 Port

## Where to find more information for the XL15 Prime

**Datasheets** - The datasheets are the first documents to refer to for key information related to specific models. A basic datasheet is provided in the box with the unit.

Find the documents via the [Documentation Search](#) page on the Horner website.

Datasheet Manual Numbers	
XL15 Prime Model 0	MAN1479
XL15 Prime Model 2	MAN1480
XL15 Prime Model 3	MAN1481
XL15 Prime Model 4	MAN1482
XL15 Prime Model 5	MAN1483
XL15 Prime Model 6	MAN1484

## Connectivity to the XL15 Prime

Connectivity				
CAN	I/O	USB	Serial	Ethernet
Other OCS Devices	Sensors	Flash Drive	Other OCS Devices	Cscape
SmartStix I/O	Indicators	Cscape	Drives	OPC Server
SmartBlock I/O	Alarms	Webcam	PLCs	Modbus TCP Devices
SmartRail I/O	Encoders	Horner WiFi Adapter	Printers	SCADA
OPC	Pumps		SmartMod I/O	I/O Devices
OCS-I/O	Relays			SmartRail I/O
	Solenoids			

## Features of XL15 Prime OCS

The XL15 Prime OCS are all-in-one industrial control devices. They combine control, user interface, I/O, and networking into a single, integrated package. Unique features of the XL15 Prime OCS include:

- Bright, 65,536 color graphical touch sensing LCD display in all models of XL15 Prime.
- Display of complex graphical objects including trends, gauges, meters, and animations.
- High performance graphic processing.
- Advanced control capabilities including floating point, multiple auto-tuning PID loops, and string handling capabilities.
- Removable media for 32GB of storage of programs, datalogging, or screen captures.
- CsCAN networking port for communication with remote I/O, other controllers, or PCs.
- High speed USB port for communication with PCs and programming of controller.
- Configurable serial protocols for communication to drives, PLCs, or other serial peripherals.
- Full featured, built-in I/O including high resolution analog, thermocouple, RTD, high speed counters, PWM outputs, and relays (depending upon the XL15 Prime OCS model used).
- Advanced high speed I/O capabilities.
- Cscape programming software that allows all aspects of the XL15 Prime OCS to be programmed and configured from one integrated application.
- Optional communication add-on modules.
- On board Ethernet port (10/100Mbps) for Cscape programming and application defined communication, with Auto MDI/MDI-X.

# Mechanical Installation



## Chapter 3: Mechanical Installation


Mounting Requirements .....	16
Mounting Orientation .....	18
Panel Cut-Out .....	19
Dimensions .....	19
Installation Procedure .....	21
Factors Affecting Panel Layout Design and Clearances .....	22

The mechanical installation greatly affects the operation, safety and appearance of the system. Information is provided to mechanically install the unit such as cut-out sizes, mounting procedures, and other recommendations for the proper mechanical installation of the unit.

**NOTE:** The datasheet is the first document to refer to for model-specific information related to XL15 Prime OCS models such as pin-outs, jumper settings, and other key installation information. See the [Documentation Search](#) for datasheets.

### Mounting Requirements

Once the panel design has been completed using the criteria and suggestions in the following sections, use the following steps to panel mount the XL15 Prime OCS.



HG-157

1. The XL15 Prime allows unique installation options that simplify installation for systems that may not need robust vibration or water resistance.
2. If the system does not experience shock or vibration and will not be exposed to weather or wash down conditions, the unit can be installed by cutting the rectangular opening and installing the four (4) supplied clips.
3. For systems that may experience shock or vibration or are installed outdoors or in washdown environments, the rectangular cut and clips are used and perimeter holes must be drilled in the panel. The supplied studs are then inserted into the perimeter of the controller and supplied nuts will secure the perimeter of the unit to the panel.
4. Please reference the XL15 Prime installation cutout drawing document (SUP1550) for further details.
5. Remove all connectors from the XL15 Prime OCS unit.
6. Make sure both inner and outer gaskets are installed on the XL15 Prime OCS and are free from dust and debris. Check that the corners of the gasket are secure.

7. Pass the unit through the panel.
8. Insert each of the four (4) mounting clips into the slots in the XL15 Prime OCS case. One clip should be installed on each corner. Lightly tighten each screw so the clip is held in place.
9. Tighten the screws on the clips such that the gasket is compressed against the panel. Recommended torque is 7-10 in•lbs (0.79-1.13 N•m).
10. If the perimeter studs are needed, it is recommended to use a thread locker (similar to Loctite® Blue 242 or equivalent). Use supplied lock washers and nut. Recommended torque is 3-4 in•lbs (0.34-0.45 N•m). Refer to Figure 3.2 (below) for the proper torque sequence.





Figure 3.2

## Mounting Orientation

### XL15 Prime OCS Mounting Clip



### XL15 Prime OCS Mounting Orientation



**NOTE:** There are no orientation restrictions on the XL15 Prime OCS. However, the above orientation provides for optimum readability of the screen. (Ports on bottom-side only)

## Panel Cut-Out

For installations requiring NEMA 4X liquid and dust protection the panel cutout should be cut, and perimeter holes must be drilled in the panel with a tolerance of  $\pm 1.0\text{mm} / -0\text{mm}$ .






Figure not to scale

## Dimensions



# XL15 PRIME CUTOUT

MUST BE PRINTED AT 100% SCALE ON ANSI C PAPER FOR DIMENSIONAL ACCURACY



(Note: Above template image is not to scale. See SUP1550 for a to-scale template.)

## Installation Procedure

**NOTE:** Refer to the Supplement (SUP1550) for the mounting template

- The XL15 Prime is a panel mounted device and is meant to be an enclosure suitable for the equipment, such that the equipment is only accessible with the use of a tool. The XL15 Prime is suitable for use in Class I, Division II, Groups F and G, and Class III Hazardous Locations or non-hazardous locations only.
  - The XL15 Prime allows unique installation options that simplify installation for systems that may not need robust vibration or water resistance.
  - If the system does not experience shock or vibration and will not be exposed to weather or wash down conditions the unit can be installed by cutting the rectangular opening and installing the four supplied clips.
  - For systems that may experience shock or vibration or are installed outdoors or in wash down environments, the rectangular cut and clips are used and perimeter holes must be drilled in the panel. The supplied studs are then inserted into the perimeter of the controller and supplied nuts will secure the perimeter of the unit to the panel.
1. Remove all connectors from the XL15 Prime OCS unit.
  2. Carefully locate an appropriate place to mount the XL15 Prime. Be sure to leave enough room at the top of the unit for insertion and removal of the microSD card. Also leave enough room for the insertion and removal of USB FLASH drives and wiring.
  3. Carefully cut the host panel per the diagram, with a tolerance of + 0.5mm / -0mm. Remove any burrs/sharp edges and ensure the panel is not warped in the cutting process. If the opening is too large, water may leak into the enclosure, potentially damaging the OCS. If the opening is too small, the OCS may not fit through the hole without damage.
  4. Confirm the outer gasket is installed on the XL15 Prime OCS and is free from dust and debris. Check that the corners of the gasket are secure. Insert the OCS through the panel cutout (from the front). The gasket needs to be between the host panel and the OCS.
  5. Insert each of the four (4) mounting clips into the outermost slots of the XL15 Prime OCS case. One clip should be installed on each corner. Lightly tighten each screw so the clip is held in place.
  6. Tighten the screws on the clips such that the gasket is compressed against the panel. Recommended torque is 7-10 in•lbs (0.79-1.13 N•m). If the perimeter studs are needed, it is recommended to use a thread locker (similar to 242 Blue Loctite). Use supplied lock washers and nut. Recommended torque is 3-4 in•lbs (0.34-0.45 N•m).
  7. Reinstall the I/O Removable Terminal Blocks. Connect communications cables to the serial port, USB ports, Ethernet port, and CAN port as required.

## Factors Affecting Panel Layout Design and Clearances

**WARNING:** It is important to follow the requirements of the panel manufacture and to follow all applicable electrical codes and standards.

The designer of a panel layout must assess the requirements of a particular system and to consider the following design factors.

### Clearance/Adequate Space

Install devices to allow sufficient clearance to open and close the panel door.

Minimum Clearance Requirements for Panel Box and Door	
Minimum Distance between base of device and sides of cabinet	2" (50.80mm)
Minimum Distance between base of device and wiring ducts	1.5" (38.10mm)
<b>If more than one device installed in panel box (or door):</b> Minimum Distance between bases of each device	4" (101.60mm) between bases of each device
<b>When door is closed:</b> Minimum distance between device and closed door (Be sure to allow enough depth for the OCS.)	2" (50.80mm)

### Grounding

**WARNING:** Be sure meet the ground requirements of the panel manufacturer and also meet applicable electrical codes and standards.

**Panel Box:** The panel box must be properly connected to earth ground to provide a good common ground reference.

**Panel Door:** Tie a low impedance ground strap between the panel box and the panel door to ensure that they have the same ground reference.

### Temperature/Ventilation

Ensure that the panel layout design allows for adequate ventilation and maintains the specified ambient temperature range. Consider the impact on the design of the panel layout if operating at the extreme ends of the ambient temperature range. For example, if it is determined that a cooling device is required, allow adequate space and clearances for the device in the panel box or on the panel door.

### Orientation

When panel-mounted, there are no orientation restrictions mechanically for the XL15 Prime OCS, however the unit may be limited to only the standard software orientation.

### Noise

Consider the impact on the panel layout design and clearance requirements if noise suppression devices are needed. Be sure to maintain an adequate distance between the XL15 Prime OCS and noisy devices such as relays, motor starters, etc.

For details on output protection, especially when using contactors and solenoids, see MAN0962.

### Shock and Vibration

The XL15 Prime OCS has been designed to operate in typical industrial environments that may inflict some shock and vibration on the unit. For applications that may inflict excessive shock and vibration please use proper dampening techniques or relocate the XL15 Prime OCS to a location that minimizes shock and/or vibration.

## Panel Layout Design and Clearance Checklist

The following list provides highlights of panel layout design factors:

- Meets the electrical code and applicable standards for proper grounding, etc.?
- Meets the panel manufacturer's requirements for grounding, etc.?
- Is the panel box properly connected to earth ground? Is the panel door properly grounded? Has the appropriate procedure been followed to properly ground the devices in the panel box and on the panel door?
- Are minimum clearance requirements met? Can the panel door be easily opened and closed? Is there adequate space between device bases as well as the sides of the panel and wiring ducts?
- Is the panel box deep enough to accommodate the controller?
- Is there adequate ventilation? Is the ambient temperature range maintained? Are cooling or heating devices required?
- Are noise suppression devices or isolation transformers required? Is there adequate distance between the base of the controller and noisy devices such as relays or motor starters? Ensure that power and signal wires are not routed in the same conduit.
- Are there other requirements that impact the system that must be considered?

# Electrical Installation



## Chapter 4: Electrical Installation

4.1: Ground Specifications .....	25
4.2: How to Test for Good Ground .....	25
4.3: Primary Power Port .....	26

**NOTE:** The datasheet is the first document to refer to for model-specific information. Refer to the [Documentation Search](#) on the Horner website.


### 4.1: Ground Specifications

Ideally, a ground resistance measurement from equipment to earth ground is  $0\Omega$ . In reality it typically is higher. The US National Electrical Code (NEC) states the resistance to ground shall not exceed  $25\Omega$ . Horner Automation recommends less than  $15\Omega$  resistance from the equipment to ground. Resistance greater than  $25\Omega$  can cause undesirable or harmful interference to the device.

**Grounding Definition** - The term **ground** is defined as a conductive connection between a circuit or piece of equipment and the earth. Grounds are fundamentally used to protect an application from harmful interference causing either physical damage such as by lightning or voltage transients or from circuit disruption often caused by radio frequency interference (RFI).

### 4.2: How to Test for Good Ground

In order to test ground resistance, a Ground Resistance Tester must be used. A typical Ground Resistance Meter Kit contains a meter, two or three wire leads, and two ground rods. Instructions are supplied for either a two-point or a three-point ground test. The figure shows a two-point ground connection test.



### 4.3: Primary Power Port

The Primary Power Range is 10-30 VDC.



HG-007

Primary Power Port Pins		
PIN	Signal	Description
1	Ground	Frame Ground
2	DC-	Input Power Supply Ground
3	DC+	Input Power Supply Voltage

#### 4.3.1: DC Input/Frame

- Solid/Stranded Wire: 12-24 AWG (3.3 – 0.2 mm<sup>2</sup>)
- Strip length: 0.28" (7 mm)
- Torque, Terminal Hold-Down Screws: 4.5 – 7 in•lbs (0.50 – 0.78 N•m)
- DC- is internally connected to I/O V-, but is isolated from the V- connection of both CAN1 and CAN2 ports. A Class 2 power supply must be used.

#### 4.3.2: Power Up

1. **OPTIONAL:** Attach ferrite core with a minimum of two turns of the DC+ and DC- signals from the DC supply that is powering the controllers.



HG-006

2. Connect to earth ground.
3. Apply recommended power.

**NOTE:** Refer to datasheet for power specifications

# System Settings and Adjustments



## Chapter 5: System Settings

Fail- Safe System .....	28
Clone Unit System .....	28
System Menu Indicator Lights .....	28
System Menu – Navigation and Editing .....	30
System Menu Map .....	31
Set Networks .....	32
View Status & Diags .....	33
I/O Slots & Protocols .....	35
Set Fkeys Mode, Serial Ports, Ethernet, Time/Date, Beeper & Screen .....	37
Removable Media .....	43
WebMI License Details .....	44
Touch Screen Calibration .....	45

### Fail- Safe System


For Fail-Safe System Settings, see "Fail-Safe System for the XL Prime Series" on page 179

### Clone Unit System

For Clone Unit Settings, see "Clone Unit" on page 173

### System Menu Indicator Lights

The XL15 Prime has a built-in System Menu, which lets the user view, and make adjustments to, the System Settings. To start the System Menu, press the far upper right corner of the touchscreen to show the function keys, then press the **SYSTEM** key (or set %SR3 to 1), which will display the Main Menu. Then use the ↑ and ↓ (Up Arrow or Down Arrow) keys to select a **Main Menu** item and press **Enter** (Return Arrow) to display the item's submenu.



OCS LEDs	
RUN	<ul style="list-style-type: none"> <li>OFF indicates OCS is in IDLE/STOP mode.</li> <li>Flashing indicates DO / IO mode or RUN with no ladder program.</li> </ul>

	OCS LEDs
	<ul style="list-style-type: none"><li>▪ ON indicates ladder code running.</li></ul>
OK	<ul style="list-style-type: none"><li>▪ OFF indicates one or more self-tests failed.</li><li>▪ ON indicates all self-tests passed.</li></ul>

## System Menu – Navigation and Editing

As mentioned above, the System Menu is started by pressing the System key on the XL15 Prime. Next press **ESC** to exit the System Menu or use **↑** and **↓** to select an item and press **Enter** to display the item's submenu.

A submenu generally shows a list of System Settings and their values. After opening a submenu, if any of its System Settings are editable, the first System Setting that can be edited is highlighted. If desired, the **↑** and **↓** keys can be used to select a different System Setting to be edited.


At this point, either press **ESC** to exit the submenu (returning to the Main Menu) or press **Enter** to edit the highlighted System Setting. If **Enter** is pressed, the System Setting's value will be highlighted, indicating that it is ready to be modified.

When modifying a System Setting's value, use either the arrow keys (**←** **→** **↑** **↓**) or the numeric keys, or the appropriate touch screen icons to select a new value.

The arrow keys are used to edit System Settings that have just a few possible values. Each time the arrow key is pressed, a new possible value is displayed. When the desired value appears, press the **Enter** key to save it; otherwise press the **ESC** key to cancel the edit.

The arrow keys are used to edit System Settings that have just a few possible values. Each time the arrow key is pressed, a new possible value is displayed. When the desired value appears, press the **Enter** key to save it; otherwise press the **ESC** key to cancel the edit.


The numeric keys are normally used to enter numeric System Settings.



In addition, to edit a single numeric digit, use the **←** or **→** key to select the digit, and then either press a numeric key or use **↑** or **↓** to modify the digit. In any case, after entering the new desired value, press the **Enter** key to save it; otherwise press the **ESC** key to cancel the edit.

# System Menu Map


## XL15 PRIME SYSTEM MENU MAP



HG-204

## Set Networks

This sub menu allows setting for the CAN and Ethernet network to be viewed or changed.




<b>CAN Ok?</b>	Yes = CAN1 connected to a CAN network and functioning properly No = Not ready to communicate on CAN network	
<b>CAN ID</b>	1 to 253 = This node's CsCAN Network ID; must be unique on network	
<b>CAN Baud</b>	125kB = 125kBd CAN network 250kB = 250kBd CAN network	500kB = 500kBd CAN network 1MB = 1MBd CAN network
<b>MAC ID</b>	Displays the Ethernet interface's MAC ID of the unit	
<b>IP</b>	Displays the IP address of the unit	
<b>NetM</b>	Displays the netmask of the unit	
<b>GatWy</b>	Displays the default gateway of the unit	

**NOTE:** The IP address, Netmask, and default Gateway can be changed from the System Menu. This is designed for commissioning or temporary field changes. The actual parameters are defined in Cscape under the Ethernet configuration and are reverted to whenever the unit goes from idle to run mode.

## View Status & Diags

### View Status


The View Status Sub-Menu displays up to 19 System Settings. Only the **OCS Mode** System Setting is editable.



<b>Model:</b>	<b>XP7xx</b> = Model number of this XL15 Prime OCS unit <b>1yz</b> = indicates the installed I/O module <b>00</b> = no I/O module
<b>Mode:</b>	<b>Idle</b> = XL15 Prime OCS is in Idle mode <b>DoIO</b> = XL15 Prime OCS is in Do I/O mode <b>Run</b> = XL15 Prime OCS is in Run mode
<b>Scan Rate (ms):</b>	<b>0.0</b> = XL15 PrimeOCS is not in Run mode <b>0.1 to 999.9</b> = Average time per ladder scan
<b>Lcl Net Use %:</b>	<b>0.0 to 100.0</b> = CAN network bandwidth utilization by this XL15 Prime OCS node
<b>All Net Use %:</b>	<b>0.0 to 100.0</b> = CAN network bandwidth utilization by all nodes
<b>Ladder Size:</b>	<b>x</b> = Number of bytes in application ladder program
<b>Config Size:</b>	<b>x</b> = Number of bytes in application I/O configuration
<b>Graphics Size:</b>	<b>x</b> = Number of bytes in application graphic screens
<b>String Size:</b>	<b>x</b> = Number of bytes in application string table
<b>Bitmap Size:</b>	<b>x</b> = Number of bytes in application bitmaps
<b>Text Tbl Size:</b>	<b>x</b> = Number of bytes in application text tables
<b>Font Tbl Size:</b>	<b>x</b> = Number of bytes in application font tables
<b>Protocol Size:</b>	<b>x</b> = Number of bytes in application downloaded protocols
<b>SMS File Size:</b>	<b>x</b> = Number of bytes in application SMS protocol configuration
<b>Firmware Rev:</b>	<b>xx.yy</b> = Current firmware version
<b>OS Ver:</b>	<b>a.b.cd.yz</b> = Current Operating System version
<b>FPGA Rev:</b>	<b>x.y</b> = Current FPGA version (High Speed IO subsystem)
<b>InitRD Rev:</b>	<b>x.yz</b> = Bootloader version
<b>Self-Test</b>	<b>Ok</b> = All power-on self-tests passed <b>Fault</b> = One or more power-on self-tests failed

## View Diags

The View Diags Sub-Menu displays up to 11 System Diagnostics, none of which are editable. The first two System Diagnostics are critical. If any of them indicate a Fault condition, the XL15 Prime OCS will not enter or remain in Run mode, and the problem must be investigated and corrected.




<b>Logic Error:</b>	<b>Ok</b> = All executed ladder instructions are legal for loaded firmware <b>Fault</b> = A ladder instruction not supported by firmware was found
<b>User Program:</b>	<b>Ok</b> = Ladder program and I/O configuration loaded successfully <b>Fault</b> = Ladder program or I/O configuration not loaded or load failed

The last nine System Diagnostics are informational. If any of them indicate a Warning condition, the XL15 Prime OCS can still enter and remain in Run mode, but the problem should be investigated and corrected.

<b>User Graphics:</b>	<b>Ok</b> = Application graphics objects loaded successfully <b>Fault</b> = Application graphics objects not loaded or load failed
<b>W-Dog Trips:</b>	<b>0</b> = Watchdog timer has not tripped since the last power-up <b>x</b> = Number of times watchdog timer has tripped
<b>Net Errors:</b>	<b>0</b> = No CAN network bus-off errors have occurred <b>x</b> = Number of CAN network bus-off errors that have occurred
<b>Network State:</b>	<b>Ok</b> = At least one other node was found on the CAN network <b>Warning</b> = No other nodes were found on the CAN network
<b>Network ID:</b>	<b>Ok</b> = This node's CAN Network ID is in the range 1 to 253 <b>Warning</b> = This node's CAN Network ID was out of range at power-up
<b>Dup Net ID:</b>	<b>Ok</b> = This node's Network ID is unique on the CAN network <b>Warning</b> = This node's Network ID is duplicated in another node
<b>Clock Error:</b>	<b>Ok</b> = Time and date have been set <b>Warning</b> = Time and date need to be set
<b>I/O System:</b>	<b>Ok</b> = I/O configuration matches the installed I/O and COM modules <b>Warning</b> = I/O configuration needs updating to match installed modules
<b>Battery:</b>	<b>Ok</b> = Backup battery operating properly <b>Warning</b> = Backup battery needs to be replaced

## I/O Slots & Protocols

### View I/O Slots



The View I/O Slots Sub-Menu displays three System Settings, all of which are **not** editable.

Internal to the XL15 Prime OCS, there is a CPU board, and up to two installed modules. Model HE-XP15E0 has no installed I/O or COM modules. All other models have an I/O module and can have a user-installed COM module.


Depending on which I/O module is installed and which I/O module has been configured by Cscape, one of the following six System Settings should appear for Slot 1:

<b>Slot 1: I/O: Empty</b>	No I/O module installed or configured
<b>Slot 1:*Unsupported</b>	Unsupported I/O module installed
<b>Slot 1:-I/O Missing</b>	No I/O module installed but an I/O module is configured
<b>Slot 1:+I/O: XExyy</b>	yy I/O module installed but no I/O module configured
<b>Slot 1:?I/O: XExyy</b>	yy I/O module installed but another I/O module configured
<b>Slot 1: I/O: XExyy</b>	yy I/O module installed and configured properly

Depending on the COM module that is installed and the COM module that has been configured by Cscape, one of the following six System Settings appears for Slot 2:

<b>Slot 2: I/O: Empty</b>	No COM module installed or configured
<b>Slot 2:*Unsupported</b>	Unsupported COM module installed
<b>Slot 2:-I/O Missing</b>	No COM module installed but a COM module is configured
<b>Slot 2:+I/O: XzC</b>	z COM module installed but no COM module configured
<b>Slot 2:?I/O: XzC</b>	z COM module installed but another COM module configured
<b>Slot 2: I/O: XzC</b>	z COM module installed and configured properly
<b>Slot 3: I/O: ETN300</b>	ETN300 has been configured through Cscape

## View Protocols



The View Protocols Sub-Menu displays three System Settings, none of which are editable.

As mentioned in Downloadable Serial Communication Protocols section, both the MJ1 (Port 1), MJ2 (Port 2), and MJ3 (Port 3) serial ports support downloadable protocols. To assign a downloadable protocol to an OCS serial port, select the **Protocol Config** item in Cscope's Program menu and then setup a protocol.

In the View Protocols Sub-Menu, the currently downloaded protocol, if any, and its version number are displayed for each of MJ1, MJ2, MJ3, and COM board.

## Set Fkeys Mode, Serial Ports, Ethernet, Time/Date, Beeper & Screen

### Set Fkeys

System Menu

**Fkeys:**

SYS-Fn enable:

( Use ↓↑ to adjust )

HG-175

Momentary
OK
RUN

Yes

△

▽

▶

◀

Esc

Enter

1

2

3

4

5

6

7

8

9

0

The Set Fkeys Sub-Menu displays two System Settings, both of which are editable.

<b>Fkeys</b>	<b>Momentary</b> = %K1-7 bits go On & Off as F1-F7 are pressed & released <b>Toggle</b> = %K1-7 bits toggle each time F1-F7 are pressed
<b>SYS_Fn enable</b>	<b>Yes</b> = Reset and all clear system functions enabled <b>No</b> = Reset and all clear system functions disabled

## Set Serial Ports

**System Menu**

Dflt Pgm Port	MJ1-232	● OK	▲	● RUN
MJ2 RS485 Bias	No	◀	▶	
MJ3 RS485 Bias	No	▼		
(Use ↑↓ to adjust)				
		Esc	Enter	
		1	2	3
		4	5	6
		7	8	9
		0		
HG-179				

The Set Serial Ports Sub-Menu displays three System Settings, all of which are editable, and one optional item. For the **Dflt Pgm Port** System setting, only MJ1-232, MJ2, and MJ3 can be selected, unless a Modem (XMC) COM module is installed.

<b>Dflt Pgm Port</b>	<b>MJ1-232</b> = MJ1 RS232 port is the default programming port <b>MJ2 &amp; MJ3</b> = If modem is onboard, then GPRS-C, GPRS-S are options <b>Modem</b> = Modem COM module is the default programming port
<b>MJ2 RS485 Bias</b>	<b>No</b> = MJ2 RS485 bias resistors are <u>not</u> switched in <b>Yes</b> = MJ2 RS485 bias resistors are switched in
<b>MJ3 RS485 Bias</b>	<b>No</b> = MJ3 R5485 bias resistors are <u>not</u> switched in <b>Yes</b> = MJ3 R5485 bias resistors are switched in

## Set Time/Date


The following instructions are to set and display the real-time clock in the controller. More details can be found in the Help File in Cscape.

Clock and Time Setting Terms	
<b>Coordinated Universal Time (UTC)</b>	Coordinated Universal Time (UTC) is the primary time standard by which the world regulates clocks and time.
<b>Time Offset</b>	In order to obtain the local time (anywhere in the world), the user needs to subtract/add a certain number of hours from UTC depending on how many time zones user is away from Greenwich.
<b>Network Time Protocol (NTP)</b>	A Networking Time Protocol (NTP) for clock synchronization between computer systems over packet-switched, variable latency data networks.
<b>Daylight Saving Time</b>	Time as adjusted to achieve longer evening daylight, especially in summer, by setting the clocks an hour ahead of the standard time.
<b>Apply Daylight Saving (DST)</b>	Daylight Saving Time (DST) is the practice of setting the clocks forward one hour from standard time during the summer months, and back again in the fall, in order to make better use of natural daylight. Selecting this option increases the Time offset by 1 hour.

**NOTE: Controller Time Zone (UTC time):** From Cscape 9.70 SP2 and FW 14.22 onwards, UTC time is supported.

System Registers for UTC (Coordinated Universal Time)	
<b>%SR210 (R/W)</b>	Time Zone: set in hours $\pm$ UTC.
<b>%SR211 (R/W)</b>	Daylight Saving: YES = 1 Daylight Saving: NO = 0 (If daylight saving is enabled, one hour will be added to the local time).
<b>%SR212 (R)</b>	UTC – Seconds
<b>%SR213 (R)</b>	UTC – Minutes
<b>%SR214 (R)</b>	UTC – Hours
<b>%SR215 (R)</b>	UTC – Date
<b>%SR216 (R)</b>	UTC – Month
<b>%SR217 (R)</b>	UTC – Year

**NOTE:** See [System Register Section](#) for Real Time Clock (RTC) settings



**To Set Time Zone:** The Time Zone setting is an hourly offset from UTC time. If using the Time Zone setting, set it first, then set the local time. UTC time will be automatically set based on the time zone and local time settings.

**If using NTP:** NTP utilizes UTC time, therefore when using NTP, the appropriate hourly offset from UTC time must entered into the time zone setting.


**Daylight Saving Time:** If currently observing Daylight Saving Time, set to **Yes**. If not currently observing Daylight Saving Time, set to **No**. The OCS controller does not automatically switch to daylight saving time; however, program logic can be written to accomplish an automatic switchover using system register %SR211. In program logic, move a "1" (INT) into %SR211 to enable Daylight Saving Time. Move a "0" (INT) into %SR211 to disable Daylight Saving Time. Trigger the move to %SR211 based on a compare function to the RTC date according to daylight saving practices in your desired region.

**To Set Local Time:** The **Set Time/Date** sub-menu displays three system settings. **Time** and **Date** may be edited, and **Day** is automatically calculated from the **Date** setting.

**NOTE:** **Time** and **Date** are split into three fields each, all of which may be edited. Touch the field or use ↓ or ↑ buttons to select a field, then use the ↓ or ↑ buttons to edit the field.

<b>Time</b>	<b>16:09:49</b> = Current time (hours:minutes:seconds in 24-hour format)
<b>Date</b>	<b>10-Jun-2013</b> = Current date (day-month-year)
<b>Day</b>	<b>Monday</b> = Current day of week calculated from the Date setting

## Set Beeper




The screenshot shows a 'System Menu' interface. At the top, a blue bar contains the text 'System Menu'. Below this, the text 'Beeper Enable:' is displayed in a black box. To the right of this text, the word 'No' is shown next to a green circle, followed by 'OK' and 'RUN' buttons, each with a green circle. Below the 'Beeper Enable:' text, the instruction '( Use ↓↑ to adjust )' is displayed. To the right of the instruction, there are four arrow buttons (left, up, down, right) and a numeric keypad with buttons for 'Esc', 'Enter', and digits 1 through 9, with a '0' button at the bottom. At the bottom left of the screen, the text 'HG-174' is displayed.

The Set Beeper submenu displays one System Setting, which is editable.

<b>Beeper Enable</b>	<b>Yes</b> ( <i>default</i> ) = Enables beeper <b>No</b> = Disables beeper ( <i>does NOT affect ladder access</i> )
----------------------	--

## Set Screen

The Set Screen Sub-Menu displays four System Settings, all of which are editable.




<b>Video Streaming:</b>	<b>To enable Video Input:</b> <ol style="list-style-type: none"> <li>1. Ensure Video Streaming is set to <b>Remote</b>.</li> <li>2. Power cycle</li> <li>3. Check the User Display screens</li> </ol>
<b>Saver enable:</b>	<b>Yes</b> = Enable screen saver <b>No (default)</b> = Disable screen saver
<b>Timeout (min):</b>	<b>5 - 1200</b> = Amount of time in minutes to expire with NO touch activity before activating screen saver (black screen)
<b>Popup Status:</b>	<b>Off (default)</b> = Disable popup status <b>Warning</b> = Display popup status only if controller status changes to NOT Ok or NOT Run mode. <b>On</b> = Display popup status on any controller status change.
<b>Update Time (mS):</b>	<b>2 - 50</b> = Maximum amount of time to allow for graphics update per scan


## Removable Media

Media Directory				
SCR0000	.JPG	26267	07-10-08	12:46
SCR0001	.JPG	14272	07-10-08	12:46
SCR0002	.JPG	15209	07-10-08	12:46
SCR0003	.JPG	29708	07-10-08	12:46
SCR0004	.JPG	29582	07-10-08	12:47
SCR0005	.JPG	23263	07-10-08	12:47
SCR0006	.JPG	14643	07-10-08	12:47
SCR0007	.JPG	14976	07-10-08	12:47
SCR0008	.JPG	15994	07-10-08	12:47
SCR0009	.JPG	17561	07-10-08	12:47
Free:		511672320	Total:	511959040
<div> <div>⬅</div> <div>⬆</div> <div>⬇</div> <div>Del</div> <div>Del All</div> <div>For mat</div> <div>Save Pgn</div> <div>Esc</div> </div>				

The Removable Media Sub-Menu displays the Removable Media Manager. After selecting Removable Media from the Main Menu, one of four Sub-Menu screens will appear:



= No microSD card has been installed in the Memory slot



= microSD card is installed, but it is still initializing.



= microSD card is installed and initialized, but contains no files.

## WebMI License Details

**System Menu**

Server Running	Yes	<span style="color: green;">●</span> OK	<span style="color: gray;">●</span> RUN	
Users	5			
Pages	5			
Data Points	25			
Expiry Date	03-Sep-2017			
User logged In	No			
		<div style="display: flex; justify-content: space-around; margin-bottom: 5px;"> <span style="border: 1px solid gray; padding: 2px 10px;">Esc</span> <span style="border: 1px solid gray; padding: 2px 10px;">Enter</span> </div> <div style="display: grid; grid-template-columns: repeat(3, 1fr); gap: 5px;"> <div style="border: 1px solid gray; padding: 2px 10px;">1</div> <div style="border: 1px solid gray; padding: 2px 10px;">2</div> <div style="border: 1px solid gray; padding: 2px 10px;">3</div> <div style="border: 1px solid gray; padding: 2px 10px;">4</div> <div style="border: 1px solid gray; padding: 2px 10px;">5</div> <div style="border: 1px solid gray; padding: 2px 10px;">6</div> <div style="border: 1px solid gray; padding: 2px 10px;">7</div> <div style="border: 1px solid gray; padding: 2px 10px;">8</div> <div style="border: 1px solid gray; padding: 2px 10px;">9</div> <div style="border: 1px solid gray; padding: 2px 10px; margin-top: 5px;">0</div> </div>		


HG-199

License details page displays the information about the WebMI license. Please refer to MAN1036 for the WebMI Manual using Horner's [Documentation Search](#) page. The information can also be viewed from Cscape using the following %SR registers:

<b>%SR209.3</b>	WebMI server status
<b>%SR209.4</b>	WebMI user logged in status
<b>%SR209.9 to SR209.16</b>	Number of Users
<b>%SR218</b>	Number of Webpages
<b>%SR219</b>	Number of Data Points
<b>%SR220-SR222</b>	Expiry Date of WebMI License

## Touch Screen Calibration

The touch screen is calibrated at the factory and rarely needs modification. However, if actual touch locations do not appear to correspond with responding objects on the display, field adjustment is available. To access the field adjustable touch screen calibration dialog, press and hold System key for longer than two (2) seconds and the “System Recovery Screen” will appear. Press “Touch Calibration” and then follow the prompts on the screen. Thereafter, use a plastic tip stylus and follow the dialog instructions.



**NOTE:** System key combinations can be locked out from user access. If the SYS-F1 key combination does NOT respond, the **SYS-Fn** enable option is likely disabled. It can be enabled from the Set Fkeys Mode screen accessible from the System Menu.

For best results in screen calibration, use a stylus with a plastic tip. When the crosshair appears, touch the center of the crosshair as exactly as possible and release.

# Register Mapping



## Chapter 6: Register Mapping

Register Definitions .....	47
%S Registers .....	48
%SR Registers .....	49
I/O Register Map for XL15 Prime .....	56
XL15 Prime Resource Limits .....	57

### Register Definitions

When programming the an OCS, data is stored in memory that is segmented into different types. This memory in the controller is referred to as registers. Different groups of registers are defined as either bits or words (16 bits). Multiple registers can usually be used to handle larger storage requirements. For example, 16 single-bit registers can be used to store a word, or two 16-bit registers can be used to store a 32-bit value.

Types of Registers	
<b>%AI = Analog Input</b>	16-bit input registers used to gather analog input data such as voltages, temperatures, and speed settings coming from an attached device.
<b>%AQ = Analog Output</b>	16-bit output registers used to send analog information such as voltages, levels, or speed settings to an attached device.
<b>%D = Display Bit</b>	These are digital flags used to control the displaying of screens on a unit which has the ability to display a screen. If the bit is SET, the screen is displayed.
<b>%I = Digital Input</b>	Single-bit input registers. Typically, an external switch is connected to the registers.
<b>%K = Key Bit</b>	Single-bit flags used to give the programmer direct access to any front panel keys appearing on a unit.
<b>%M = Retentive Bit</b>	Retentive single-bit registers.
<b>%Q = Digital Output</b>	Single-bit output registers. Typically, these bits are connected to an actuator, indicator light, or other physical outputs.
<b>%R = General Purpose Register</b>	Retentive 16-bit registers.
<b>%S = System Bit</b>	Single-bit bit coils predefined for system use.
<b>%SR = System Register</b>	16-bit registers predefined for system use.
<b>%T = Temporary Bit</b>	Non-retentive single-bit registers.

## %S Registers

%S registers indicate system status as follows:

S#	Name	Predefined I/O Name	Notes
%S1	First Scan	FST_SCN	On for 1 scan only each time the program is first run
%S2	Network OK	NET_OK	If on, the Network is OK
%S3	10ms pulse	T_10MS	Cycling pulse that is high for 5ms and low for 5ms
%S4	100ms pulse	T_100MS	Cycling pulse that is high for 50ms and low for 50ms
%S5	1 second pulse	T_1SEC	Cycling pulse that is high for 500ms and low for 500ms
%S6	I/O OK	IO_OK	If on, the I/O system is OK
%S7	Always On	ALW_ON	This bit is always on
%S8	Always OFF	ALW_OFF	This bit is always off
%S9	Pause Scan	PAUSING_SCN	On for at least 1 scan prior to Pause 'n Load
%S10	Resume Scan	RESUMED_SCN	On for 1 scan only after Pause 'n Load is done
%S11	Forcing Present	FORCE	If on, I/O is presently being forced
%S12	Forcing Enabled	FORCE_EN	If on, I/O forcing is been enabled
%S13	Net I/O OK	NET_IO_OK	If on, Network I/O is OK

## %SR Registers

%SR registers are special word-length registers that display and/or control system operations in the controller. Not all controllers support all defined system registers. Click on the name of the register to see more information on that register.

SR #	Name and Description	Default I/O Name	Min/Max Values	Program (Read/Write)	Display (Read/Write)
%SR1	User Screen Number (0=none)	USER_SCR	0 to 1023	Read/Write	Read/Write
%SR2	Alarm Screen Number	ALRM_SCR	0 to 1023	Read Only	Read Only
%SR3	Built-in Screen Numbers below: 1 = Main System Menu 2= Set Network ID, Network Status, (%SR29) 3= Set Network Baud (%SR30) 4= Set Contrast (%SR32) 5= View OCS Status 6= View OCS Diagnostics 7= View I/O Slots 8= Set Function Key Mode (%SR33) 9= Set Serial Ports (%SR34) 10= Set Time/Date (%SR44-%SR50) 11= Set Beeper (%SR183) 12= Set Screen (%SR185) 13= Removable Media 14= View Protocols 15= IP Address 16= Fail Safe System 17= Backup / Restore Data 18= Enable AutoRun 19= Enable AutoLoad 20= Clone Unit 21= Touch Calibration 24= License Details	SYS_SCR	0 to 24	Read/Write	Read/Write
%SR4	Self Test Results	SELF_TEST		Read Only	Read Only
%SR4.1	Self Test Results - BIOS Error			Read Only	Read Only
%SR4.2	Self Test Results - Engine Error			Read Only	Read Only
%SR4.3	Self Test Results - Ladder Error			Read Only	Read Only
%SR4.4	Self Test Results - RAM Error			Read Only	Read Only
%SR4.5	Self Test Results - Duplicate ID Error			Read Only	Read Only
%SR4.6	Self Test Results - Bad ID Error			Read Only	Read Only
%SR4.7	Self Test Results - I/O Configuration Error			Read Only	Read Only
%SR4.8	Self Test Results - Bad Network Error			Read Only	Read Only
%SR4.9	Self Test Results - Bad Logic Error			Read Only	Read Only
%SR4.10	Self Test Results - Bad Clock Error			Read Only	Read Only
%SR4.11	Self Test Results - DeviceNet Error			Read Only	Read Only
%SR4.12 - 16	<b>Reserved</b>				
%SR5	Control Station Mode 0= Idle	CS_Mode	0 to 3	Read Only	Read/Write

	1= Do I/O 2= Run 3= Online Change				
%SR6	Average Scan Rate ms (tenths of ms)			Read Only	Read Only
%SR7	Minimum Scan Rate ms (tenths of ms)			Read Only	Read Only
%SR8	Maximum Scan Rate ms (tenths of ms)			Read Only	Read Only
%SR9	Current Touch Pressure	TCH_PRESSURE	0 to 3000	Read Only	Read Only
%SR10	Threshold Touch Pressure	TCH_PRESSURE_TSH	0 to 3000	Read/Write	Read/Write
%SR11-12	Ladder Size (32-Bit DINT)			Read Only	Read Only
%SR13-14	User Text Screen Size (32-Bit DINT)			Read Only	Read Only
%SR15-16	System Text Screen Size (32-Bit DINT)			Read Only	Read Only
%SR17-18	I/O Configuration Table Size (32-Bit DINT)			Read Only	Read Only
%SR19-20	Network Config Table Size (32-Bit DINT)			Read Only	Read Only
%SR21-22	Security Data Table Size (32-Bit DINT)			Read Only	Read Only
%SR23	Ladder Code CRC			Read Only	Read Only
%SR24	User Text CRC			Read Only	Read Only
%SR25	System Text CRC			Read Only	Read Only
%SR26	I/O Configuration Table CRC			Read Only	Read Only
%SR27	Network Configuration Table CRC			Read Only	Read Only
%SR28	Security Data Table CRC			Read Only	Read Only
%SR29	Network ID	NET_ID		Read Only	Read/Write
	CsCAN Mode		1 to 253		
	DeviceNet Mode		0 to 63		
	CANopen Mode		1 to 127		
%SR30	<b>Network Baud Rate</b> 0=125KB 1= 250kB 2= 5000KB 3= 1MB 4=50K		0 to 4	Read Only	Read/Write
%SR31	<b>Network Required</b> 0= Network not required 1= Network required 2= Network optimized 3= Network required and optimized		0 to 3	Read Only	Read Only
%SR32	LCD Display Contrast setting		0 to 255	Read Only	Read/Write
%SR33	Function Key Toggle Mode 0= Momentary 1= Toggle		0 to 1	Read/Write	Read/Write
%SR34	RS-232 Serial Protocol Mode 0= Firmware Update (RISM) 1= CsCAN 2= Generic (Ladder- Controlled) 3= Modbus RTU 4= Modbus ASCII			Read Only	Read Only

<b>%SR35-36</b>	Unique Serial Number / Hexadecimal LAN1 MAC ID			Read Only	Read Only
<b>%SR37</b>	Model Number			Read Only	Read Only
<b>%SR38</b>	Engine Version ( /100)			Read Only	Read Only
<b>%SR39</b>	BIOS Rev Number ( / 100)			Read Only	Read Only
<b>%SR40</b>	FPGA Image Rev Number ( / 10)			Read Only	Read Only
<b>%SR41</b>	Vertical Pixel Count			Read Only	Read Only
<b>%SR42</b>	Horizontal Pixel Count			Read Only	Read Only
<b>%SR43</b>	Keypad Type			Read Only	Read Only
<b>%SR44</b>	Real-Time-Clock Second	RTC_SEC	0 to 59	Read Only	Read Only
<b>%SR45</b>	Real-Time-Clock Minute	RTC_MIN	0 to 59	Read Only	Read Only
<b>%SR46</b>	Real-Time-Clock Hour	RTC_HOUR	0 to 23	Read Only	Read Only
<b>%SR47</b>	Real-Time-Clock Date	RTC_DATE	1 to 31	Read Only	Read Only
<b>%SR48</b>	Real-Time-Clock Month	RTC_MONTH	1 to 12	Read Only	Read Only
<b>%SR49</b>	Real-Time-Clock Year	RTC_YEAR	1996 to 2095	Read Only	Read Only
<b>%SR50</b>	Real-Time-Clock Day (1=Sunday)	RTC_DAY	1 to 7	Read Only	Read Only
<b>%SR51</b>	Network Error Count			Read Only	Read Only
<b>%SR52</b>	Watchdog-Tripped Error Count			Read Only	Read Only
<b>%SR53-54</b>	<b>Reserved</b>				
<b>%SR55.13</b>	Self-Test: Battery Low or Missing			Read Only	Read Only
<b>%SR56</b>	Key Currently Pressed No key = 0 (No key pressed since power-up) F1 = 1 F2 = 2 F3 = 3 F4 = 4 F5 = 5 F6 = 6 F7 = 7 F8 = 8 F9 = 9 F10 = 10 F11 = 11 F12 = 12 Enter = 13 +/- = 14 . (dot) = 15 0 = 16 1 = 17 2 = 18 3 = 19 4 = 20 5 = 21 6 = 22 7 = 23 8 = 24	LAST_KEY	0 to 255	Read Only	Read Only

	9 = 25 System = 26 Escape = 27 Left = 28 Right = 29 Up = 30 Down = 31 Shift = 32 Soft Key 1 = 34 Soft Key 2 = 35 Soft Key 3 = 36 Soft Key 4 = 37 Soft Key 5 = 38 Soft Key 6 = 39 Soft Key 7 = 40 Soft Key 8 = 41 Release = 255 (Keys pressed since power-up but not currently)				
<b>%SR57</b>	LCD Backlight Dimmer Register 0-100 = 0% to 100% On 100-255 = 100% On		0 to 255	Read Only	Read Only
<b>%SR57.16</b>	Disable Screen Saver			Read/Write	Read/Write
<b>%SR58</b>	User LEDs	USER_LEDS		Read/Write	Read/Write
<b>%SR59</b>	Engine Build Number (Only last three numbers displayed)			Read Only	Read Only
<b>%SR60</b>	Build Option Build Test = 0 Build Beta = 1 Build Product = 2		0 to 2	Read Only	Read Only
<b>%SR61</b>	Number of CsCAN Network IDs	NUM_IDS		Read Only	Read Only
<b>%SR62-130</b>	<b>Reserved</b>				
<b>%SR131-135</b>	OCS Model: ASCII, 10 characters			Read Only	Read Only
<b>%SR136</b>	Communication Download Timeout			Read Only	Read Only
<b>%SR137</b>	Communication Idle Timeout			Read Only	Read Only
<b>%SR138-148</b>	<b>Reserved</b>				
<b>%SR149-150</b>	Free-running 10kHz count: 1 count = 0.1ms (32-Bit DINT)			Read Only	Read Only
<b>%SR151</b>	<b>Reserved</b>				
<b>%SR153 - 163</b>	<b>Reserved</b>				
<b>%SR164</b>	FailSafe / Clone				
<b>%SR164.1</b>	RS-485 Port Biasing #1 (MJ1 or MJ2)			Read/Write	Read/Write
<b>%SR164.2</b>	RS-485 Port Biasing #2 (MJ2 or MJ3)			Read/Write	Read/Write
<b>%SR164.3</b>	Indicates Automatic Restore Operation has been performed	AUTO_RESTRD		Read Only	Read Only
<b>%SR164.4</b>	Indicates Backup of Registers has been taken	BCKUP_TAKN		Read Only	Read Only
<b>%SR164.5</b>	Enable AUTORUN – Sets “Enable AutoRun” to “Yes” or “No”	EN_AUTO_LD		Read/Write	Read/Write

%SR164.6	Enable AUTOLOAD – Sets “Enable AutoLoad” to “Yes” or “Not”	EN_AUTO_LD		Read/Write	Read/Write
%SR164.7	Start Backup trigger bit – Setting TRUE starts backup of all register data	STRT_BCKUP		Read/Write	Read/Write
%SR164.8	Clear Backup trigger bit – Setting TRUE clears backup of all register data (if a backup was done previously)	CLR_BACKUP		Read/Write	Read/Write
%SR164.9	MAKE_CLONE trigger bit = Setting TRUE does a Load Clone (if a media card is present)	MAKE_CLONE		Read/Write	Read/Write
%SR164.10	LOAD_CLONE trigger bit – Setting TRUE does a LOAD CLONE (if a media card is present that contains clone files)	LOAD_CLONE		Read/Write	Read/Write
%SR164.11	Make Clone Fail (This bit goes high when Make/Create Clone fails)	MK_CLN_FL		Read/Write	Read/Write
%SR164.12	Load Clone Fail (This bit goes high when Load Clone fails)	LD_CLN_FL		Read/Write	Read/Write
%SR164.14	<b>Reserved</b>			Read/Write	Read/Write
%SR164.15	<b>Reserved</b>			Read/Write	Read/Write
%SR165-166	<b>Reserved</b>				
%SR167	Screen Update Time, Default= 5ms		2 to 50	Read/Write	Read/Write
%SR168-170	<b>Reserved</b>				
%SR171	X-Coordinate Touched (current value) X-Coordinate Untouched (reverts to 0,0)			Read Only	Read Only
%SR172	Y-Coordinate Touched (current value) Y-Coordinate Untouched (reverts to 0,0)			Read Only	Read Only
%SR173	System-Function Disable		0 to 1	Read/Write	Read/Write
%SR174	Removable Media Protect			Read/Write	Read/Write
%SR174.1	Request Media Card be Removed			Read/Write	Read/Write
%SR174.2	Indicates safe to remove Media Card			Read/Write	Read/Write
%SR175	Removable Media - Status			Read Only	Read Only
%SR176-177	Removable Media Free Space (32-Bit DINT)			Read Only	Read Only
%SR178-179	Removable Media Total Space (32-Bit DINT)			Read Only	Read Only
%SR180	<b>Reserved</b>				
%SR181	Bits 1-16 indicate Unacknowledged in Alarm Groups 1-16	ALM_UNACK		Read Only	Read Only
%SR182	Bits 1-16 indicate Active in Alarm Groups 1-16	ALM_ACT		Read Only	Read Only
%SR183	Beep on Keypress Enable 0= Disabled 1= Enabled	SYS_BEEP	0 to 1	Read/Write	Read/Write
%SR184	Internal Beeper 0=OFF 1=ON	USER_BEEP	0 to 1	Read/Write	Read/Write
%SR185	Screen Saver Enabled 0= Disabled 1= Enabled		0 to 1	Read Only	Read Only

	<b>NOTE:</b> See %SR57.16				
%SR186	Screen Saver Time in minutes (delay)		5 to 1200	Read Only	Read Only
%SR187	Network Usage (Average)	NET_USE	0 to 1000	Read Only	Read Only
%SR188	Network Usage (Minimum)		0 to 1000	Read Only	Read Only
%SR189	Maximum Net Usage of all units on the CAN network		0 to 1000	Read Only	Read Only
%SR190	Network TX Usage % ( / 10) (Average)	NT_TX_AVG	0 to 1000	Read Only	Read Only
%SR191	Network TX Usage % ( / 10) (Minimum)		0 to 1000	Read Only	Read Only
%SR192	Network TX Usage % ( / 10) (Maximum)		0 to 1000	Read Only	Read Only
<b>EXTENDED SYSTEM REGISTERS</b>					
%SR193	Online Change	ONLINE_CHG			
%SR193.1	TRUE if 2 programs in target FLASH			Read Only	Read Only
%SR193.2	TRUE to switch programs, FALSE when complete			Read Only	Read Only
%SR193.3	TRUE if executing program is temporary test			Read Only	Read Only
%SR193.4	TRUE during last scan of switched-from program			Read Only	Read Only
%SR193.5	TRUE during first scan of switched-to program			Read Only	Read Only
%SR193.6	TRUE to revert to FLASH and delete all RAM; FALSE when complete			Read Only	Read Only
%SR193.9	TRUE if error in temporary program			Read Only	Read Only
%SR194	Battery Charge Temp Low			Read Only	Read Only
%SR195	Battery Charge Temp High			Read Only	Read Only
%SR196	Charging State <b>NOTE:</b> Refer to <a href="#">MAN1142</a> for more details on Rechargeable Batteries 0=Waiting 1=Normal Charging 2=Hot Charge 3=Hot Charge 4= Battery Hot 5= Cold Charge 6=Battery Cold 7=No Battery 8= Not Charging (after 8 hours of charging) 9= CPU Hot, not charging 10 Battery voltage <2V, not charging 11= First 2 minutes Init Wait (Not Charging)		0 to 11	Read Only	Read Only
%SR197	Charging Current Maximum Current mA			Read Only	Read Only
%SR198	Battery Voltage is mV			Read Only	Read Only
%SR199	<b>Reserved</b>				
%SR200	InitRD Version ( /100)			Read Only	Read Only
%SR201 - 205	Linux Kernel version: ASCII, 10 characters			Read Only	Read Only
%SR206-208	<b>Reserved</b>				
%SR209.3	WebMI Server Status. Bit 3 is ON if server running.			Read Only	Read Only
%SR209.4	WebMI User Logged in Status.			Read Only	Read Only

	Bit 4 is ON if 1 or more users logged in.				
<b>%SR209.8 - 209.14</b>	Number of Users. Shows in upper byte in decimal format.			Read Only	Read Only
<b>%SR210</b>	Time Zone: set in minutes $\pm$ UTC (Ex: Estimate is 4 hours behind GMT= -240 minutes)			Read/Write	Read/Write
<b>%SR211</b>	Daylight Saving: YES = 1 Daylight Saving: NO = 0 (If daylight saving is enabled, one hour will be added to the local time).			Read/Write	Read/Write
<b>%SR212</b>	UTC - Seconds			Read Only	Read Only
<b>%SR213</b>	UTC - Minutes			Read Only	Read Only
<b>%SR214</b>	UTC - Hours			Read Only	Read Only
<b>%SR215</b>	UTC - Date			Read Only	Read Only
<b>%SR216</b>	UTC - Month			Read Only	Read Only
<b>%SR217</b>	UTC - Year			Read Only	Read Only
<b>%SR218</b>	Number of Webpages, license detail			Read Only	Read Only
<b>%SR219</b>	Number of Data Points, license detail.			Read Only	Read Only
<b>%SR220-222</b>	Expiration Date of WebMI License, license detail			Read Only	Read Only

## I/O Register Map for XL15 Prime

**NOTE:** These registers can be used as general purpose registers

Registers	Description					
	no I/O	102 I/O	103 I/O	104 I/O	105 I/O	106 I/O
%I1-%I12	Unused	Digital Inputs				
%I13-%I16	Unused	Reserved		Digital Inputs	Reserved	
%I17-%I24	Unused		Reserved	Digital Inputs	Reserved	
%I25-%I29	Unused		Reserved			
%I30 - %I131	Unused	PWM Table, see "High Speed I/O (HSC/PWM) " on page 91				
%I32	Unused		ESCP Alarm* (Electronic Short Circuit Protection)			
%Q1	Unused	PWM Table , see "High Speed I/O (HSC/PWM) " on page 91				
%Q2-%Q6	Unused	Digital Outputs				
%Q7-%Q12	Unused	Reserved	Digital Outputs			
%Q13-%Q16	Unused	Reserved		Digital Outputs	Reserved	
%Q17 - %Q20	Unused	HSC Table, see "High Speed I/O (HSC/PWM) " on page 91				
%Q21-%Q24	Unused	Reserved				
%AI1-%AI4	Unused	Analog Inputs	%AI1 - %AI2 for Analog Input Channels %AI3 - %AI4 - Unused			Mirror of first four analog channels
%AI33 - %AI38	Unused					Analog Inputs - for all 6 channels
%AQ1-%AQ8	Unused		PWM Table, see "High Speed I/O (HSC/PWM) " on page 91			
%AQ9-%AQ10	Unused				Analog Outputs	

\*The ESCP bit is set high when the output current is too high, and the output driver has shut down for thermal protection. This typically happens when outputs are shorted, or they are driving loads that are higher than the output rating.

## XL15 Prime Resource Limits

Resource	Value
%S	13
%SR	448
%T	16000
%M	16000
%R	49999
%K	5
%D	1023
%I	2048
%Q	2048
%AI	512
%AQ	512
Ethernet	CsCAN, Ping, EGD, SRTP, Modbus TCP Master (Downloadable protocol) & Slave, Ethernet IP, FTP, or HTTP @ 10MBd or 100MBd
CsCAN	125kBd, 250kBd, 500kBd, or 1MBd
Serial Ports	1 RS-232 & 1 RS-485 on first Modular Jack (MJ1/2) 1 RS-232 or 1 RS-485 on second Modular Jack (MJ3)
IDs Per CsCAN Network	64 w/o repeat (253 w/ 3 repeaters)
Keypad	5 keys (4 Function keys and a System Key)
Display	15" XGA TFT (500 cd/m <sup>2</sup> typical)
Screen Memory	64MB
User Screens	1023
Data Fields Per User Screen	1023
Ladder Code	1024kB

# Cscape Configuration




## Chapter 7: Cscape Configuration

Cscape Status Bar .....	59
Establishing Communications .....	60
Cscape Configuration .....	68

XL15 Prime OCS hardware is programmed with a Windows based PC application called Cscape. This application can be used to program, configure, monitor, and debug all aspects of the XL15 Prime OCS unit. Please see the Online Help provided with Cscape for additional details.

### Cscape Status Bar

When the XL15 Prime OCS is connected to a PC using Cscape software, a Status Bar appears at the bottom of the screen. The Cscape Status Bar can be used to determine if communications have been established between the XL15 Prime OCS and the Cscape program. Components of the Cscape Status Bar are explained below:




HG-120

## Establishing Communications

The XL15 Prime OCS can communicate with Cscape using USB to USB, USB to serial adapters, serial port communications via MJ1 Port, onboard Ethernet Port, CAN (CsCAN), or modems.

If a direct USB connection is to be used, connect the USB-C port on the OCS to an open USB port on the PC. (Programming cable options are HE-PRG-A2C and HE-PRG-C2C). The OCS will install as a device once plugged in. Drivers for it are normally found automatically by the Windows operating system as long as an Internet connection is established.

See also the [Tools of the Trade](#) on the Horner website.




HG-681

The PC will detect a new device has been plugged into the USB port.

Now that the XL15 Prime is plugged in, go to **Cscape > Controller > Connection Wizard**. If you are just opening Cscape, Connection Wizard usually opens by default.




Select USB and click **Next >>**.




HG-115


If the Connection Wizard does not pop up upon opening Cscape, then select **Controller** (in the Cscape tool bar) > **Connection Wizard**, choose your connection method. If you are connecting for the first time, we suggest connecting via USB.



If **Controller USB COM Port** is not present in the dropdown list, the Windows operating system has not yet recognized the OCS as an installed device. Be sure the installation process is complete and that the correct drivers are installed. The Connection Wizard must be completely closed and reopened to refresh the USB dropdown list.

An alternate way to select the COM setting is to go to **Cscope > Tools > Application Settings > Communication > Configure** and choose connection method in **Add Target**.





<b>Communication Configuration Dialog</b>	
<b>Target Name</b>	Name for connection. This is not a mandatory column to be filled, by default Cscape will populate 'Default1' in edit box.
<b>Connection Medium</b>	
<b>Com Port</b>	Select this option to communicate over serial communication with the device. The port number can be configured here.
<b>Ethernet</b>	Select this option to communicate over Ethernet. Provide the IP address of the device. Select Built in/ ETN Ethernet mode if the device has on-board Ethernet port. NOTE: The controller should support the type of connectivity selected and configured for Ethernet communication.
<b>Installed Modem</b>	Select this option to communicate to the device through the internal modem of the computer. Cscape will automatically detect the internal modem attached with PC and list in the attached drop down. User can select modem and telephone number for target controller. NOTE: Cscape will do necessary initialization for the selected internal modem.
<b>USB</b>	Select this option to communicate over USB. Hornor devices and Hornor USB to serial converters are recognized and can be specifically selected.
<b>Connected Device</b>	
<b>NOTE:</b> This configuration is required if the controller to which Cscape is communicating is connected to a CsCAN network.	
<b>Connected Device</b>	By default, this option is selected and networking feature of Cscape is disabled.
<b>Target Node ID</b>	On selecting this option, Networking feature of Cscape is enabled. CsCAN ID for the target controller to be provide here.
<b>Connection Settings (General Communication Settings)</b>	
<b>Maximum Baud Rate</b>	Select the baud rate for serial communication.
<b>Timeout</b>	Select the communication timeout. NOTE: Select a larger timeout for GPRS and installed modem communication configuration

If communications are successful, the message line should show “USB (COM8)” for this example, and an (R) should follow the Target number.

USB (COM8)	User: NONE	XL4e - CsSCAN Model Equal	Not Equal	Local:1 Target:1 (R) [no forces]
------------	------------	---------------------------	-----------	----------------------------------

When connected directly to the controller to which Cscape communications are required, the **Local ID** and the **Target ID** should match.

↑ ↑  
**Local ID** and **Target ID** match.


HG-446

If the controller is not communicating, you may need to set the target ID of the controller in Cscape or on the unit. The Target ID allows directing communications to a particular unit when multiple units are connected via a CsCAN network. Units without CsCAN network ports respond to any network ID and do not require the ID to be configured.




To check or change the ID on XL15 Prime OCS, press the System Menu key.

The first item in the menu is Set Networks. Pressing Enter allows you to view or modify the ID of the unit.



To change the Target ID of Cscape, highlight CAN ID and press **Enter** to provide a new number.



## Communicating via MJ1 Serial Port


If a serial programming connection is to be used and the PC has a 9-pin serial COM port, which is increasingly rare, there is nothing to install assuming the port already works. All that is needed is a programming cable to go from the COM port to the OCS programming port.

If a serial programming connection is to be used and the PC does not have a COM port, a USB-to-Serial adapter may be used. Drivers for it are normally found automatically by the Windows operating system as long as an internet connection is established. Otherwise, the drivers may be loaded from the Horner FTP site at <https://hornerautomation.com/support-files>.

- Connect the PC's serial port or the USB-to-Serial adaptor to the port labeled MJ1 on the XL15 Prime.
- The instructions are similar to using a USB port, as shown above. In the Connection Wizard, select the "Serial" option.
- If communications are successful, the target indicator should show the mode of the controller Target: yy(R) as shown in the "Cscape Status Bar" on page 59.
- If the controller is not communicating, you may need to set the **Target ID** of the controller in Cscape or on the unit. The **Target ID** allows directing communications to a particular unit when multiple units are connected via a CsCAN network. Units without CsCAN network ports respond to any network ID and do not require the ID to be configured.
- To check or change the ID on the XL15 Prime OCS, press the System Menu Key.
- The first item in the menu is Set Networks. Pressing Enter allows you to view or modify the ID of the unit.
- Pressing Enter allows you to view or modify the ID of the unit.
- To change the Target ID of Cscape use the **Controller > Set Target Network ID** dialog.

## Communicating via On Board Ethernet Port

From Cscape go to **Controller > Hardware Configuration** and do auto configuration for the connected controller. Click on Config of Ethernet and select Module Setup.



**Hardware Configuration**

Controller: Local I/O | CAN1 (CsCAN) I/O | CAN2 (CsCAN) I/O | LAN1 I/O | LAN2 I/O

Series: XL Prime OCS Series

Device Type: XL15 Prime

Model #: HE-XP15E2

Network Ports:

- CAN1: CsCAN [Config]
- CAN2: CsCAN [Config]
- LAN1: ETN300 [Config]
- LAN2: ETN300 [Config]

Serial Ports [Config]

OCS Wi-Fi Module [Config]

Description: Touch screen Operator Control Station with fixed I/O

Properties:

- Display Type: 480 by 640 LCD
- Keypad Type: Touch + 7 F keys
- Program Memory: 2048 K Bytes
- Network Type: CsCAN

Advanced Ladder Functions:

- Supports Analog Data
- Real Time Clock Support
- Supports Retentive Data


Auto Config

OK Cancel Apply Help

H3-555

The IP address, netmask, and default gateway of the controller may be temporarily set from the System Menu under the Set Networks menu item. Once running or power cycled the configuration will come from the Cscape configuration stored in the unit.

In Module configuration dialog, go to IP Address field enter unused IP Address and configure unused registers in Register field & then click OK. Screen shot for the same as follows:



Download the configuration in to Controller. Connect LAN cable to the Controller in default LAN Port.

From Cescape go to **Tools > Editor Options > Communication Port > Configure**. Select Ethernet and enter IP address which is configured in the file. Select mode as XL Series mode from drop down list.


The controller should get connected to Cescape. If communications are successful, the target indicator should show the mode of the controller Target: yy(R) as shown in the as shown in the "Cescape Status Bar" on page 59 section.

## Cscape Configuration

An overview of configuration:

1. Start the configuration by selecting the Controller > Hardware Configuration menu item.
2. If the XL15 Prime OCS is connected to the PC press the Auto Config System button to automatically detect the Base model, I/O and any communication options.
3. If the XL15 Prime OCS is not connected press the Config button to the right of the top of the unit. This allows the base CPU to be selected.
4. Select either XL15 Prime OCS CsCAN from the type drop down box.
5. Once the type of XL15 Prime OCS is selected, the model # drop down box will provide the XL15 Prime OCS model numbers from which to choose from.
6. Once the XL15 Prime OCS CPU is selected, press OK to exit the dialog and configure the I/O that is present in the first slot.
7. The I/O configure dialog (Specifically the Module Setup tab) provides four (4) buttons to configure all of the I/O. Go through each area of I/O and configure it.
8. Once done configuring the I/O, OK out of configuration dialogs.

Configuring the XL15 Prime OCS I/O has four main portions that are covered in this chapter. For additional information on I/O, refer to "General I/O Configuration" on page 1 or "High Speed I/O (HSC/PWM) " on page 91.



The four areas of Hardware configuration are Digital in / HSC, Digital out / PWM, Analog In, Analog Out.

# General I/O Configuration



## Chapter 8: General I/O Configuration

Built-in Digital and Analog I/O Overview .....	70
Removing the Back Cover .....	71
Digital / HSC Input Configuration .....	72
Digital / PWM Output Configuration .....	75
Analog Input Configuration .....	81
Analog Outputs .....	88

### Built-in Digital and Analog I/O Overview

The Horner OCS is a compact unit that contains high density and very versatile I/O. Using the I/O properly requires wiring to the proper terminals, configuring jumpers inside the Horner OCS unit and configuring Cscape properly. This section will offer some tips and suggestions to configure the I/O properly. For the register mapping of the I/O, refer to the "System Register Tables" on page1 for more details.

Built-in Digital & Analog I/O								
Digital				Analog				
	DC In	DC Out (+)	Relay Out	HSC In*	Pulse Out**	mA/V In	mA/V RTD/TC (Universal)	mA/V Out
<b>Model 2</b>	12	--	6	4	--	4	--	--
<b>Model 3</b>	12	12		4	2	2	--	--
<b>Model 4</b>	24	16	--	4	2	2	--	--
<b>Model 5</b>	12	12	--	4	2	2		2
<b>Model 6</b>	12	12	--	4	2	--	6	4

\*Shared with total DC inputs

\*\*Shared with total DC outputs

For more details, see the controller datasheets via [Document Search](#).


## Removing the Back Cover

**WARNING: Power, including I/O power must be removed from the unit prior to removing the back cover. Failure to do so could result in electrocution and/or damage to equipment.**

Some I/O configurations require jumper settings to be changed inside the Horner OCS unit. Examples of these settings are setting positive or negative logic on digital inputs or setting current or voltage on analog inputs.


Each Horner OCS I/O jumper is set to a factory default. Refer to the datasheet for a specific Horner OCS model to find the default setting to determine if a jumper change is necessary. Refer to Horner's [Documentation Search](#) page.

To remove the back cover of the Horner OCS, remove the four (4) Phillips screws from the back of the unit. It may help to place the Horner OCS unit face down on a clean work surface. Once the four screws are removed the back cover can be lifted straight off.



HG-166

Once the back is removed the jumper selection can be changed. The jumper settings are documented on each data sheet using a diagram such as the figure below and a description of the jumper settings.



To re-install the back cover, place the cover back on the unit. The DIN clip should be on the same side as the power connector. Place the screw back into the hole and turn the screw slowly counter clockwise until it clicks into the threads. This prevents the screw from being cross-threaded. Now turn the screw clock-wise until the cover is firmly secured. Repeat this process for all four (4) screws. Recommended torque is 3 - 4 in-lbs (0.34 – 0.45 Nm).


## Digital / HSC Input Configuration

Horner controllers vary greatly based on series and model numbers. Refer to the datasheets on the [Document Search](#) table on the Horner website.

The inputs are designed to support both positive and negative input modes. For many models, the mode is set by a jumper setting and a configuration parameter in Cscape. The Model 6 does not require jumpers, and only requires a configuration parameter in Cscape. All the inputs on the unit must be configured to the same mode.

### Positive Logic vs. Negative Logic Wiring

The OCS can be wired for positive logic inputs or negative.



In positive logic mode a positive voltage applied to the input will turn the input. The internal design of this mode is basically a resistor from the input to I/O ground. This mode is sometimes called sourcing or PNP.


In negative logic mode, connecting the input to the I/O ground or zero volts will turn the input on. The internal design of this mode is basically a resistor from the input to the positive I/O voltage (usually 12 or 24V). This mode is sometimes called sinking or NPN.

Some of the digital inputs may support high-speed input functional such as counting or frequency measurement.


## Digital Input Configuration

Home > Hardware Configuration [select Device Type/Model#] > Local I/O Tab > I/O / Config Button > Module Setup > Digital In/HSC


Select Hardware Configuration from the Home menu and ensure that the correct Device Type and Model# are selected. Then select the **Local I/O** tab.



After selecting Local I/O, select the **Config** button next to the I/O connector.




The **Module Configuration** screen will appear, select the **Module Setup** tab. See below.



The Module Setup allows a user to configure four types of I/O. **NOTE:** Not all controllers offer all four types. Refer to the controller's datasheet on the using Horner's [Documentation Search](#) page.

Select **Digital In/HSC** to open the Digital / HSC Input configuration dialog for a specific controller.



The dialog box is titled "Digital / HSC Input Configuration". It contains several sections:

- Digital inputs active mode:** Radio buttons for "Positive Logic" (selected) and "Negative Logic". A note states: "Note: This setting must match that of the jumpers on the product".
- Counter Modes:** Radio buttons for "2 Counter mode" (selected), "4 Counter mode", "8 Counter mode", and "Custom mode". A note states: "Note: 2 Channel Supports: 1) 2-HSC, 2) 2-Quadrature, 3) 2-Stepper Outputs".
- HSC I/O Mapping:** Four rows for mapping digital and analog inputs/outputs to specific channels (e.g., %I1601, %AI401, %Q1601, %AQ401).
- HSC I/O Filtering:** Checkboxes for %I9, %I10, %I11, and %I12. A "Filter Frequency" slider (1KHz to 10MHz) and a "Number of Samples" slider (1 to 10).
- Counter1 | Counter2:** A section for configuring individual counters. It includes a "Type" dropdown (set to "Disabled"), a "Mode" dropdown, and various function dropdowns (Disable Function, Latch Function, Preload Function, Clear Function, Marker, Match) with associated "Polarity" dropdowns.

Buttons for "OK" and "Cancel" are at the bottom right. The label "HG-524" is at the bottom left.

The Active mode group box allows the user to select if inputs are active high (Positive logic) or active low (Negative logic). It is important that this setting matches the jumper settings on the hardware.

The High-Speed Counters group box contains all the windows that are used to configure the four available high-speed counters on the Horner OCS. To configure a counter, the user needs to set the type, mode, and counts per rev.

The type drop down includes the following options:

- Disabled
- Frequency
- Totalize
- Pulse
- Quadrature
- Marker (Only available in counter #3 if counter #1 is set to quadrature.)


The mode drop-down items are set according to the type selection. The Counts Per Rev. window is enabled/disabled according to the type selection as well.

## Digital / PWM Output Configuration

### Solid State Digital Outputs

Solid-state digital outputs are generally used to activate lamps, low voltage solenoids, relays, and other low voltage and low current devices.

**NOTE:** The digital outputs used on some controllers are sourcing outputs. This means the output applies a positive voltage to the output pin when turned ON. When turned off, the output applies approximately zero volts with respect to the I/O ground. Use the Documentation Page to view the datasheet for a specific controller for specifics on a module's I/O.



The digital outputs used in the OCS have electronic short circuit protection and current limiting. While these electronic protections work in most applications, some application may require external fusing on these outputs.

The digital outputs in the OCS are typically controlled via %Q bits in the register mapping. Some of the outputs are designed for high-speed applications and can be used for PWM or frequency output applications.

When the controller is stopped, the operation of each output is configurable. The outputs can hold the state they were in before the controller stopped or they can go to a predetermined state. By default, digital outputs turn off.

**NOTE:** The digital outputs feature an output fault bit. %I32 will turn on if any of the outputs experience a short circuit, over-current or the output driver overheats.

## Relay Outputs


Relay outputs are designed to switch loads that typically have high voltage or current requirements or require the isolation that relays provide. Relay outputs are not available on all controllers, see the datasheet. **NOTE:** The design of the OCS does not require external coil power for the relays to function. The relays will activate anytime the OCS is powered. There are several factors that should be considered when using relays:

- **Relay Life** – Relays are mechanical devices that have a long but limited life. Typically, switching more current limits the life of relays. Please check the data sheets at the end of this manual for expected relay life.
- **Current / Temperature Derating** – Products containing relays often have total current limits based on the ambient temperature of the application. Please see the product data sheet for current / temperature derating information for relays.
- **Fusing** – External fusing is generally required to protect the relays, devices and wiring from shorts or overloads.

**WARNING:** To protect the module and associated wiring from load faults, use external (5A) fuse(s) as shown. Fuses of lower current or fusing for the entire system need to be in place to assure the maximum current rating of the unit is not exceeded.

**WARNING:** Connecting high voltage to any I/O pin can cause high voltage to appear at other I/O pins.

Below is an example of Relay Fusing:




**Protection for Inductive Loads** - Inductive loads can cause reverse currents when they shut off that can shorten the life of relay contacts. Some protective measures need to be determined by an engineer. Below you will find recommendations that will work for many applications. If you have additional questions on protection from inductive load, consult an application engineer or Horner Technical Support. Details on devices that may protect outputs can be found in the [Spark Quencher Datasheet](#), MAN0962, which is located on the website.

**Output State on Controller Stop** - When the controller is stopped, the operation of each output is configurable. The outputs can hold the state they were in before the controller stopped or they can go to a predetermined state. By default, relay outputs turn off.


## Digital Output Configuration

**Home > Hardware Configuration [select Device Type/Model#] > Local I/O Tab > I/O / Config Button > Module Setup > Digital Out/PWM**


Select Hardware Configuration from the Home menu and ensure that the correct Device Type and Model# are selected. Then select the **Local I/O** tab.




After selecting Local I/O, select the **Config** button next to the I/O connector.




The **Module Configuration** screen will appear, select the **Module Setup** tab. See below.



The Module Setup allows a user to configure four types of I/O. **NOTE:** Not all controllers offer all four types. Refer to the controller's datasheet the using Horner's [Documentation Search](#) page.



Select **Digital Out/PWM** to open the **Digital / PWM Output Configuration** dialogue.



The dialog box is titled "Digital / PWM Output Configuration". It contains two main sections for Q1 and Q2 outputs. Each section has radio buttons for "Normal", "PWM #1", "HSC1 Output", and "Stepper". To the right of these sections are fields for "Starting Analog Out" (set to %AQ421 x 20) and "Starting Digital In" (set to %I1617 x 4). Below these are two sections: "PWM State on Controller Stop" and "Output State on Controller Stop". The PWM section has fields for duty cycle and frequency for both PWM #1 and #2, each with a "Hold Last State" checkbox. The Output State section shows a grid of 12 output states (1-12) with icons representing their state. A legend at the bottom explains the icons: a square with a diagonal line for OFF, a square with a solid fill for ON, and a square with a red border for Hold Last State. OK and Cancel buttons are at the bottom right.

The **Q1** and **Q2** group boxes allow the user to specify the operation of the multifunction outputs.

**PWM State On Controller Stop** - Contains items that allow the user to specify how the PWM outputs behave when the controller is stopped. These items can either hold their value or default to some value when the controller is stopped.

**NOTE:** The PWM outputs are set to the OFF state at power-up and during program download and remain in that state until the unit is placed in RUN.

**Output State On Controller Stop** - Contains items to allow the user to specify how the remaining digital outputs behave when the controller is stopped. These items can either hold their value or default to some value when the controller is stopped. **NOTE:** The number of Output States on Controller Stop vary by product.

**Stop State** - When a controller stops running ladder logic, the state of most output I/O modules can be configured. By default digital outputs turn OFF and analog outputs go to a zero output level. Outputs can be configured to hold the last state the outputs was in when the controller stopped, or it can be configured to go to a predefined state. **NOTE:** When a controller is in DO I/O mode the outputs are still controlled by the values in the controller's registers.


**NOTE:** The number of Output State on Controller Stop varies by controller. See the datasheet on the Documentation Page for more details.

## Analog Input Configuration


The analog inputs on the OCS allow voltage or current measurement from a variety of devices. The voltage or current mode is set though jumpers on the unit and settings in Cscope. Each channel can be separately configured for voltage or current mode. The analog inputs have a digital filter that can be used to filter electrical noise that may be unavoidable in some installations. The downside to digital filtering is the inputs will respond more slowly to sudden changes in the actual input.

**Home > Hardware Configuration [select Device Type/Model#] > Local I/O Tab > I/O / Config Button > Module Setup > Analog In**

Select Hardware Configuration from the Home menu and ensure that the correct Device Type and Model# are selected. Then select the **Local I/O** tab.




After selecting Local I/O, select the **Config** button next to the I/O connector.




The **Module Configuration** screen will appear, select the **Module Setup** tab.

The Module Setup allows a user to configure four types of I/O. **NOTE:** Not all controllers offer all four types. Refer to the controller's datasheet on the Horner website's Documentation Page for more information regarding specific models.



Select **Analog In** to open the **Analog Input Configuration** dialogue:



The Channel x drop down windows allow the user to specify the mode for each analog input to operate. The Channel x drop down windows are enabled/disabled according to which model is being configured. All of the models have the following modes available: 0..10V, 0..20mA & 4..20mA.

On the XL Prime series, the Model 5 and Model 6 modules have more channel options.

## Universal Analog Inputs Model 5


The universal analog inputs provide a high resolution, very flexible interface for a variety of analog inputs. These inputs include voltage, current, thermocouple, RTD, and millivolt. Each channel can be configured separately using jumpers and configuration settings in Cscope.

Like the standard analog inputs, these inputs have a digital filter that can be used to filter electrical noise that may be unavoidable in some installations. The downside to digital filtering is the inputs will respond more slowly to sudden changes in the actual input.


Analog In for Model 5
Channels 1 & 2
0..10V
0..20mA
4..20mA
100mV
PT100 DIN RTD, 1/20°C
Type J Thermocouple, 1/20°C
Type K Thermocouple, 1/20°C
Type N Thermocouple, 1/20°C
Type T Thermocouple, 1/20°C
Type E Thermocouple, 1/20°C
Type R Thermocouple, 1/20°C
Type S Thermocouple, 1/20°C
Type B Thermocouple, 1/20°C
* The <b>Filter Constant</b> provides filtering to all channels.

## Model 5 Universal Analog Input Configuration

1. Select Analog In to access the Analog Input Configuration menu.
2. Select any of the Analog input types from the drop-downs by clicking the down arrow beneath each corresponding Channel, as seen below:



3. Ensure the proper wiring is used for each of the pins on the Universal Analog Inputs as seen in the image and table below:



**Table for Model 5 Universal Wiring**

J3 Connector for Universal Wiring	
T1+	TC (1+) or RTD (1+) or 100mV (1+)
T1-	TC (1-) or RTD (1-) or 100mV (1-)
T2+	TC (2+) or RTD (2+) or 100mV (2+)
T2-	TC (2-) or RTD (2-) or 100mV (2-)
AQ1	10V or 20mA OUT (1)
AQ2	10V or 20mA OUT (2)

<b>J3 Connector for Universal Wiring</b>	
0V	Common
MA1	0-20mA IN (1)
V1	0-10V IN (1)
0V	Common
MA2	0-20mA IN (2)
V2	0-10V IN (2)
0V	Common


## Universal Analog Inputs Model 6

The Universal Analog Inputs on the Model 6 IO board are unique from other Horner XL-series input/output cards in that they are configurable through the module configuration instead of having to change jumper settings in order to setup the input type.


Analog In for Model 6
Channels 1-6
0..10V
0..20mA
4..20mA
Disable
0-60mV
PT100 DIN RTD, 1/10°C
PT1000 DIN RTD, 1/10°C
Type J Thermocouple, 1/10°C
Type K Thermocouple, 1/10°C
Type N Thermocouple, 1/10°C
Type T Thermocouple, 1/10°C
Type E Thermocouple, 1/10°C
Type R Thermocouple, 1/10°C
Type S Thermocouple, 1/10°C
Type B Thermocouple, 1/10°C

## Model 6 Universal Analog Input Type Configuration

1. Select Analog In to access the Analog Input Configuration menu.
2. Select any of the Analog input types from the drop-downs by clicking the down arrow beneath each corresponding Channel, as seen below:



3. Ensure the proper wiring is used for each of the 3 pins A, B, and C on the Universal Analog Inputs as seen in the reference image below:




## Scaling Analog Inputs & Examples

To access the Advanced Math Scaling function, select **Home > View > Project Toolbox**. This will open a side bar, and then select **Advanced Math > Scale**.


### Example 1

The Cscape Scale function, found in the Advanced Math functions, allows for very easy conversion of the raw input value into a meaningful reading. For example, a pressure transducer may be specified as a 4-20mA signal to signify a 0-2000 psi pressure reading. With the analog channel set to the 4...20mA range, the raw analog input value, which is in INT format ranges from 0 to 4mA to 32000 for 20mA. Use the Scale function to obtain an Integer pressure reading using the 0-32000 raw input range and the sensor's 0-2000psi output range.



### Example 2:

If readings with fractions are required, the raw Integer input value must first be translated in REAL, or Floating Point Format, see note below. . The Cscape INT-to-REAL Conversion function may be used to convert the raw input value from INT to REAL format in an intermediate memory location. The SCALE function, specified as REAL type, may be used to scale the converted raw value into a reading that supports digits beyond the decimal place, i.e. 475.25psi.



## Analog Outputs

**NOTE:** Refer to the datasheet for details on jumper settings.


The analog outputs on Horner OCS devices provide high resolution voltage or current outputs. The voltage or current selection is controlled with jumpers and configuration settings in Cscape.

**NOTE:** Each channel can be separately configured for voltage or current mode.

When the controller is stopped, the operation of each output is configurable. The outputs can hold the state they were in before the controller stopped or they can go to a predetermined value. By default,

analog outputs are set to a value of zero (0).

The following figure illustrates the Analog Output Configuration dialog. To open the I/O configuration dialogs, select **Controller > Hardware Configuration > Local I/O > Config > Module Setup**.



The Output value on Stop group box contains items that allow the user to specify how the analog output channels behave when the controller is stopped. The outputs can either hold their value or default to a value when the controller is stopped.

The Output Mode group box allows the user to select the operating modes for each of the analog outputs. The modes include the following:

- 0..10V
- 0..20mA
- 4..20mA

For more information on Stop State, refer to the "Cscape Configuration" on page 1.

# High Speed I/O (HSC & PWM)



## Chapter 9: High Speed I/O (HSC/PWM)

9.1: Overview .....	91
9.2: High Speed I/O Glossary .....	92
9.3: High Speed Counter (HSC) Functions .....	93
9.4: HSC Functions .....	96

### 9.1: Overview

In addition to the compliment of simple analog and digital I/O, several of the OCS I/O modules support High Speed Counting (HSC) I/O functions and may also support Pulse Width Modulation (PWM) Output functions (non-relay modules).

- The HSC functions include internal timing, frequency, totalizing, pulse width/period, and quadrature measurement.
- The PWM functions include traditional PWM (with variable rate and duty cycle) and a stepper (limited functionality) with variable acceleration and deceleration rates.

The OCS contains a Field-Programmable Gate Array (FPGA), which is an integrated configurable circuit that allows the OCS to be programmed to have either two high-speed counters or four high-speed counters. The OCS ships with two high-speed counters, but a customer can contact Horner Technical Support to receive a file that will configure the unit to have four.

These modes are not supported simultaneously

- Two counter mode supports Quadrature mode and two stepper outputs
- Four counter mode does not support Quadrature mode and supports only one stepper output

This chapter describes the operation of these high level I/O functions. For configuration details of these functions, see "Cscope Configuration".

## 9.2: High Speed I/O Glossary

Glossary of High Speed I/O Terms	
<b>Accumulator</b>	Register used to accumulate or store up a sum or count of many items or events.
<b>Clear</b>	A special function to zero out the value in a specific register. - Not used with Frequency or Period Measurement.
<b>Disable</b>	A special function to prevent the counter from running.
<b>Encoder</b>	A sensor or transducer for converting rotary motion or position to a series of electronic pulses
<b>FPGA</b>	An integrated, configurable circuit that allows the controller to be programmed to have either two high-speed counters or four high-speed counters.
<b>Frequency Input</b>	The number of times an electromagnetic signal repeats an identical cycle in a unit of time, usually one second.
<b>Latch (strobe)</b>	A special function that uses a digital logic circuit to store one or more bits. A latch has a data input, a clock input and an output. When the clock input is active, data on the input is "latched" or stored and transferred to the output register either immediately or when the clock input goes inactive. The output retains its value until the clock goes active again.
<b>Marker</b>	Input into the OCS that indicates a particular position. Typically, an encoder has a marker output that represents a specific point in the rotation.
<b>Polarity</b>	A Polarity pull-down box is associated with each function and indicates the manner in which the trigger happens (e.g., High level, Low Level, Falling Edge, Rising Edge).
<b>Preload (load)</b>	A special function used to trigger loading of a value into a register upon an event. - Not used with Frequency or Period Measurement.)
<b>Quadrature</b>	A high-speed device that expresses the phase relationship between two periodic quantities of the same period when the phase difference between them is one fourth of a period. A coupler in which the two output signals are 90° out of phase.
<b>Totalizer</b>	A counter that sums the total number of cycles applied to its input.

## 9.3: High Speed Counter (HSC) Functions

The OCS supports two or four high speed configurable counters. There are four dedicated inputs that can be configured to a number of different options. Each of the two counters can run in one of five modes. Those modes are Totalizer, Frequency Counter, Pulse Width Measurement, Period Measurement and Quadrature measurement. For some modes, more than one HSC input may be consumed. The measurement values are provided to ladder in a %AI register. Refer to the **Register** chapter for more details.

### 9.3.1: Frequency

**In frequency mode**, the frequency of the input signal is written to the accumulator in terms of hertz (cycles/second). When using frequency mode, four update selections are provided that specify the width of the sample window.

**NOTE:** Selecting a shorter sample window provides a quicker measurement (faster response) but lowers the frequency accuracy (resolution) and increases the minimum frequency measurement limit. In this mode the Disable and Latch special functions are allowed. Refer to the "High Speed I/O Glossary " on the previous page "High Speed I/O Glossary " on the previous page for a description of these functions.

### 9.3.2: Totalize


**In totalize mode**, the accumulator is incremented or decremented each time the input transitions in a specific direction.

The totalizer supports the following modes:

<b>Internal</b>	This mode ties the input to the counter to an internal 10MHz or 1MHz clock. The special functions can be used to accurately time events.
<b>Count Up</b>	This increments the accumulator when the input is enabled.  <b>NOTE:</b> Two inputs can be assigned. Either input can cause the counter to increment. The second input can also be disabled.
<b>Count Down</b>	This decrements the accumulator when the input is enabled.  <b>NOTE:</b> Two inputs can be assigned. Either input can cause the counter to decrement. The second input can also be disabled.
<b>Up/Down (Input 1 Up/Input 2 Down)</b>	In this mode, Input 1 (assigned to any of the four inputs) increments the counter, while Input 2 (also assigned to any of the 4 inputs) decrements the counter.
<b>Clk/Dir (Input 1 Clk, Input 2 Dir)</b>	This mode uses input 1 as a clock signal to increment or decrement the counter and then uses input 2 to decide the direction. Input 2 disabled increments the counter, while input 2 enabled decrements the counter.

**NOTE:** The totalize mode enables the Disable, Latch, Preload, and Clear special functions. Refer to the "High Speed I/O Glossary " on the previous page for a description of these functions.

**NOTE:** Counter triggers off the **rising edge** of the signal.



Three different options are available to reset the current count:

The totalize function also supports an option which compares the current accumulator value with a supplied Preset Value (PV), which is provided through a %AQ, and drives a physical digital output based on the that comparison.

**NOTE:** This option (available for HSC1 and HSC2 only) drives Q1 or Q2 output point (respectively) once the associated totalizer accumulator reaches (or exceeds) the PV value. To enable this function, the corresponding PWM function output (Q1 or Q2) must be configured for HSCx Output.


**NOTE:** Q1 and Q2 are PWM function outputs that may be configured independently as one of the following: standard digital output, PWM, HSCx or stepper output.

Preset values may be modified during run-time. A preset value of zero disables (resets) the totalizer compares function output causing the output to remain low.


### 9.3.3: Pulse Width Measurement

In **pulse width measurement mode**, the high-speed input can measure the width of a pulse stream in one of two modes and provides a continuous indication of the last sampled value. In this mode the Disable and Latch special functions are allowed. Refer to the "High Speed I/O Glossary " on page 92 for a description of these functions.

**Width High 1  $\mu$ s Counts** – In this sub-mode the accumulator value will contain the number of 1  $\mu$ s counts the pulse is high.




**Width Low 1  $\mu$ s Counts** – In this sub-mode the accumulator value will contain the number of 1  $\mu$ s counts the pulse is low.




### 9.3.4: Period Measurement

In **period measurement mode**, the high-speed input can measure the period of a pulse stream in one of two modes and provides a continuous indication of the last sampled value. In this mode, the Disable and Latch special functions are allowed. Refer to the "High Speed I/O Glossary" on page 92 for a description of these functions.

**Period Rising Edges 1  $\mu$ s Counts** – In this sub-mode the period of the input signal is reported in one (1)  $\mu$ s units. The period measurement will start on the rising edge of the input.




**Period Falling Edges 1  $\mu$ s Counts** – In this sub-mode the period of the input signal is reported in 1  $\mu$ s units. The period measurement will start on the falling edge of the input.



### 9.3.5: Quadrature

**Quadrature mode** uses two HSC inputs, any of the four HSC inputs can be assigned for this purpose. Quadrature mode works much like the totalizer except the accumulator will automatically increment or decrement based on the rotation phase of the two inputs. See the following example for more details. Quadrature inputs are typically used for reporting the value of an encoder.

Two modes are available for quadrature that select whether the accumulator counts up or down when the phase of Input 1 leads Input 2. Confirm with the encoder documentation to determine the output form it uses or try both modes to determine if the encoder counts up when expected.



Using the above waveforms and a HSC input configuration of "Quadrature" - "1 leads 2, count up," the accumulator will count up when 1 is rising and 2 is low, 1 is high and 2 is rising, 1 is falling and 2 is high, and when 1 is low and 2 is falling. This results in 4 counts per revolution. So in order to determine the number of cycles, the accumulator would have to be divided by 4.

Marker reset operation is configured in the special operations and can be assigned to any of the 4 high speed inputs or can be assigned to be controlled by a "Q" bit in ladder.

**NOTE:** The quadrature mode enables the Disable, Latch, Preload, Clear and Marker special functions. Refer to the "High Speed I/O Glossary" on page 92 for a description of these functions.

### 9.3.6: Register Match

Totalizer & Quadrature counter modes support a register match function. When the accumulator value matches either the Match 1 or Match 2 value configured in the corresponding %AQ registers, a high-speed output can Turn On, Turn Off, or Toggle. An internal %I register mirrors the output state whether the high-speed output is configured or not. The output can be reset in program logic using the corresponding %Q registers.

1. 2-Counter Mode has Register Match support for both counters.
2. 4-Counter Mode has Register Match support only for counters 1 and 2.

3. The High-Speed Outputs are %Q1 for Counter 1 and %Q2 for Counter 2. They operate as high-speed outputs, independent of the controller scan rate, when configured as 'HSC Output' in the Digital Out/PWM configuration in Cscape.
4. The High-Speed Output state reflects in the status register "High Speed Out", e.g. %I1603 for Counter 1 (the update speed of the status bit is scan rate dependent)
5. The High-Speed Output can be reset through ladder with the assigned output, e.g. %Q1606 for Counter 1
6. Both Match 1 and Match 2 values will trigger the match function.
7. If the output is already triggered by any Match register while using 'Turn On' or 'Turn Off' modes, subsequent matches will not affect the output.
8. If using 'Toggle' mode, every match of either Match value will toggle the output to the opposite state.

## 9.4: HSC Functions

The high-speed input on the OCS contains many optional tasks. All of which can be disabled, or set to an internal pre-assigned register (Assigned %Q) or to one of the external high speed inputs (External Input #1, 2, 3, or 4), or they can be set as an "overflow interrupt" or "underflow interrupt" meaning that they will occur when either the Overflow or Underflow input has been activated.

- **Disable:** When the Disable function is active, it will "disable" the high-speed inputs and no longer count pulses until it is re-enabled
- **Latch:** When the Latch function is active, it takes the current value of the Accumulator and moves it into the "Latch Value" register
- **Preload:** When the preload function is active, it will take the value from the "Preload" register and put it into the "Accumulator" for the corresponding Counter.
- **Clear:** When the clear function is active, it will move a value of 0 into the "Accumulator" for the corresponding counter.
- **Marker:** When the marker function is enabled, it acts as a dynamic enable/disable for the Disable, Latch, Preload, and Clear functions. If the marker is enabled and "Assigned %Q" is selected, then both the "Disable" and the "Disable Marker" bits need to be set high in order to disable the high-speed input. If the Marker is set for one of the inputs, then the input will need to be "High" in order to use any of the Disable, Clear, Preload, or Latch functions.

### 9.4.1: Status Bits

There are three status bits (%I registers for each high-speed counter):

- **Overflow Flag:** This status bit turns high when the Accumulator “overflows”, it moves from 4,294,967,295 (-1 if Signed) to 0, this bit can be reset with the “Output Reset Bit”. See Table 9.4.
- **Underflow Flag:** This status bit turns high when the Accumulator “underflows”, it moves from 0 to 4,294,967,295 (-1 if Signed), this bit can also be reset with the “Output Reset Bit”.

**NOTE:** For the Overflow and Underflow flag registers, if using some sort of counter that counts both up and down, going over the threshold to go negative, triggers the underflow, and then going back over the threshold back into positive numbers will trigger the positive register to go active.

- **High Speed Out:** This register will follow the high-speed output assigned to the counter, it is important to note that this register is still populated within the scan time so the value in this register may not be up to date depending on the timing of the output (it should be up to date within one scan).

## Chapter 9: XL Series Only

### 9.5: HSC Functions Register Maps

The register assignments for the high-speed I/O can be reassigned via a setting in Cscape. The values shown are the DEFAULT values and may not match the same starting point as the values shown below.

#### 9.5.1: I/O Mapping 2-Counter Mode (XL Series Only)

HSC Functions Register Map for 2 HSC Configuration				
Register	Frequency	Pulse	Totalize	Quad
%AI401-402	Accumulator - Counter 1			
%AI403-404	Latch Value – Counter 1			
%AI405-406	Accumulator – Counter 2			
%AI407-408	Latch Value – Counter 2			
%AQ401-402			Preload – Counter 1	
%AQ403-404		Match1 – Counter 1		
%AQ405-406		Match2 – Counter 1		
%AQ407-408			Preload – Counter 2	
%AQ409-410		Match1 – Counter 2		
%AQ411-412		Match2 – Counter 2		
%AQ413-424	Reserved			
%Q1601	Latch – Counter 1			
%Q1602			Preload – Counter 1	
%Q1603			Clear – Counter 1	
%Q1604	Disable – Counter 1			
%Q1605			Direction – C 1	
%Q1606			Output Reset – Counter 1	
%Q1607			Preload Disable – Counter 1	
%Q1608			Latch Disable – Counter 1	
%Q1609				Disable Marker – C1
%Q1610				Latch Marker – C1
%Q1611				Preload Marker – C1
%Q1612				Clear Marker – C1
%Q1613-1616	Reserved			
%Q1617	Latch – Counter 2			
%Q1618			Preload – Counter 1	
%Q1619			Clear – Counter 1	
%Q1620	Disable – Counter 2			
%Q1621			Direction – C 2	

HSC Functions Register Map for 2 HSC Configuration				
Register	Frequency	Pulse	Totalize	Quad
%Q1622			Output Reset – Counter 2	
%Q1623			Preload Disable – Counter 2	
%Q1624			Latch Disable – Counter 2	
%Q1625				Disable Marker – C2
%Q1626				Latch Marker – C2
%Q1627				Preload Marker – C2
%Q1628				Clear Marker – C2
%I1601	Overflow Flag – Counter 1			
%I1602	Underflow Flag – Counter 1			
%I1603	High Speed Out 1			
%I1604	Reserved			
%I1605	Overflow Flag – Counter 2			
%I1606	Underflow Flag – Counter 2			
%I1607	High Speed Out 2			
%I1608	Reserved			

### 9.5.2: I/O Mapping 4-Counter Mode (XL Series Only)

HSC Functions Register Map for 4 HSC Configuration			
Register	Frequency	Pulse	Totalize
%AI401-402	Accumulator - Counter 1		
%AI403-404	Latch Value - Counter 1		
%AI405-406	Accumulator - Counter 2		
%AI407-408	Latch Value - Counter 2		
%AI409-410	Accumulator - Counter 3		
%AI411-412	Latch Value - Counter 3		
%AI413-414	Accumulator - Counter 4		
%AI415-416	Latch Value - Counter 4		
Register	Frequency	Pulse	Totalize
%AQ401-402			Preload - Counter 1
%AQ403-404	Match 1 - Counter 1		
%AQ405-406	Match 2 - Counter 1		
%AQ407-408			Preload - Counter 2
%AQ409-410	Match 1 - Counter 2		
%AQ411-412	Match 2 - Counter 2		
%AQ413-414			Preload - Counter 3
%AQ415-416	Match 1 - Counter 3		
%AQ417-418	Match 2 - Counter 3		
%AQ419-420			Preload - Counter 4
%AQ421-422	Match 1 - Counter 4		
%AQ423-424	Match 2 - Counter 4		
Register	Frequency	Pulse	Totalize
%Q1601	Latch - Counter 1		
%Q1602			Preload - Counter 1
%Q1603			Clear - Counter 1
%Q1604	Disable - Counter 1		
%Q1605			Direction - C1
%Q1606			Output Reset - Counter 1
%Q1607			Preload Disable - Counter 1
%Q1608			Latch Disable - Counter 1
%Q1609-1616	Reserved		
%Q1617	Latch - Counter 2		
%Q1618			Preload - Counter 2

Register	Frequency	Pulse	Totalize
%Q1619			Clear - Counter 2
%Q1620	Disable - Counter 2		
%Q1621			Direction - C2
%Q1622			Output Reset - Counter 2
%Q1623			Preload Disable - Counter 2
%Q1624			Latch Disable - Counter 2
%Q1625-1632	Reserved		
%Q1633	Latch - Counter 3		
%Q1634			Preload - Counter 3
%Q1635			Clear - Counter 3
%Q1636	Disable - Counter 3		
%Q1637			Direction - C3
%Q1638			Output Reset - Counter 3
%Q1639			Preload Disable - Counter 3
%Q1640			Latch Disable - Counter 3
%Q1641-1648	Reserved		
%Q1649	Latch - Counter 4		
%Q1650			Preload - Counter 4
%Q1651			Clear - Counter 4
%Q1652	Disable - Counter 4		
%Q1653			Direction - C4
%Q1654			Output Reset - Counter 4
%Q1655			Preload Disable - Counter 4
%Q1656			Latch Disable - Counter 4
%Q1657-1664	Reserved		
%I1601	Overflow Flag - Counter 1		
%I1602	Underflow Flag - Counter 1		
%I1603	High Speed Out 1		
%I1604	Reserved		
%I1605	Overflow Flag - Counter 2		
%I1606	Underflow Flag - Counter 2		
%I1607	High Speed Out 2		
%I1608	Reserved		
%I1609	Overflow Flag - Counter 3		
%I1610	Underflow Flag - Counter 3		
%I1611	High Speed Out 3		
%I1612	Reserved		

Register	Frequency	Pulse	Totalize
%I1613	Overflow Flag - Counter 4		
%I1614	Underflow Flag - Counter 4		
%I1615	High Speed Out 4		
%I1616	Reserved		

### 9.5.3: I/O Mapping 4-Counter Mode (XL Prime Series only)

Default Analog Output Registers for HSC	
Register	Function
%AQ401 – 402	Preload Value (Counter1)
%AQ403 – 404	Match1 Value (Counter1)
%AQ405 – 406	Match2 Value (Counter1)
%AQ407 – 408	Preload Value (Counter2)
%AQ409 – 410	Match1 Value (Counter2)
%AQ411 – 412	Match2 Value (Counter2)
%AQ413 – 414	Preload Value (Counter3)
%AQ415 – 416	Reserved
%AQ417 – 418	Reserved
%AQ419 – 420	Preload Value (Counter4)

Default Analog Input Registers for HSC	
Register	Function
%AI401 – 402	Accumulator/Count Value (Counter1)
%AI403 – 404	Latch Value (Counter1)
%AI405 – 406	Accumulator/Count Value (Counter2)
%AI407 – 408	Latch Value (Counter2)
%AI409 – 410	Accumulator/Count Value (Counter3)
%AI411 – 412	Latch Value (Counter3)
%AI413 – 414	Accumulator/Count Value (Counter4)
%AI415 – 416	Latch Value (Counter4)

Default Output Registers for HSC	
Register	Function
%Q1601	Latch Trigger (Counter1)
%Q1602	Preload Trigger (Counter1)
%Q1603	Clear Trigger (Counter1)
%Q1604	Disable Counter (Counter1)
%Q1605	Direction (Counter1)
%Q1606	Underflow/Overflow/HSCQ Reset (Counter1) ( High – Reset)
%Q1607	Preload Disable (Counter1) (High – Disable)
%Q1608	Latch Disable (Counter1)(High – Disable)
%Q1609	Reserved
%Q1610	Reserved
%Q1611	Reserved
%Q1612	Reserved
%Q1613	Reserved
%Q1614	Reserved
%Q1615	Reserved
%Q1616	Reserved
%Q1617	Latch Trigger (Counter2)
%Q1618	Preload Trigger (Counter2)
%Q1619	Clear Trigger (Counter2)
%Q1620	Disable Counter (Counter2)
%Q1621	Direction (Counter2)
%Q1622	Underflow/Overflow/HSCQ Reset (Counter2) ( High – Reset)
%Q1623	Preload Disable(Counter2) (High – Disable)
%Q1624	Latch Disable (Counter2)(High – Disable)
%Q1625	Reserved
%Q1626	Reserved
%Q1627	Reserved
%Q1628	Reserved

Default Output Registers for HSC	
Register	Function
%Q1629	Reserved
%Q1630	Reserved
%Q1631	Reserved
%Q1632	Reserved
%Q1633	Latch Trigger (Counter3)
%Q1634	Preload Trigger (Counter3)
%Q1635	Clear Trigger (Counter3)
%Q1636	Disable Counter (Counter3)
%Q1637	Direction (Counter3)
%Q1638	Underflow/Overflow/HSCQ Reset (Counter3) ( High – Reset)
%Q1639	Preload Disable(Counter3) (High – Disable)
%Q1640	Latch Disable (Counter3)(High – Disable)
%Q1641	Reserved
%Q1642	Reserved
%Q1643	Reserved
%Q1644	Reserved
%Q1645	Reserved
%Q1646	Reserved
%Q1647	Reserved
%Q1648	Reserved
%Q1649	Latch Trigger (Counter4)
%Q1650	Preload Trigger (Counter4)
%Q1651	Clear Trigger (Counter4)
%Q1652	Disable Counter (Counter4)
%Q1653	Direction (Counter4)
%Q1654	Underflow/Overflow/HSCQ Reset (Counter4) ( High – Reset)
%Q1655	Preload Disable(Counter4) (High – Disable)
%Q1656	Latch Disable (Counter4) (High – Disable)
%Q1657	Reserved
%Q1658	Reserved
%Q1659	Reserved
%Q1660	Reserved
%Q1661	Reserved
%Q1662	Reserved
%Q1663	Reserved
%Q1664	Reserved

Default Input Registers for HSC	
Register	Function
%I1601	Overflow Flag (Counter1)
%I1602	Underflow Flag (Counter1)
%I1603	HSCQ (Counter1)
%I1604	Reserved (Counter1)
%I1605	Overflow Flag (Counter2)
%I1606	Underflow Flag (Counter2)
%I1607	HSCQ (Counter2)
%I1608	Reserved (Counter2)
%I1609	Overflow Flag (Counter3)
%I1610	Underflow Flag (Counter3)
%I1611	HSCQ (Counter3)
%I1612	Reserved (Counter3)
%I1613	Overflow Flag (Counter4)
%I1614	Underflow Flag (Counter4)
%I1615	HSCQ (Counter4)
%I1616	Reserved (Counter4)

## 9.6: High Speed Output Functions

On units that support high-speed output functions, two dedicated outputs are available that can be configured for one of four modes of operation. Those modes are Normal, PWM, HSC Match and Stepper.

### 9.6.1: Normal


When either Q1 or Q2 is configured for Normal operation, the digital output registers %Q1 and %Q2 drives that respective output.

### 9.6.2: PWM


When either Q1 or Q2 is configured for PWM, the PWM function drives that respective output. Both PWM channels may be individually enabled and can have independent frequency and duty cycles.

The PWMs require two parameters (%AQs) to be set for operation. These parameters may be set at run-time.

**Duty Cycle** – The Duty Cycle is a 32-bit value from 0 to 32,000 indicating the relative duty cycle of the output. For example, a value of 8000 would indicate a 25% duty cycle, a value of 16,000 would indicate a 50% duty cycle. Zero (0) turns the output off, 32,000 turns the output on.




**Frequency** – The Frequency is a 32-bit value indicating the output frequency in Hertz. One over the frequency is the period.



At controller power-up or during a download, the PWM output is maintained at zero until both the Frequency and the Duty cycle are loaded with non-zero values. When the controller is placed in stop mode, the state of the PWM outputs is dependent on the PWM State on Controller Stop configuration. This configuration allows for either hold-last-state or specific frequency and duty cycle counts. Specifying zero for either the period or duty causes the PWM output to remain low during stop mode.

### 9.6.3: PWM Output Waveform



PWM Output Waveform Table	
Rise Time	150ns Max
Fall Time	150ns Max
PWM Period	Frequency = 1/Period

### 9.6.4: High Speed Counter Match

When either Q1 or Q2 is configured for HSC Output operation, their output state is based on a comparison between the counter accumulator and match registers. Refer to the "HSC Functions Register Maps" on page 98 for more details.

### 9.6.5: Stepper Function

The OCS supports two stepper functions, one on each high-speed output when in two counter mode. In four counter mode, the OCS supports one stepper function

The Stepper requires five parameters (%AQs) to be set for operation. These parameters may be set at run-time but are 'latched' when the stepper is commanded to start:

<b>Start Frequency (pulses per second)</b>	Sets the frequency for the first cycle during the acceleration phase and the frequency of the last cycle during the deceleration phase. When an acceleration or deceleration count is specified, the Start Frequency must be greater than 0 and must not exceed the run frequency or an error is generated.
<b>Run Frequency (pulses per second)</b>	Sets the frequency for the last cycle during the acceleration phase, the consistent frequency during the run phase, and the frequency of the first cycle during the deceleration mode. The Run Frequency must be greater than 0 and must not exceed 5000Hz (standard).
<b>Acceleration Count</b>	Sets the number of cycles to occur within the acceleration phase. The frequency of the cycles within this mode will vary linearly between the specified Start and Run frequency. The Accel count must not equal 1 or an error is generated. Setting this value to zero disables this phase.
<b>Run Count</b>	Sets the number of cycles to occur within the run phase. The frequency of the cycles within this mode is constant at the specified Run frequency. The Run count may be any value. Setting this value to zero disables this phase.
<b>Deceleration Count</b>	Sets the number of cycles to occur within the deceleration phase. The frequency of the cycles within this phase will vary linearly between the specified Run and Stop frequency. The Decel count must not equal 1 or an error is generated. Setting this value to zero disables this phase.

The stepper provides two Boolean registers to provide stepper status:

<b>Ready/Done</b>	A high indication on this register indicates the stepper sequence can be started (i.e. not currently busy) and also when the move is completed.
<b>Error</b>	A high indication on this register indicates that one of the analog parameters specified above is invalid or the stepper action was aborted before the operation was complete. This register is cleared on the next start command if the error was corrected.

The stepper requires one discrete register to control the stepper action. Setting this register starts the stepper cycle. This register must remain set to complete the entire cycle. Clearing this register before the cycle is complete aborts the step sequence and sets the error bit.

**NOTE:** Setting the PLC mode to stop while the stepper is in operation causes the stepper output to immediately drop to zero and the current stepper count to be lost.

**NOTE:** The stepper output level may cause damage or be incompatible with some motor drive inputs. Consult drive documentation to determine if output level and type is compatible.

## 9.7: High Speed Output Functions Register Map

The register assignments for the high speed I/O can be moved via a setting in Cscope. The values shown are the DEFAULT values and may not match the same starting point as the values shown below.

### 9.7.1: I/O Mapping 2–Counter Mode

Default Analog Output Registers for PWM & Stepper		
Register	PWM	Stepper
%AQ421 – 422	Duty Cycle (PWM1)	Start Frequency (Stepper1)
%AQ423 – 424	Frequency (PWM1)	Run Frequency (Stepper1)
%AQ425 – 426		Acceleration Count (Stepper1)
%AQ427 – 428		Run Count (Stepper1)
%AQ429 – 430		Deceleration Count (Stepper1)
%AQ431 – 432	Duty Cycle (PWM2)	Start Frequency (Stepper2)
%AQ433 – 434	Frequency (PWM2)	Run Frequency (Stepper2)
%AQ435 – 436		Acceleration Count (Stepper2)
%AQ437 – 438		Run Count (Stepper2)
%AQ439 – 440		Deceleration Count (Stepper2)

Default Input Registers for PWM & Stepper		
Register	PWM	Stepper
%I1617		Ready/Done (Stepper1)
%I1618		Error (Stepper1)
%I1619		Ready/Done (Stepper2)
%I1620		Error (Stepper2)

Default Output Registers for PWM & Stepper		
Register	PWM	Stepper
%Q1	PWM Output 1	Stepper 1 Output
%Q2	PWM Output 2	Stepper 2 Output

## 9.7.2: I/O Mapping 4-Counter Mode

Default Analog Output Registers for PWM & Stepper		
Register	PWM	Stepper
%AQ451 – 452		Start Frequency (Stepper1)
%AQ453 – 454	PWM1 Frequency	Run Frequency (Stepper1)
%AQ455 – 456		Acceleration Count (Stepper1)
%AQ457 – 458		Run Count (Stepper1)
%AQ459 – 460		Deceleration Count (Stepper1)
%AQ461 – 462	PWM2 Duty Cycle (32-bit)	
%AQ463 – 464	PWM2 Frequency	
%AQ465 – 469	Reserved	
%Q1*	PWM1 Out	Stepper On
%Q2*	PWM2 Out	
%		Stepper Ready / Done
%		Stepper Error

\*Q30 and Q31 for model 2 using HSQ or HSQ-5 add-module (necessary to start move)

Default Input Registers for PWM & Stepper		
Register	PWM	Stepper
%I1617		Ready/Done (Stepper1)
%I1618		Error (Stepper1)

Default Output Registers for PWM & Stepper		
Register	PWM	Stepper
%Q1	PWM Output 1	Stepper 1 Output
%Q2	PWM Output 2	Stepper 2 Output

### 9.7.3: PWM Examples

#### Example 1

	Duty Cycle	Frequency
To get a 50% Duty Cycle @ 10kHz waveform on PWM1:	Set %AQ421–422 = 16,000	Set %AQ423–424 = 10,000

#### Example 2

	Duty Cycle	Frequency
To get a 50% Duty Cycle on PW1 and 90% Duty Cycle on PWM2 @ 1kHz waveform:	Set %AQ421–422 = 16,000 Set %AQ431–432 = 28,800 (duty cycle (32000 * 0.9))	Set %AQ423–424 = 1,000 Set %AQ433–434 = 1,000

#### Example 3

	Duty Cycle	Frequency
To turn PWM 1 output ON all the time	Set %AQ421–422 = 32,000	Set %AQ423–424 = Any Value

#### Example 4

	Duty Cycle	Frequency
To turn PWM 1 output OFF all the time	Set %AQ421–422 = 0	Set %AQ423–424 = Any Value

## 9.7.4: STP Examples

### Example 1

	Start Frequency	Run Frequency	Accel Count	Run Count	Decel Count
10,000,000 steps control sequence	Set %AQ421-22 = 2500 (Hz)	Set %AQ423-24 = 5000 (Hz)	Set %AQ425-26 = 1,000,000 (Steps)	Set %AQ427-28 = 8,000,000 (Steps)	Set %AQ429-30 = 1,000,000 (Steps)
When the start bit is energized, the example starts at 2.5kHz and ramps up to 5kHz during the first 1,000,000 steps. Then, it runs at 5kHz for the next 8,000,000 steps. Finally, during the last 1,000,000 steps it slows to a stop.					

### Example 2

	Start Frequency	Run Frequency	Accel Count	Run Count	Decel Count
5,000,000 steps control sequence	Set %AQ421-22 = 500 (Hz)	Set %AQ423-24 = 1000 (Hz)	Set %AQ425-26 = 2,000,000 (Steps)	Set %AQ427-28 = 2,000,000 (Steps)	Set %AQ429-30 = 1,000,000 (Steps)
When the start bit is energized, the example starts at 0.5 kHz and ramps up to 1 kHz during the first 2,000,000 steps. Then, it runs at 1 kHz for the next 2,000,000 steps. Finally, during the last 1,000,000 steps it slows to a stop.					

### Example 3

	Start Frequency	Run Frequency	Accel Count	Run Count	Decel Count
6,000,000 steps control sequence	Set %AQ421-22 = 50 (Hz)	Set %AQ423-24 = 250 (Hz)	Set %AQ425-26 = 150,00 (Steps)	Set %AQ427-28 = 5,500,000 (Steps)	Set %AQ429-30 = 350,000 (Steps)
When the start bit is energized, the following example starts at 50Hz and ramps up to 250Hz during the first 150,000 steps. Then, it runs at 250Hz for the next 5,500,000 steps. During the last 350,000 steps it slows to a stop.					


**NOTE:** Prior to the start of a move, the Ready/Done bit for that channel must be ON %I1617 or %I1619 for channel 1 and 2 respectfully). The Ready/Done bit will turn OFF during the move, and then back ON once the move is completed.

**NOTE:** The pulse generation hardware on the OCS can generate any frequency that can be evenly divided into 10MHz (10,000,000Hz) under the maximum recommended frequencies for each model. This results in a very smooth operation at lower frequencies, with a progressively choppy operation at higher frequencies, as the units reach their maximum recommended frequency.

## 9.8: HSC I/O Filtering

This feature is used to enable digital Filter for HSC Inputs.

Selecting Digital In/HSC configuration opens up the following dialog where in HSC I/O Filtering is available.



The dialog box is titled "Digital / HSC Input Configuration". It contains several sections:

- Digital inputs active mode:**
  - ☒ Positive Logic
  - ☐ Negative Logic

Note: This setting must match that of the jumpers on the product
- Counter Modes:**
  - ☒ 2 Counter mode
  - ☐ 4 Counter mode
  - ☐ 8 Counter mode
  - ☐ Custom mode

Note: 2 Channel Supports:  
1) 2-HSC  
2) 2-Quadrature  
3) 2-Stepper Outputs
- HSC I/O Mapping:**
  - Starting Digital In: %I1601 Name: [dropdown] 1-BIT x 8
  - Starting Analog In: %AI401 Name: [dropdown] 16-BIT x 8
  - Starting Digital Out: %Q1601 Name: [dropdown] 1-BIT x 32
  - Starting Analog Out: %AQ401 Name: [dropdown] 16-BIT x 12
- HSC I/O Filtering (highlighted with a red box):**
  - Checkboxes: %I9, %I10, %I11, %I12
  - Filter Frequency: [slider from 1KHz to 10MHz] 5000 KHz
  - Number of Samples: [slider from 1 to 10] 3
- Counter1 | Counter2:**
  - Type: Quadrature
  - Mode: 1 lags 2 count Up
  - Input1: External Input #1
  - Input2: External Input #2
  - Disable Function: Disabled
  - Latch Function: Disabled
  - Preload Function: Disabled
  - Clear Function: Disabled
  - Marker: Disabled
  - Match: Disable

Buttons: OK, Cancel

Input signal is filtered based on the filter frequency and Number of samples selected. User has to select Filter Frequency and Number of samples based on the frequency of the Input signal.

**Filter Frequency:** To set the filter, choose a value that is:  $4 \times \text{Number of Samples} \times \text{Expected Max Hz on the high-speed inputs}$ .

**Number of samples:** The input must be stable for this many samples before the HSC accumulator is affected by any change.

The state (high or low) of the high-speed input is sampled with every rising input edge of the filter frequency. The rising edges of the filter frequency are totaled in a sample counter, and when that total equals the number of samples configured, the sample counter is reset. If the high-speed input state did not change by the time of the sample counter reset, that state, high or low, is passed on to the high-speed accumulator. If the high-speed input state changes during the sample counting, the sample counter is reset to zero and the process starts over.

Figure 1: Input Signal




Figure 2: Filter Frequency: Example 1MHz

Number of Samples: 4

HG-012

If user selects filter frequency as 1MHz and Number of samples as 4, then Input signal is sampled for 4 samples and if the signal is stable for 4 samples i.e. 4 $\mu$ s then the signal is passed to Accumulator.

If the Input state is changed in between the sampling counts, then the count is reset, and the Input state is again checked for given number of samples.

Refer to Dotted lines in the Figure 2, after 2 samples the state of input signal changes to 1, so the counter is again started to count 4 samples, to pass the signal to accumulator.

There will be a delay in passing the input signal to accumulator since we are filtering the Input signal and the delay is based on the selected filter frequency and Number of samples. In the above example filter frequency is 1MHZ (1 $\mu$ s) and number of samples: 4, so the minimum delay in input signal will be 4 $\mu$ s.

Figure 3: Input Signal Before Filtering




Figure 4: Input Signal After Filtering

This delay will be 4 $\mu$ s

HG-013

# Serial Communications



## Chapter 10: Serial Communications

---

Port Descriptions .....	117
Wiring .....	118
DIP Switches .....	119
RS-485 Termination .....	119
RS-485 Biasing .....	119
Cscape Programming via Serial Port .....	119
Ladder-Controlled Serial Communication .....	119
Configuration with USB Type C .....	120

All XL15 Prime OCS models provide two independent serial ports, on the first 8-pin modular jack, which is labeled **MJ1/MJ2**. The MJ1 serial port is RS-232 while the MJ2 port is RS-485. By default, MJ1 can be connected to the COM port of a PC running Cscape, for OCS programming. In addition, both MJ1 and MJ2 can be used for application-specific communication, using a variety of standard data exchange protocols.


The second 8-pin modular jack, which is labeled **MJ3**, provides a multiplexed serial port, which can be configured for either RS-232 or RS-485. MJ3 can be optionally set for OCS programming via the System Menu for connection to the COM port of a PC running Cscape.

### Port Descriptions

The MJ1 serial port contains an RS-232 interface with RTS/CTS handshaking. The MJ2 serial port contains a half-duplex RS-485 interface with no handshaking. The MJ3 serial port can be configured as either RS-232 or RS-485. The MJ2 and MJ3 RS-485 interfaces provide switchable termination and bias resistors internally, which can be enabled/disabled with DIP switches.

## Wiring

### MJ1/2 Serial Ports




HG-008

**MJ1:** RS-232 w/Full Handshaking

**MJ2:** RS-485 Half-Duplex

	MJ1 Pins		MJ2 Pins	
PIN	SIGNAL	DIRECTION	SIGNAL	DIRECTION
8	TXD	OUT	--	--
7	RXD	IN	--	--
6	0V	COMMON	0V	COMMON
5	+5V @ 60mA	OUT	+5V @ 60mA	OUT
4	RTS	OUT	--	--
3	CTS	IN	--	--
2	--	--	RX-/TX-	IN/OUT
1	--	--	RX+/TX+	IN/OUT

### MJ3 Serial Port



HG-008

2 Multiplexed Serial Ports on One Modular Jack (8 position)

	MJ3 PINS	
PIN	SIGNAL	DIRECTION
8	TXD RS-232	OUT
7	RXD RS-232	IN
6	0V	COMMON
5	+5V @ 60mA	OUT
4	TX- RS-485	OUT
3	TX+ RS-485	OUT
2	RX- RS-485	IN
1	RX+ RS-485	IN

**NOTE:** Attach optional [ferrite core](#) with a minimum of two turns of serial cable.

## DIP Switches

The DIP switches are used to provide a built-in termination to both the MJ1, MJ2 & MJ3 ports if needed. The termination for these ports should only be used if this device is located at either end of the multidrop/daisy-chained RS-485 network.

DIP Switches			
SWITCH	NAME	FUNCTION	DEFAULT
1	MJ3 RS-485 Termination	ON = Terminated	OFF
2	MJ3 Duplex	Both ON = Half	OFF
3		Both OFF = Full	OFF
4	MJ2 RS-485 Termination	ON = Terminated	OFF

## RS-485 Termination

Proper RS-485 termination minimizes signal reflections and improves reliability. Both the MJ1 and MJ2/3 serial ports allow an internal termination resistor to be placed between data lines via DIP Switch Settings.

Only the two devices physically located at the endpoints of the RS-485 network should be terminated.

## RS-485 Biasing

RS-485 biasing passively asserts a line-idle state when no device is actively transmitting, which is useful for multi-drop RS-485 networking.

Both the MJ2 and MJ3 serial ports allow internal bias resistors to be switched in, pulling pin 1 up to 3.3V and pulling pin 2 down to ground. The Set Serial Ports item in the System Menu can be used to enable RS-485 biasing. Also, an application graphics screen that writes to %SR164 can do the same thing. Setting %SR164.1 enables MJ2 biasing and setting %SR164.2 enables MJ3 biasing.

If biasing is used, it should be enabled in only one of the devices attached to the RS-485 network.

## Cscape Programming via Serial Port

The XL15 Prime OCS MJ1 and MJ3 serial ports support CsCAN Programming Protocol. If a PC COM port is connected to the XL15 Prime OCS MJ1 or MJ3 serial port, Cscape can access the XL15 Prime OCS for programming and monitoring. Programming can also be done via the CAN port, USB A port, or Ethernet.

## Ladder-Controlled Serial Communication

Using Serial Communication function blocks, MJ1, MJ2 and MJ3 serial ports support Generic Modbus Master and Modbus Slave Protocols. In addition, external modems can be connected and accessed using Init and Dial and Answer Modem function blocks.

## Configuration with USB Type C

- The unit must be connected to the PC or laptop using the USB Type C port
- It is recommended to use an isolated USB cable between the PC or laptop and the unit
- It is possible to perform downloads and uploads, and to use the data monitoring functions, after connection is confirmed

Load the program and monitor data using the USB Type C. To load with USB Type C, configure the communications port in Cscape as follows:

1. From the toolbar, select **Tools> Application Settings > Communications > USB button**.

# CAN Communications



## Chapter 11: CAN Communications

11.1: Port Description .....	122
11.2: CAN Port Wiring .....	122
11.3: Cscape Programming via CAN .....	123
11.4: Ladder-Controlled CAN Communication .....	123
11.5: Using CAN for I/O Expansion (Network I/O) .....	123
11.6: OCSIO-I/O Expansion Port .....	123

**NOTE:** For additional CAN information, refer to the CAN Networks manual, MAN0799 ([MAN0799](#)) using Horner's [Documentation Search](#) page.

OCS models provide a CAN network port, which is implemented with 5-pin connectors. The CAN port allows the OCS to exchange global data with other OCS controllers and to access remote Network I/O devices (SmartStix, Smart Blocks and Smart Rail Modules). The port also supports pass-through communications for programming multiple OCS controllers over the CsCAN network. Also, the CAN port supports CsCAN, CANopen, J1939, and DeviceNet Master (layer 3 as a selectable option).


### 11.1: Port Description

The OCS CAN ports implement the ISO 11898-2 physical layer and the CAN 2.0A data link layer standards. Also, since the CAN ports are powered by an internal isolated power supply, external CAN power is not required.

**NOTE:** The CAN port does not supply power to the network.

### 11.2: CAN Port Wiring

Use the CAN Connector when using CsCAN or other CAN network. Torque rating: 4.5 - 7 in•lbs (0.50 - 0.78 N•m)



HG-001

CAN Network & Power Port Pin Assignment		
Pin	Signal	Signal Description
1	V-	CAN and Device Ground - Black
2	CN_L	CAN Data Low - Blue
3	SHLD	Shield Ground - None
4	CN_H	CAN Data High - White
5	V+	Only used for Remote I/O. Not required for local device power.

### 11.3: Cscape Programming via CAN

The CAN port supports CsCAN Programming Protocol. If a PC has a CAN interface installed (via PCI card or USB), and the PC CAN port is connected to the OCS CAN port, Cscape can access the OCS for programming and monitoring.

In addition, the OCS supports single-point-programming of all OCS devices that are connected to the CAN port network. If the PC COM port is connected to the OCS MJ1 serial port, the OCS can act as a pass-through gateway allowing Cscape to access all OCS devices that are attached to the CAN port network.

### 11.4: Ladder-Controlled CAN Communication

Using Put and Get Network Words function blocks, the CAN1 port can exchange digital and analog global data with other devices (nodes) attached to the CAN network.


In addition, Put and Get Network Heartbeat function blocks allow nodes on the CAN network to regularly announce their presence and to detect the presence (or absence) of other nodes on the network.

### 11.5: Using CAN for I/O Expansion (Network I/O)

Connecting network I/O devices (SmartStix, SmartBlock, SmartMod, or SmartRail) to the OCS CAN1 port allows the OCS-I/O to be economically expanded and distributed. A variety of modules are available for this purpose.

### 11.6: OCSIO-I/O Expansion Port

This port is reserved for future functionality, but is not operational at this time.



# Ethernet Communication



## Chapter 12: Ethernet Communications

<b>Ethernet Module Protocols and Features</b> .....	<b>125</b>
<b>Ethernet Module Specifications</b> .....	<b>125</b>
<b>Ethernet Module Configuration</b> .....	<b>126</b>
<b>Ethernet Configuration – IP Parameters</b> .....	<b>129</b>
<b>Ethernet Module Protocol Configuration</b> .....	<b>129</b>

### Ethernet Module Protocols and Features

The XL15 Prime controller supports the following:

1. Downloadable Protocols: **Modbus Client**
2. ETN300 Protocols: **ICMP (Ping), EGD, Modbus Slave, EtherNet/IP I/O Adapter (UDP), FTP, ASCII over TCP/IP**
3. Supports a maximum of 4 WebMI simultaneous connections
4. Ethernet SmartRail

The following table describes the Ethernet Module Protocols and features supported by the Ethernet port on the XL15 Prime .

Protocol / Feature	Protocol / Feature Description
ICMP (Ping)	Internet Control Message Protocol
EGD	Ethernet Global Data
SRTP Slave (90-30 Service Request)	Service Request Transfer Protocol
CsCAN TCP Server	Horner APG CsCAN over Ethernet (for Cscape to OCS programming)
Modbus Slave	Modbus over Ethernet
Ethernet / IP	ODVA CIP over Ethernet
FTP (File Server)	File Transfer Protocol
HTTP (Web Server)	HyperText Transfer Protocol (Web Server)
ASCII over TCP/IP	ASCII Data over Ethernet
NTP Protocol	Network Time Protocol (Obtain clock from web-based server)

### Ethernet Module Specifications


Speeds	10/100 Base-T Ethernet (10Mbps) 100 BaseTx Fast Ethernet (100Mbps)
Modes	Half or Full Duplex
Auto-Negotiation	Both 10/100Mbps and Half/Full Duplex
Connector Type	Shielded RJ-45
Recommended Cable Type	CAT5 (or better) UTP

## Ethernet Module Configuration

**NOTE:** The following configuration is required for all applications regardless of the protocols used. Additional configuration procedures must be performed for each protocol used.

To configure the Ethernet Module, use Cscape Programming Software to perform the following steps:

1. On the main Cscape screen, select the **Controller** menu and its **Hardware Configuration** sub-menu to open the Hardware Configuration dialog.
2. If configuring a different OCS Model than the one shown in the **Hardware Configuration** dialog, click on the topmost Config button, select the desired OCS Model, and then click **OK**.



3. Click the **Config** button to the right of the LAN1 for LAN 1 or LAN2 for LAN 2, revealing the Ethernet Module Configuration dialog.
4. Configure the Ethernet Module parameters as follows:

**IP Address:** Enter the static IP Address for the Ethernet Module being configured.

**NOTE:** IP Addresses are entered as four numbers, each ranging from 0 to 255. These four numbers are called octets, and they are always separated by decimal points.

**Net Mask:** Enter the Net Mask (sometimes called Subnet Mask) being used by all nodes on the local network. Typical local networks use Class C IP Addresses, in which case the low octet (rightmost number) is used to uniquely identify each node on the local network. In this case, the default Net Mask value of 255.255.255.0 should be used.

**Gateway:** Enter the IP Address of a Gateway Server on the local network that allows for communication outside of the local network. To prevent the Ethernet Module from communicating outside the local network, set the Default Gateway IP Address to 0.0.0.0 (the default setting).

**Status Register:** Enter an OCS Register reference (such as %R100) to indicate which 16-bit OCS register will have the Ethernet Status word written to it. The table shows how this register value is formatted and explains the meaning of each bit in the Status Word.

Ethernet Status Word Register Format																	
High Byte								Low Byte									
Bit 16	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1		
0	0	Dup	Spd	0	Rx	Tx	Link	TCP Connections									
Status Bit				Status Indication								Status Values					
												Minimum		Maximum			
0				Reserved								Always 0					
Dup				Link Duplex (Auto-Negotiated)								0 = Half Duplex		1 = Full Duplex			
Spd				Link Speed (Auto-Negotiated)								0 = 10 Mbps		1 = 100 Mbps			
Rx				Receive State								0 = Inactive		1 = Active			
Tx				Transmit State								0 = Inactive		1 = Active			
Link				Link State								0 = Down		1 = Up			
TCP Connections				Total Number of Active TCP Connections (CsCAN, SRTP, Modbus, Ethernet IP, FTP, HTTP)								0		40			

**Version Register:** Enter an OCS Register reference (such as %R101) to indicate which 16-bit OCS register will have the Ethernet Firmware Version written to it. The value stored in the Version Register is (Ethernet Firmware Version \* 100). For example, for Ethernet Firmware Version 4.30, the Version register will contain 430.

**Get Setting From:** “Get settings from” allows the programmer to either configure the IP Address, Net Mask, or Gateway for two functions: Configuration or Register.

**Configuration:** The configuration for the IP Address, Net Mask, or the Gateway will be assigned using the value in the Default Settings in this window.

**Register:** The configuration for the IP Address, Net Mask, or the Gateway will be assigned using the values in the registers assigned.

**NOTE:** The low octet of the IP Address can be replaced with the unit’s CAN Network ID, by checking the **Use CAN ID for last Octet** checkbox.

## Ethernet Configuration – IP Parameters

For primary operation, the IP address, Net Mask, and Gateway should be set in the LAN config of the **Cscape Hardware Configuration**. There are options to get IP parameters from the LAN Config or to get parameters from registers. It is possible to set the Ethernet IP parameters from the OCS System Menu, but only as a temporary measure. The following points on IP parameter configuration should be considered.

**IP Parameters in Non-Volatile RAM:** The IP parameters of the Cscape LAN Config are written to non-volatile RAM on power down. IP parameter settings made in the System Menu are not written to non-volatile RAM. Any IP parameters settings made in the System Menu will be lost after cycling power to the unit. It will revert to the last downloaded Cscape LAN Config that was loaded into non-volatile RAM at power down.

**“Cscape LAN Config” / “Get Settings from” Configuration:** When ‘Get settings from’ is set to Configuration, the IP parameters specified under ‘Default Settings’ is used after downloading to the controller. The IP parameters are represented in System Menu / Set Networks and can be edited. However, any edits made from System Menu / Set Networks is not retained through a power cycle. After power cycle, the unit reverts to the last downloaded Cscape LAN Config that was loaded into non-volatile RAM at power down.

**“Cscape LAN Config” / “Get Settings from” Register:** When ‘Get settings from’ is set to Register, the IP parameters are retrieved from the OCS registers assigned in LAN Config. Configured registers must be populated with the desired IP parameters:

- The IP parameters are represented in System Menu / Set Networks.
- The IP parameters cannot be edited from System Menu / Set Networks while the unit is in run mode.
- The IP parameters always follow the values in the registers unless the OCS unit is placed in idle mode. Then the IP parameters can be edited in System Menu / Set Networks. When the OCS is placed back into run mode, it reverts to the registers for IP parameters.

## Ethernet Module Protocol Configuration

The Protocol Support area contains a list of all the protocols supported by the platform being configured. To activate a protocol, check its checkbox.

For protocols that require additional configuration, click on a listed protocol to select it and then click the Configure Selected Protocol button. This will open a new dialog with configuration options for the selected protocol.

For detailed information on individual protocol configuration, refer to latest version of the [Ethernet Manual](#), SUP0740.

# Downloadable Protocols



## Chapter 13: Protocol Configuration

13.1: Overview .....	131
13.2: Protocol Device Driver Selection .....	131
13.3: Network Configuration .....	133
13.4: Device List and Device Configuration .....	134
13.5: Scan List .....	136

### 13.1: Overview

Through loadable protocol device drivers, certain models of the OCS family can provide the ability to exchange data with remote devices such as variable-frequency drives, PLCs and remote I/O devices. This feature greatly expands the OCS's control capability with negligible effect on the OCS's ladder scan time.

Remote devices that communicate serially must do so under certain rules of data transfer known as a protocol. Many device manufactures have created their own protocol for communications with their device. For a OCS to communicate with a specific device, it must be loaded with the corresponding serial communications protocol device driver that supports that protocol.

A limited number of protocol device drivers are packaged with the Cscape distribution; however, as more are developed, they will be made available as add-on packages. A device driver is typically distributed as a Windows module, which contains the configuration menus, help files and the target executable driver code. When updating device drivers, an install routine loads the device driver to the Cscape directory structure and makes that driver available to Cscape applications.

Once installed, the protocol device driver can be included as part of a Cscape application by selecting it from a list of installed protocol device drivers and attaching it to the desired serial port (**Home > Protocols**). Only one protocol device driver can be associated with a serial port, though some OCS models support multiple protocols on a single Ethernet port.

Once the protocol is selected for a specific port, that port must be configured to match the bit transfer size and rate of the target device(s). This is configured under the **Network Config** menu, which contains port specific information such as the basic serial port parameters (i.e. baud rate, stop bits parity, retries, etc.). In addition to the serial port parameters, this menu also contains the transaction scan update control configuration and any network level protocol specific configuration.

Once the network is configured, each device on the serial communications network must be configured. For some communications (i.e. RS-232), the network can be limited to one device. The devices are configured under the **Device Config** menu, which contains an arbitrary device name, the device ID and optionally a OCS status register that contains any device fault information.

Once each device(s) is configured, a Scan List of entries must be created which defines the transfer of data between a local (OCS ) register(s) and a remote device register(s). These entries are created under the Data Mapping menu, which contains a OCS register, a target device ID, a target device register address, the number of registers to transfer, and update type.

Each entry can be configured for one of two types of initiating a transaction: **Polled and Triggered**. Polled type entries initiate a transaction with the remote device on every transaction scan. Triggered type entries only initiate a transaction when a corresponding local (OCS ) binary trigger register is set. Once a triggered type transaction completes, the protocol device driver resets the local (OCS ) binary register to indicate completion.

These basic types are also subdivided into read or write operations. For polled operations, a Read operation only reads from a remote device. Likewise a Read/Write operation continuously reads from the remote device unless the target OCS register value changes from one ladder scan to another. In this case, the new OCS value is written to the target device. For triggered operations, only a read or write action is available.


When downloaded to the OCS , the Scan List is scanned sequentially to generate data transactions with the remote device. This transaction scanning can be on a continual basis (**automatic**) or controlled from ladder logic (manual) once a complex connection is created via a program. The specific transaction-scanning mode is selected from the **Network Config** menu.

Please refer to the Cscape Help file for more information on Downloadable Protocols Configuration.

### 13.2: Protocol Device Driver Selection

From the Cscape **Home > Protocols** menu, select the port drop-down box to select a protocol device driver. All protocol device drivers currently loaded in Cscape are displayed in the drop down selection along with their version numbers. A selected protocol can be removed by selecting **None** from the drop-down selection. Some OCS models can be limited in the number of ports or number of protocol device drivers that can be selected. Once a protocol is selected, the Network, Devices and Data

(Scan List) must be configured through corresponding dialogues accessible through the respective buttons (Network, Devices and Scan List).




**NOTE:** If the MJ1 port is to be used in the Protocol Config, it will no longer be available for Cscape programming unless the controller is put into IDLE mode.

Three fields must be configured after a protocol is selected:

1. Network
2. Devices
3. Scan List

## 13.3: Network Configuration



The image shows a 'Network Config (Modbus Master)' dialog box. It is divided into several sections: 'Port Configuration' with fields for Baud Rate (9600), Parity (None), Data Bits (8), Stop Bits (1), Handshake (None), Protocol (Modbus RTU), Mode (RS-232), Retries (2), Timeout (10000 mSec), and Slave Speed (Fast); 'Update Scan' with 'Automatic' selected, Update Interval (0 mSec), ReacquireTime (100000 mSec), and 'Manual' options for Trigger and ID Select; 'Master ID / Address' with Address (0); and 'Status' with Register and Name fields. At the bottom are 'Protocol Help', 'OK', and 'Cancel' buttons.


Network Configuration provides the required parameters to configure the network. Each protocol is different and may not require the entire Network Config field. Please refer to the table below for the options in the Network Config field.

Network Protocols		
<b>Baud Rate, Data Bits, Stop Bits, Parity</b>	These field define the bit level transfer over the serial port.	
<b>Handshake</b>	<b>None</b> – No handshake lines are used <b>Multidrop Full</b> – Rx remains active while Tx is occurring. <b>Multidrop Half</b> – Rx is shut off while Tx is occurring. <b>Radio Modem</b> – Wait for CTS acknowledgment before transmitting (legacy radio modem support).	
<b>Protocol</b>	If a driver supports multiple protocols, it is selected here, (i.e. Modbus supports RTU or ANSI).	
<b>Mode</b>	Specifies if port operates in RS-232 or RS-485 mode.	
<b>Retries</b>	Specifies number of times a transaction is retried on a failed response.	
<b>Timeout</b>	Specifies the amount of time for a device to wait for a valid response.	
<b>Update Scan</b>	Automatic	<b>Update Interval</b> – Specifies the update interval at which all the mapped entries are executed. <b>Reacquire Time</b> – Specifies the amount of time to wait before attempting communications with an offline device.
	Manual	<b>Trigger</b> – Specifies the binary register that a single transaction scan of the Scan List.

Network Protocols		
		<b>ID Select</b> – If an analog is specified in the field, the ID Select filter is enabled.
<b>Status Register</b>	Specifies the starting OCS register of eight (8) consecutive registers (4-32bit counters), which provide an indication of the network health.	
<b>Scanner Address</b>	Specifies the OCS's device (network) ID if a master ID is required by the protocol.	
<b>Protocol Help</b>	Provides protocol specific help.	

## 13.4: Device List and Device Configuration


### 13.4.1: Device List



This configuration list is reached from the Device button on the Protocol Config screen and provides a list of the configured devices on the Network. Devices must be created and exist in this list before corresponding Scan List entries can be created for this device. Typically, the number of entries is limited to **64 devices**.

- **Add** - Opens the Device Config dialog to add a new device to the list.
- **Delete** - Remove selected device from list (all corresponding Scan List entries are also removed).
- **Config** - Invoke the Device Config dialog for the currently selected device. This can also be accomplished by double-clicking a device entry.
- **Mapping** - Invoke the Scan List limiting the entries displayed for the selected device.

### 13.4.2: Device Configuration



The dialog box is titled "Dialog" and contains the following sections:

- Device:**
  - Name: [Text Field]
  - ID: [Text Field] (Slave Address)
- Device Options:**
  - ☐ Swap words on 32-bit data
  - ☐ Target returns 32-bit on single register request
  - Device Type: [Modicon PLC 5-Digit Addressing]
  - Mode: [Device Supports all modbus write function codes]
- Disable Device:**
  - Register: [Text Field] Name: [Text Field] 16-bit
- Status:**
  - ☐ Enable
  - Address: [Text Field] Name: [Text Field] 2 x 16-bit
  - ☐ Stop on Error ☐ Retry on Error


Buttons: Ok, Cancel

HG-122

This configuration is reached from the device list when adding or modifying an existing device. While each protocol is somewhat different and can contain protocol specific field, all protocols typically support at least:

- **Device Name** - Specifies a tag name for this device. This tag name is used in the Data Mapping configuration to identify this device. This allows device addresses to be modified without the need to update all associated Data Mapping entries.
- **Device ID** - Specifies the target device communications ID or station address.
- **Swap Words on 32-bit Data** - If a Scan List entry is configured to transfer 32-bits and this option is checked, the high and low 16-bit values are swapped when transferred between the target and OCS.
- **Disable Device** - From Cscape 9.90 SP3 and firmware 15.40 onwards, disable device feature has been added in protocol device configuration. This option is used to disable a particular slave configured in the network. Single bit register has to be configured to use this function. Setting the bit high disables the slave and OCS will not send any serial (TCP for ethernet protocols) packets only to this slave until the bit is high. Setting the bit low enables the communication with the slave again.
- **Status Enable** - This checkbox enables device status to be displayed and controlled from two consecutive 16-bit registers.
- **Status Address** - Enter the starting 16-bit OCS register of two consecutive registers used for device status. The first register contains the protocol device driver specific error code while the second register contains the index of the offending Scan List entry.
- **Status Modes:**
  - a. **Stop on Error** - Specifies that communications be only reattempted after offline status when the corresponding device status register is cleared.
  - b. **Retry on Error** - Specifies that communications be reattempted either during the reacquire interval or when the corresponding device status register is cleared.

## 13.5: Scan List



The image shows a software window titled "Scan List (Modbus Master)". It has a menu bar with "Edit", "View", and "Sort". Below the menu bar is a table with the following columns: Index, Local Name, Register, Type, Dev Name, ID, Target, and Length. The table is currently empty. To the right of the table are four buttons: "Add", "Delete", "Config", and "Edit Names". At the bottom of the window, there is a "Filter By Device:" label followed by a dropdown menu showing "All". There are also "Cancel" and "OK" buttons at the bottom right. The window has a standard Windows-style title bar with a close button (X) in the top right corner.

This configuration list is reached from the Scan List button on the Protocol Config screen or the **Mapping** button on the Device List screen and provides a Scan List of the Data Mapping entries. To transfer data between the OCS and remote target, a Scan List must be created that defines each transaction. Each mapping entry (transaction) contains the source and destination registers, the number of consecutive registers transferred, the direction of the transfer and what triggers the transfer. Typically, **the number of entries is limited to 512**.

**NOTE:** The order of the Scan List is the order in which the transactions occur. Sort functions are provided to change the order of the list. Each entry also has an identifying index. If the device status register is enabled and a transaction failure occurs, the status register indicates the index number of the transaction that failed.

### 13.5.1: Menu

- **Edit > Copy All** - Copies Scan List to clipboard in a tab delimited format suitable for pasting into an application like Microsoft Excel.
- **Edit > Paste** - Loads Scan List from clipboard. Pasted items are added to the scan list even if they are duplicates.
- **View > Toggle All Name View** - Expands Scan List such that each point and corresponding local name is displayed.
- **Sort** Scan List by different criteria. The firmware will scan the devices based on the order they are displayed or sorted. There are four ways to sort the scan list:
  - a. **By Local Address** – Sorts the list by local register address in increasing order.
  - b. **By Target Address** – Sorts the list by target register address in increasing order.
  - c. **By Device Name** – Sorts by device name, then target address.
  - d. **Interleave Devices** – This sort evenly distributes request among the different devices. Instead of requesting 100 blocks from device A, then 100 blocks from device B, one requests is sent to device A, then one request is sent to device B until all the data has been requested. This is useful for devices that may have a timeout timer because the time between each scan for a particular device is minimized. This sorting options usually doesn't affect performance.


### 13.5.2: Buttons

- **Add** - Opens the Data Mapping dialog to add a new entry to the Scan List.
- **Delete** - Removes selected entry from Scan List
- **Config** - Opens the Data Mapping dialog for the currently selected entry. This can also be accomplished by double-clicking an entry.
- **Edit Names** - Invokes the Edit Names dialog for the currently selected entry. The Edit Names dialog provides the ability to create OCS program names for each point in the transaction.

### 13.5.3: Display Control

**Filter by Device** - Limits displayed entries to only those assigned to the indicated device. To show all entries select **-All-**.

### 13.5.4: Data Mapping Configuration (Scan List Entry)



The dialog box is titled "Dialog" and contains three main sections: Target, Local, and UpdateType. The Target section includes a Device Name dropdown menu (set to "test (1)"), a Device Register text field with a right arrow button, a checkbox for "32 bit access", and a Length text field (set to "1"). The Local section includes a Register text field and a Name dropdown menu. The UpdateType section includes five radio buttons: "Polled Read" (selected), "Polled Read/Write", "Polled Read/Write Init", "Triggered Read", and "Triggered Write". Below these is a Trigger Register text field and a Name dropdown menu. At the bottom are "OK" and "Cancel" buttons. The text "HG-121" is visible in the bottom left corner.

#### Target

- **Device Name** - Selects the target device (by tag name) to use for this transaction. Only those device entries previously created from the Device Config menu are available.
- **Device Register** - Specifies the target device's register to use for this transaction. This designation is target-specific. The configuration menu displays an error if a specified address is unacceptable. **Generally, the data type of the local (OCS ) register must match the data type of the device register.**
- **The Right Arrow button** - Displays protocol device driver specific help for the target addressing. Note that some devices can require register addresses that exist on 8-bit, 16-bit or 32-bit boundaries.
- **Local Register** - Specifies the local (OCS ) register that is the source or destination for the transaction.
- **Local Name [Optional]** - Optionally allows selection of a OCS register by name <or> creation of a name for a register already selected by direct reference. Created names can be used thereafter to specify the local (OCS ) register in ladder or graphics address fields.
- **32-Bit Access** - Allows two local (OCS ) 16-bit registers to be treated as a single 32-bit value. For example, if the value in either 16-bit register is modified, both registers are written to the device. Device-specific, 32-bit word swapping options also apply to this designation. Since the transaction is treated as a 32-bit access, the length is generally limited to 16. Note that some protocols can disable this feature.

- **Length**
  - a. Specifies the number of consecutive device registers that are transferred in this transaction. Note that some protocols can limit the length that can be transferred. However, typically the **length is limited to 32**. The configuration menu displays an error if a specified length is unacceptable.
  - b. **If allowed, specifying a length greater than one (multiple consecutive register transfers per transaction) is more efficient than creating a single transaction for each register.** This grouping of registers per transaction can significantly reduce the transaction scan time; however, **update types that include writing on a polled basis require additional consideration.**
  - c. On **Read/Write** and **Read/Write/Init** update types, the write transaction only occurs when the local (OCS ) register value changes. If the length is greater than 1 for Read/Write and Read/Write/Init types, only the local register(s) that change in value are written. More specifically, only one write transaction occurs per scan per mapping entry for the register or consecutive sub-group of local registers that changed in value. Depending on the protocol, the number of points written with that write transaction are limited either to one or the number of consecutive points that changed value.
  - d. **Therefore, if several local registers (specified in a single mapping entry) change in value prior to a transaction scan, it takes SEVERAL transaction scans to complete all the write operations. Furthermore, all write operations are completed before a read operation is scheduled.**
  - e. **For Manual Update (transaction) scans (i.e. dialup modem), it is recommended that all Read/Write Scan List entry lengths be limited to 1.**

## Update Type

This field specifies the direction and what triggers the transfer of data between the OCS and target device for a mapping entry.

- **Polled Read** - On every transaction scan, a read-only target device register(s) transaction occurs.
- **Polled Read/Write**
  - a. On every transaction scan, a read target device register transaction occurs unless a local register value has changed. The write transaction only updates those local registers that have changed in value. If several non-consecutive local registers (contained in a single mapping entry) change value between transaction scans, it takes several consecutive transaction scans to write each changed register.
  - b. When the OCS is placed in RUN mode, **the initial action for this mapping type is a read target register transaction.** This transaction initializes the local (OCS ) register(s) to match that of the remote device register(s). Thereafter, any change to the corresponding OCS register(s) triggers a write operation to the remote device.

- **Polled Read/Write/Init**
  - a. On every transaction scan, a read target device register transaction occurs unless a local register value has changed. The write transaction only updates those local registers that have changed in value. If several non-consecutive local registers (contained in a single mapping entry) change value between transaction scans, it takes several consecutive scans to write each changed register.
  - b. On every transaction scan, a read target device register transaction occurs unless a local register value has changed. The write transaction only updates those local registers that have changed in value. If several non-consecutive local registers (contained in a single mapping entry) change value between transaction scans, it takes several consecutive scans to write each changed register.
  - c. When the OCS is placed in RUN mode, **the initial action for this mapping type is a write target register transaction**. This transaction initializes the target device register(s) to match that of the local (OCS ) register(s). Thereafter, any change to the corresponding OCS register(s) triggers a write operation to the remote device.
  - d. The initial write transaction does not occur until after the first logic scan of the OCS . This allows registers to be initialized locally before Writing to the target device register(s).
- **Triggered Read** - A read transaction is triggered by a high level on a separately designated OCS (binary) trigger register. Once the read transaction is complete (or the device is offline), the OCS trigger register is cleared by the OCS . This update type can be used for occasional data accesses such as retrieving trend data. Note that this operation increases the associated transaction scan time and can cause the **Update Interval Exceeded Counter** to increment on a tightly adjusted update interval.
- **Triggered Write** - A write transaction is triggered by a high level on a separately designated OCS (binary) trigger register. Once the write transaction is complete (or the device is offline) the OCS trigger register is cleared by OCS . This function can be used for occasional data accesses such as sending recipe data. Note that this operation increases the associated transaction scan time and can cause the **Update Interval Time Exceeded Counter** to increment on a tightly adjusted update interval.

# User Interface



## Chapter 14: User Interface


Screen Specifications .....	142
Displaying and Entering Data .....	143
Alpha-Numeric Keypad .....	144
Screen Navigation .....	146
Ladder-Based Screen Navigation .....	147
Beeper Acknowledgement .....	147
Touch (Slip) Sensitivity .....	148
Alarms .....	148
Removable Media .....	150
Screen Saver .....	152
Screen Brightness .....	152
Touch Screen Pressure .....	153

This chapter presents the user interface (or operator view) of the XL15 Prime and some of the model specific characteristics of the XL15 Prime as compared to the rest of the OCS line. This chapter does NOT cover building screens or using the Cscape graphics editor. For instructions on creating screens and using the graphics editor, refer to the Graphics Editor Help File in Cscape.

### Screen Specifications

Display Type	15" XGA TFT (500 cd/m <sup>2</sup> typical)
Resolution	1024x768
Color	24-bit (16,777,216)
Built-In Storage	8 GB
User-Programmable Screens	1023 max pages; 1023 objects per page
Backlight	LED – 50,000-hour life

## Displaying and Entering Data



Multiple objects are provided for displaying data such as virtual panel lights, push buttons, numeric value displays, bar graphs, meters, graphs and animated bitmaps. On the XL15 Prime, these graphical objects (through ladder manipulation of attribute bits) can change color, flash, or change visibility to attract operator attention.

On objects that accept user input, the input is provided by touching the object or alternately changing an OCS register (i.e. function key registers). Objects that allow input generally have a raised 3D appearance. An exception is the binary type objects, such as buttons, which are shown in a depressed 3D appearance when in the ON state. Objects that normally accept touch input may be disabled through program control (through ladder manipulation of an attribute bit). If an object is disabled, the object's representation changes to a 2D appearance.

On objects that represent non-discrete information, more action may be required beyond that of simply touching the object. For example, the slider object requires the operator to touch and slide the control in the direction desired. Alternately, alpha-numeric entry objects invoke a pop-up alpha-numeric keypad for additional user input. The alpha-numeric keypad is discussed below.


**NOTE:** If the numeric entry object displays >>>>>>, the value is too big to display in the field or is above the maximum for an editable field. Likewise, if the numeric entry object displays <<<<<< in a numeric field, the value is too small to display or is below the minimum for an editable field.

## Alpha-Numeric Keypad

To allow entry of a specific number or text, several of the input objects invoke a pop-up alpha-numeric keypad when the object is touched. An example of the alpha-numeric keypad invoked from a numeric input object is shown below. Once invoked, the operator may touch the appropriate keys to enter a specific value. When entering a value, the alpha-numeric keypad is in one of two modes [new-value or edit-value].

**New-Value Mode** - Generally, when the alpha-numeric keypad is first invoked, it is placed in new-value mode. Initially, the alpha-numeric keypad displays the current value with all the digits being highlighted. Once the first digit is entered, the current value is erased from the display and the new digit is placed in the first location. Thereafter, no digits are highlighted, and new digits are added to the rightmost position while the other digits are shifted left.

**Edit-Value Mode** - Edit-value mode may be entered from the initial new-value mode by pressing either the left or right arrow key before any digit key is pressed. The result will be a single character highlighted. The user may then either touch a key to change the digit at the selected position or the up and down arrows may be used to add or subtract (respectively) from the selected digit. The user may then use the left or right arrow keys to select a new position.



Once the desired value is entered, pressing the Enter key moves that value into the object (and the corresponding OCS register) and the alpha-numeric keypad disappears. Alternately, pressing the ESC key any time before the Enter key cancels the operation, leaves the objects current value unchanged, and the alpha-numeric keypad disappears.


**NOTE:** Each numeric entry object has a configured minimum and maximum value. If the operator enters a value outside of the configured range, the new value is ignored when Enter is pressed and the current object value is NOT changed.

Since the alpha-numeric keypad services several different graphical objects, certain keys on the alpha-numeric keypad may be disabled (grayed) when the keypad is invoked for certain objects. The following describes the alpha-numeric keypad variation based on object.

Alpha-Numeric Keypad Variations	
Numeric Object	When editing a numeric value, the [+/-] or the [.] key are disabled (grayed) if the object is NOT configured for floating-point value or a signed value.
Password Object	When editing a password value, the arrow keys, [+/-], and the [.] keys are disabled. Additionally, overwrite mode is disabled. When entering digits, the pop-up keypad hides the value by displaying '*' alternately for each digit.
ASCII Object	When editing an ASCII value, an ASCII keypad is displayed. The ASCII keypad has 3 modes: numeric, symbols and alpha. In Alpha mode, the Caps Lock button may be pressed to access capital letters. Typing a character will overwrite the entire old string and start a new entry. Press the backspace arrow to delete the previous character. Pressing Enter will save the entry, pressing ESC will cancel the edit and return the string to the previous value.
Text Table Object	When editing a Text Table Object, all the keys except the Up and Down arrow keys are grayed and disabled. The next text selection is made by pressing either the Up or Down arrow.
Time/Date Object	When editing a Time/Date Table Object, all the keys except the Up, Down, Left and Right arrow keys are grayed and disabled. The specific field (i.e. hour or minutes) is selected using the Left and Right arrows. The value in the selected field is changed by pressing either the Up or Down arrow.

## Screen Navigation


To allow the operator to change screens, a Screen Jump Object is generally used. This object may be visually represented as a 3-D button (responding to touch) or remain invisible and logically tied to an OCS register. An optional system icon may be configured for display along with the legend, which aids in identifying the object as one that causes a screen change.



## Ladder-Based Screen Navigation

Ladder logic can use several techniques to control screen navigation. Coils can be tied to %D registers to make them screen coils. These coils have two modes: switch and alarm. If the ladder program energizes an alarm display coil, the screen associated with this coil is displayed and overrides the normal user screens. This is designed to show alarm conditions or to display other ladder-detected events. When the text coil is de-energized, the previous screen that was being viewed before the alarm is returned.

The switch display coil switches to the associated screen when it is energized. Once it is de-energized, the screen remains until it is switched by the user or ladder.



There is also a system register that can be used to for control-based screen navigation. %SR1 can be read to determine the current screen or written to change the current screen. Refer to the online help in Cscape for more information on control-based screen navigation.

## Beeper Acknowledgement

The XL15 Prime contains an internal beeper that provides an audible acknowledgment when an operator touches a graphic object that accepts touch input. When the graphic object is enabled, a short 5ms tone is emitted. When the graphic object is disabled, a longer 100ms tone is emitted to announce that the graphical object is not currently accepting the touch input.

If beep acknowledgement is not desired, the beeper function can be disabled from the **System Menu**.

## Touch (Slip) Sensitivity

Touch slip sensitivity is preset to meet most applications; however, adjustment is available to reduce the sensitivity for touch release. That is, once a graphical object (button) is touched and held by a finger, the default touch slip sensitivity allows for a slight slip of the finger on the graphical object before the XL 15 Prime assumes touch been released (equates to approximately a quarter inch of movement with a stylus).

In some applications (such as jog buttons) where the operator is pushing a button for a period of time, the amount of slip while holding a button pressed may exceed the default sensitivity. To increase the amount of tolerable slip and prevent false releases of the button, the XL 15 Prime allows adjustment of the allowable slide up to 5x the default value.

To enable the touch (slip) sensitivity, first an OCS data register must be allocated through the Graphics Editor Configuration menu for Display Settings. Once a Touch Sensitivity register is assigned, that register may be modified [range = 1 (Low) to 5 (High)] to the desired slide amount. If a value outside the valid range is entered in the touch sensitivity register, it is ignored, and the last valid value is used.

## Alarms

Alarm presentation to the operator is highly configurable and beyond the scope of this document to describe fully. For more information, refer to the graphics editor help file in CSPACE. This section presents a typical configuration thereby providing an introductory description on what the operator should expect.


The alarm object is generally used to enunciate alarms to the operator. While the display characteristics of this object is configurable, it is generally displayed as a button that changes colors to indicate the highest state of the alarm(s) in the alarm group it is monitoring. The following indicates the priority of the alarm states and the default colors associated with these states.

<b>Highest</b>	(Red)	Unacknowledged Alarms Exist
-	(Yellow)	Acknowledged Alarms Exist
<b>Lowest</b>	(Green)	No Alarms Exist



To view, acknowledge and/or clear alarms, the operator must access the alarm viewer. This is accomplished by touching an (enabled) alarm object. When accessed, the alarm viewer is displayed as pop-up alarm viewer dialog.

## Alarm Viewer



The currently selected entry is indicated by a yellow highlight which can be moved up or down by touching the arrow buttons or by directly touching an entry. If more entries exist than can fit on the page, a scroll bar is displayed on the right side that also indicates the current relative position.

The current state of the displayed alarm is indicated by its color and optionally by an abbreviated indicator after the date/time stamp (ALM, ACK, RTN). The operator can acknowledge an alarm by selecting it from the list and touching the ACK button. The operator can also clear an alarm if that function is enabled in the alarm object. If not enabled, the Clear buttons are grayed and do not respond to touch. Once view operations are complete, simply touch the Esc button to remove the pop-up alarm viewer.

**NOTE:** OCS registers %SR181 and %SR182 are available for ladder use, which indicate presence of unacknowledged or acknowledged alarm (respectively). The screen designer may implement these registers to switch screens or activate the beeper to attract the operator's attention.

## Removable Media


The Removable Media Object is generally used to inform the operator on the current state of the removable media device and allow access to its file structure. The Removable Media Object is displayed as a button that changes colors to indicate the current state of the removable media device. The following indicates the device states and the default colors associated with these states.



To view and perform file operations, the operator must access the removable viewer. This is accomplished by either touching an (enabled) removable media object or through the System Menu. When accessed, the removable media viewer is displayed as pop-up removable media dialog.


**NOTE:** The Removable Media Object can be configured to open the removable media viewer at a certain directory complete with restrictions on transversing back up the file path. This may be used to restrict operator access to non-critical files.

Media Directory			
SCREEN00.BMP	153654	01-13-96	1:10P
SCREEN01.BMP	153654	01-13-96	1:13P
SCREEN26.BMP	153654	01-13-96	1:08P



The currently selected entry is indicated by a yellow highlight which can be moved up or down by touching the arrow buttons or by directly touching an entry. If more entries exist than can fit on the page, a scroll bar is displayed on the right side that also indicates the current relative position.

File operations are accomplished by pressing the appropriate button at the bottom of the Removable Media Viewer. The configuration of the removable media object that invokes the Removable Media Viewer defines what buttons are enabled and available to the user. A button is grayed and does not respond to touch if configured as disabled.


The  (Enter) button (if enabled) performs certain operations based on the selected file's type:

..	Change display to parent directory
<DIR>	Change display to child directory
bmp, jpeg	Display bitmap (if compatible format)
pgm	Load application (if compatible model and version)

Alternately, the (enter) button can be configured to simply load the ASCII representation of the file path (including the file name) to a group of OCS registers. That pathname can then be used by ladder for opening and manipulating that file.

Once view operations are complete, simply touch the Esc button to remove the pop-up removable media viewer.

If the removable media is used in an application, the Removable Media Device requires changing by the operator, and the application is attempting to write to the removable media when it is removed, the screen designer should create objects that allow the operator to temporarily halt access to the removable media. This prevents corruption to the file system if the removable media is removed during a file-write sequence. The graphic objects should set OCS register %SR174.1 (when requesting the card be removed) and provide an indicator based on OCS register %SR174.2 (which indicates that it is safe to remove the removable media).



## Screen Saver

The XL15 Prime screen backlight life is typically five (5) years when in continuous use. If the application does not require interaction with the XL15 Prime for long periods of time, the backlight life can be extended by using the screen saver function. When enabled through the System Menu, the backlight is shut off (screen goes black) after a specified time of no touch activity on the screen. When the screen saver shuts off the backlight, any operator touch on the screen or function keys reactivates the backlight.

**NOTE:** When the screen saver is active (backlight shut off), any initial touch activity on the screen (or function key) to reactivate the backlight is otherwise ignored by the XL15 Prime. Any additional touch activity is also ignored by the XL15 Prime for approximately one second thereafter.

It is possible for the application to temporarily disable the screen saver by generating a positive transition to %SR57.16 (coil only) at a rate faster than the screen saver timeout value. This may be desired while waiting for alarm acknowledgement.


## Screen Brightness

The XL15 Prime provides a feature that allows screen dimming for night operation. To enable this feature, the application must access and control system register %SR57 (Display Backlight Brightness). Screen brightness is continuously variable by driving %SR57 through the range of 100 (full bright) to 0 (full off). It is left to the screen designer on if and how to present a Screen Brightness control to the user.

**NOTE:** The backlight life can be extended by dimming or powering off the backlight.

## Touch Screen Pressure

The Horner XL Prime series OCS controllers have a resistive touch screen that allows mechanically detecting touch events. The resistive touch screen works by measuring the resistance between two layers of conductive film.



HG-186

**NOTE:** Touch creates contact between resistive circuit layers, closing a switch.

With a unique change to the touch monitoring firmware user can measure the pressure being exerted on the touch screen. This feature has been added in some Horner XL Prime series controllers. This allows the OCS programmer to be notified of the touch pressure and it can configure the pressure required to accept a touch event.

There are two system registers that provide this touch feature:

- **%SR9 (I/O Name - TCH\_PRESSURE)** - Records the highest-pressure level of the last touch on the screen that exceeds the threshold value set in %SR10. This is a range of 0 to 3000. Zero (0) indicates no pressure and 3000 is the maximum amount of pressure that can be measured.
- **%SR10 (I/O Name - TCH\_PRESSURE\_TSH)** - This register sets the pressure threshold to indicate a touch. A value of 200 is typically the lightest touch, 600 is moderate and 1000+ is a heavy touch.

These new features allow customizing the feel of the touch screen and can be used to add unique user interface features such as having different operations depending on the force of the touch.

# Audio Playback



## Chapter 15: Audio Playback


<b>15.1: Audio Specifications</b> .....	<b>155</b>
<b>15.2: Audio Configuration</b> .....	<b>156</b>
<b>15.3: Audio Files</b> .....	<b>157</b>

### 15.1: Audio Specifications

Audio Files Specifications	
Formats Supported	.MP3 & .WAV
Audio Channel Type Supported	Stereo
# of Files Supported	256 Audio Files can be configured
Bit Rates Supported	64kbps, 128kbps (recommended), 192kbps, 256kbps, 1411kbps
.MP3 Format Bit Rate Range	96 to 320kbps
.WAV Bit Rate	Usually 1411kbps
Sampling Rate Supported	24000Hz to 44100Hz
Audio Playback	<ul style="list-style-type: none"> <li>Only one audio file can be played at a time.</li> <li>If multiple bits are simultaneously triggered, only the least significant bit will be acted upon. After completing playback, the next least significant bit will be acted upon.</li> </ul>
File Location	Files must be present in Removable Media for playback and are NOT downloaded from Cscape.

## 15.2: Audio Configuration

1. In Cscape, select the controller series and model number by selecting **Controller > Hardware Configuration** from the toolbar. Click **OK**.
2. Next select **Program** from the toolbar and then **Audio Config**. This following dialog will open:




- **Triggers** – Set the trigger bit high to play the audio file.  
**NOTE:** The bit needs to be left on to continue playing. The bit will be set to low after the file is finished laying.
- **Status** – This register gives the status of the audio files, see table below.


1st and 2nd Status Registers		
	Bit Number	Description
1st Status Register	Bit 1 to Bit 8	Volume Control (0-100)
	Bit 9	Play Control (1=Pause, 0=Play)
	Bits 10-16	Not Used
2nd Status Register	Bit 1	Cannot open ALSA Lib
	Bit 2	Cannot open MP3 Lib
	Bit 3	Audio output device cannot be setup
	Bit 4	Cannot open input Audio Stream
	Bit 5	Memory allocation failed
	Bit 6	Buffer is not free
	Bit 7	Write Fail
	Bit 8	Short Write
	Bit 9	Recover Error
	Bit 10	Filename Error
	Bits 11-16	Not Used

## 15.3: Audio Files

- **Index** – Index of all the audio files will be assigned automatically when audio files are added.
- **Audio Target Path** – This gives information about the path of the audio file, audio filename, and format of the audio files added to the list.



**Add** – Selecting this button display the following window, where an audio filename with full path needs to be configure. The Modify and Delete button are also available in the Audio Config dialog.



**ALERT:** Audio files are not downloaded from Cscape; they must be present

**ALERT:** Only one audio file can be played at a time. If multiple bits are simultaneously triggered, only the least significant bit will be acted upon.

**ALERT:** Only MP3 and WAV formats are supported.

**ALERT:** 256 audio files can be played.

# Video Object




## Chapter 16: Video Object

16.1: Video Object Overview .....	160
16.2: Opening Video Object in Cscope .....	161
16.3: Video Properties Configuration .....	162
16.4: Video Object Performance .....	164
16.5: Web Cameras .....	164

### 16.1: Video Object Overview

The Video Object feature allows two options for video type: Stream and Playback. The Video Object trigger is used to start, stop, and pause video, and the System Register provides the status of the video object, which supports various resolutions and frames per second.



The Video Properties dialog box is divided into three main sections: Video Type, Control, and Display Properties. The Video Type section has two radio buttons: Stream and Playback. The Stream section has a text field for 'Enter Channel No' and a dropdown for 'Name' with a '14-BIT' label. The Playback section has a text field for 'Enter Target Path' and a dropdown for 'Name' with a '14-BIT' label. The Control section has two rows: Trigger and Status Register. Each row has a text field, a dropdown for 'Name', and a '14-BIT' label. The Display Properties section has two rows: Resolution and Frames Per Second. The Resolution row has a dropdown set to 'Variable size'. The Frames Per Second row has a dropdown set to 'MAX\_FPS'. There is an 'Attributes>>>' button to the right of the Frames Per Second dropdown. At the bottom are 'OK' and 'Cancel' buttons. The text 'HG-102' is visible in the bottom left corner.


Specifications of Video Properties	
Streaming Channels	4 channels supported through USB hub
	1 channel can be viewed at a time
Playback Formats	.mp4, .mov, .mpg, .wmv
Resolution	320x240 (QVGA)
Frames per Seconds	10, 15, 20, 24, 30 & MAX_FPS

## 16.2: Opening Video Object in Cscape


**NOTE:** For Cscape 10 please refer to the Help File.

In Cscape, select the OCS and model number by selecting **Controller > Hardware Configuration** from the toolbar.


1. Open the Graphics Editor by selecting the “T” button from the toolbar.




2. In the Graphics Editor, select the video button from the toolbar.



3. Click on the grid.




4. Then double click on the icon in the middle to open the Video Properties dialog.



## 16.3: Video Properties Configuration

### 16.3.1: Video Type



The image shows a 'Video Properties' dialog box with a close button (X) in the top right corner. The dialog is divided into three main sections: 'Video Type', 'Control', and 'Display Properties'. The 'Video Type' section is highlighted with a red rectangle and contains two radio buttons: 'Stream' and 'Playback'. The 'Stream' option is currently selected. To the right of the 'Stream' radio button is a text field labeled 'Enter Channel No' with a 'Name:' dropdown menu and a '14-BIT' label. To the right of the 'Playback' radio button is a text field labeled 'Enter Target Path' with a 'Name:' dropdown menu and a '14-BIT' label. The 'Control' section contains two rows: 'Trigger' with a 'Name:' dropdown menu and a '14-BIT x 8' label, and 'Status Register' with a 'Name:' dropdown menu and a '14-BIT' label. The 'Display Properties' section contains two rows: 'Resolution' with a dropdown menu showing '320 x 240 (QVGA)' and an 'Attributes>>>' button, and 'Frames Per Second' with a dropdown menu showing 'MAX\_FPS'. At the bottom of the dialog are 'OK' and 'Cancel' buttons. The text 'HG-103' is visible in the bottom left corner.

There are two options for video type: **Stream** and **Playback**.


**Stream** – This option can be selected to view live video from a web cam. Four channels are supported through the USB hub. Only one channel can be viewed at a time. Enter Channel Number directly or through registers in the Enter Channel No field.

**Playback** – This option can be selected to view videos that are stored in Removable Media on the controller. Videos present in both A (microSD) and B (USB) drives are supported and can be viewed. Supported formats including .mp4, .mov, .mpg, and .wmv, can be played.

Select **Playback** and enter video name in the Enter Target Path field either directly or through registers.

**For example:** Test1.mp4 (from microSD) or B:\Test2.mp4 (from USB).

### 16.3.2: Control



**Trigger** - The video control trigger is used to start, stop and pause video. Video trigger is done by bit level addressing. The trigger reserves eight (8) bits and uses the first two (2) bits.

**NOTE:** The least significant bit is Bit 1.

Bit 1	High = Start Low = Stop
Bit 2	High = Pause Low = Play

**System Bit** - The Video Control System Bit provides the status of the Video Object. The status word is 16-bits and should be viewed in hexadecimal format.

0x0001	Video is currently playing
0x0002	Video is paused
0x00010	Channel number cannot be greater than 4
0x0020	File not present or corrupted
0x0040	Frame per second not supported or not compatible

### 16.3.3: Configuring Display Properties

Video Properties

Video Type

☐ Stream Enter Channel No

☒ Playback Enter Target Path

Test1.mp4

Control

Trigger %R00001.1 Name: x 8

Status Register %R00010 Name:

Display Properties

Resolution 320 x 240 (QVGA)

Frames Per Second MAX\_FPS

20

24

30

MAX\_FPS

Attributes>>>

OK Cancel

Resolution Options	320x240 (QVGA)
Frames per Seconds	10, 15, 20, 24, 30 & MAX_FPS

## 16.4: Video Object Performance

1. When Video Object is active, navigating to System Menu or any popup window, causes Video Object to be inactive.
2. Video Object can be made active in both Idle and Run modes.
3. If Frames Per Second of the configured video is different from the video that is configured in Cscape, frames can be missed during the video.

## 16.5: Web Cameras

If multiple web cameras are directly connected to the OCS, then only one web cam will be considered. If user needs to connect multiple web cams, USB hub needs to be used. A maximum of four channels (web cameras) are supported.


# Removable Media



## Chapter 17: Removable Media

17.1: microSD Cards .....	166
17.2: Using the Removable Media Manager .....	167
17.3: Log Data .....	168
17.4: View and Capture Screens .....	168
17.5: Removable Media Object .....	168
17.6: Function Blocks in Cscape .....	169
17.7: Filenames .....	170
17.8: System Registers used with RM .....	170

All Horner controllers models provide a Removable Media slot, labeled Memory Card, which supports standard microSD flash memory cards. microSD cards can be used to save and load applications, to capture graphics screens, and to log data for later retrieval.



### 17.1: microSD Cards

MicroSD cards(Memory Cards) with up to 32GB of flash memory, are compatible with the Horner controller Memory Card slot. The Memory Card slot is equipped with a “push-in, push-out” connector and a microSD card can be safely inserted into the Memory Card slot whether the Horner controller power is On or Off.

- To install a microSD card: Align its 8-pin gold edge connector down, facing the front of the Horner controller unit as shown above; then carefully push it all the way into the Memory Card slot. Ensure that it clicks into place.
- To remove the microSD card: Push down on the top of the card gently to release the spring. The card pops up for removal.

### 17.1.1: microSD File System

The microSD Memory Card slot uses the PC-compatible FAT32 File System. This means that a PC, with a microSD-compatible card reader, can read files that have been written by the Horner controller and can write files that can be read by the Horner controller.

However, the Horner controller does not support long filenames, but instead implements the 8.3 filename format. This means that all file and directory names must consist of up to eight (8) characters, followed by an optional dot, and an optional extension with up to three (3) characters.

Directories and sub-directories can be nested up to 16 levels deep as long as each path name string does not exceed 147 characters.

## 17.2: Using the Removable Media Manager

The Removable Media Manager is an interactive Horner controller screen that performs the following functions:

- Display total capacity, and available space in kilobytes
- Browse file and directory lists
- Delete files and directories
- Format a microSD card
- Load and save application programs
- View screen capture bitmaps

The Removable Media Manager can be accessed via the System Menu or by using Cscape to place a Removable Media Manager object on an application graphics screen.


Media Directory				
SCR0000	.JPG	26267	07-10-08	12:46
SCR0001	.JPG	14272	07-10-08	12:46
SCR0002	.JPG	15209	07-10-08	12:46
SCR0003	.JPG	29708	07-10-08	12:46
SCR0004	.JPG	29582	07-10-08	12:47
SCR0005	.JPG	23263	07-10-08	12:47
SCR0006	.JPG	14643	07-10-08	12:47
SCR0007	.JPG	14976	07-10-08	12:47
SCR0008	.JPG	15994	07-10-08	12:47
SCR0009	.JPG	17561	07-10-08	12:47
Free:		511672320	Total:	511959040
←	△	▽	Del	Del All
			For	Save
			mat	Pgn
				Esc

## 17.3: Log Data

Using Read and Write Removable Media function blocks, an application ladder program can read and write Horner controller register data in the form of comma-delimited files, with a .csv extension. These files are compatible with standard database and spreadsheet PC programs. In addition, an application ladder program can use Rename and Delete Removable Media function blocks to rename and delete files.

## 17.4: View and Capture Screens

The Horner controller File System uses bitmap files with the .BMP extension or JPEG files with the .JPG extension to store Horner controller graphic screen captures.

To view a captured Horner controller screen, use the Removable Media Manager to find and highlight the desired .BMP or .JPG file, and then press Enter. 


To capture an Horner controller screen, turning on the assigned **Screen Capture Control Register** will capture the current Horner controller graphics screen and write it to the microSD card using the assigned **Screen Capture Filename**.

Before capturing an Horner controller screen, Cscape must first be used to assign a **Screen Capture Control Register** and Filename in the application. To do this, first open the Graphics Editor by selecting the **View > Edit Screens** item on the **Cscape Screens** menu. Next, select the **Screen Capture** item of the **Graphics Editor Config** menu and then enter a Control Register and Filename.

To capture an Horner controller screen, turning On the assigned **Screen Capture Control Register** will capture the current Hornercontroller graphics screen and write it to the microSD card using the assigned **Screen Capture Filename**. To view a captured Horner controller screen, use the Removable Media Manager to find and highlight the desired .BMP or .JPG file, and then press Enter.

## 17.5: Removable Media Object

The configuration of the Removable Media Object that loads the Removable Media Viewer defines what buttons are enabled and available to the user.

The  (Enter) button (if enabled) performs certain operations based on the selected file's type:

..	Change display to parent directory
<DIR>	Change display to child directory
pgm	Load application (if compatible model and version)

Alternately, by checking the 'Write Selected Filename' option, the RM Manager object will load the currently displayed path and filename into a block of registers for use with other Removable Media functions. The register block is assigned in the 'File Select' config found in the Config menu of the graphic/screen editor.

Once view operations are complete, simply touch the Esc button to remove the pop-up removable media viewer.

## 17.6: Function Blocks in Cscape

**NOTE:** For detailed information regarding RM function blocks and parameters, refer to the Help File in Cscape Software. Refer to 'USB flash Media support for RM Functions' for USB flash drive access details.

The following RM functional blocks are available in Cscape Software. These function blocks will reference:

- microSD when filename is prefixed with 'A:' or nothing
- USB A flash drive when filename is prefixed with 'B:'

<b>Read RM csv</b>	Allows reading of a comma-separated value file from the microSD interface into the controller register space.
<b>Write RM csv</b>	Allows writing of a comma-separated value file to the microSD interface from the controller register space.
<b>Rename RM csv</b>	Allows renaming a file on the RM card. The data in the file is not changed.
<b>Delete RM csv</b>	Allows deleting a file on the RM card
<b>Copy RM csv</b>	Allows copying a file on the RM card. The data in the file is not changed.

### 17.6.1: Program Features

- Datalog Configuration** - This feature allows the controller to periodically log register values to Removable Media. The register data is stored in .csv (comma separated value) format, which is compatible with 3rd party PC applications, such as Microsoft Excel.
- Report Editor** - This feature allows the OCS to be configured to generate text printouts which incorporate data from the registers embedded in the text. The reports can be printed using a serial interface printer through any of the serial ports of the OCS or can be saved on the removable media of the device.
- Recipes Editor** - Recipes allow the user to send or update multiple registers simultaneously.

### 17.6.2: Graphic/Screen Editor

- Trends** - The historic support feature in the trend object utilizes Removable Media.
- Removable Media** - This is a graphic object used to access files and functions pertaining to Removable Media.
- Recipes** - This is a graphic object that is used in conjunction with the recipe editor which is mentioned above.

### 17.6.3: Additional Configuration

- Alarms** - Alarm data can be logged to a .csv file stored on Removable Media.
- Screen Capture** - The screen capture function allows a bitmap or jpeg image of the displayed OCS screen to be written to the Removable Media card.
- Filename Counters** - The filename counters can be accessed wherever Removable Media functions require a path name. A typical application is the auto-incrementing of a file name when doing screen captures.
- File Select** - File Select is used to specify the register block that is used with the Removable Media Manager object 'Write Selected Filename' option.

## 17.7: Filenames

The RM function blocks support the flash with a Windows standard FAT-16 file system. All names must be limited to the "8.3" format where the filename contains eight characters a period then a three-character extension.

The entire filename including any path must be less than or equal to 147 characters.

When creating filenames and directories, it is sometimes desirable to include parts of the current date or time. There are six special symbols that can be entered into a filename that are replaced by the OCS with current time and date information.

Filename Special Symbols		
Symbol	Description	Example
\$Y	Substitutes the current 2-digit year	2015 = 15
\$M	Substitutes the current month with a 2-digit code	March = 03
\$D	Substitutes the current day	22nd = 22
\$h	Substitutes the current hour in 24-hour format	5 pm = 17
\$m	Substitutes the current minute	45 = 45
\$s	Substitutes the current second	34 = 34

**NOTE:** All the symbols start with the dollar sign (\$) character. Date symbols are in upper case, time symbols are in lower case.

The following are examples of the substituted time/date filenames:

Current date and time: March 1, 2015 5:45:34 PM

**Filename:** Data\$M\$D.csv = Data0301.csv

**Filename:** Year\$Y\Month\$M\aa\$D\_\$h.csv = Year15\Month03\aa01\_17.csv

**Filename:** Month\_\$M\Day\_\$D\h\_\$m\_\$s.csv = Month\_03\Day\_01\17\_45\_34.csv

## 17.8: System Registers used with RM

**%SR174** – Removable Media Protect. Write a one (1) to %SR174 to prohibit read/write access to the removable media card. Write a zero (0) to allow access.

**%SR175 Status** – This shows the current status of the RM interface.

**%SR176 Free Space** – This 32-bit register shows the free space on the RM card in bytes.

**%SR178 Card Capacity** – This 32-bit register shows the total card capacity in kilobytes.

Possible status values are shown in the table:

RM Status Values	
0	RM interface OK
1	Card present but unknown format
2	No card in slot
3	Card present, but not supported

RM Status Values	
4	Card swapped before operation was complete
5	Unknown error

# Clone Unit



## Chapter 18: Clone Unit

18.1: Make Clone .....	173
18.2: Load Clone .....	176

"Clone Unit" feature allows the user to "clone" the OCS of the exact same model. This feature "clones" application program and unit settings stored in the following:

- Prime Series: retentive memory
- Non-Prime controllers: battery-backed RAM of an OCS into the RM


This feature can be used for:

- Replacing an OCS by another unit of the same model.
- Duplicating or "clone" units without a PC.


### 18.1: Make Clone

The user needs to perform the following to Clone:

**Step 1:** The "Clone Unit" can be accessed by going to the "System Menu" of the OCS. A new menu "Clone Unit" has been added at the end of the main System Menu as shown below:




**Step 2:** Selecting “Make Clone” will open the following menu screen.

The 'Clone Unit' menu screen has a blue header with the title 'Clone Unit'. Below the header, the text 'Directory Empty' is displayed. At the bottom, there are two status fields: 'Free: 1004257280' and 'Total: 1004257280'. Below these fields is a row of five buttons: 'Load Clone', 'Make Clone', a downward arrow, an upward arrow, and 'Esc'.

HG-111

**NOTE:** Free/Total – displays number of free and total bytes in Removable Media.

Make/Create Clone option enables user to duplicate/Clone application file, all unit settings and all register values. Selecting Make Clone brings up the screen below for the user:

This screen shows the 'Make Clone Files' confirmation dialog. It has a blue header with the title 'Make Clone Files'. The main text asks 'Are You Sure?'. Below this text are two buttons: 'Ok' and 'Cancel'. The background of this dialog is semi-transparent, showing the 'Clone Unit' menu from the previous screen. At the bottom of the background menu, the status fields 'Free: 1004257280' and 'Total: 1004257280' and the button row are visible.

HG-110

After confirmation, the OCS will create two new files in the root directory of the Removable Media Drive as shown below.

Clone Unit			
AUTOLOAD.PGH	2120	07-14-09	12:11a
CLONE.DAT	24570	07-14-09	12:11a
Free: 1004208128 Total: 1004257280			
Load Clone	Make Clone	▽	△
Esc			

HG-112

AUTOLOAD.PGM	Application file
CLONE.DAT	File having all unit settings and register values

**NOTE:** Make/Create clone operation automatically includes the security in \AUTOLOAD.PGM file for security enabled files.

Once the cloning is successful, OCS gives a message as below:

Clone Unit	
Directory Empty	
<div style="border: 1px solid black; padding: 5px;"> <div style="background-color: red; color: white; text-align: center; padding: 2px;"><b>Cloning Status</b></div> <div style="text-align: center; padding: 10px;"> <b>SUCCESS: MAKE CLONE operation</b> </div> <div style="text-align: center; padding: 5px;"> <input type="button" value="Ok"/> </div> </div>	
Free: 1004224512 Total: 1004257280	
Load Clone	Make Clone
▽	△
Esc	

Make/Create clone can also be triggered by setting %SR164.9 bit to “1” from Ladder program or graphics. Once the operation is completed, this bit is made zero by the firmware. When Make Clone operation is triggered by this SR bit, it does not ask the user for confirmation for making clone. The success / failure of the operation is also not notified on screen to the user.

In case of failure of “Make Clone” operation, %SR164.11 bit is set to “1” by the firmware and never reset.


**NOTE:** Backup of registers in flash memory is not performed by Clone Feature. Refer to "Fail-Safe System" on page 1.

## 18.2: Load Clone


This option loads the application, all unit settings and register values from Removable media to the OCS memory (regardless of the AutoLoad settings) and then resets the OCS for the settings to take effect.

User needs to perform the following to Load Clone:

**Step 1:** Select “Clone Unit” from main System Menu of OCS as shown below:




**Step 2:** Selecting “Clone Unit” menu will open the following menu screen. Select “Load Clone”.



HG-112

**Step 3:** User needs to confirm Load Clone as shown below:



**Step 4:** After confirmation, all unit settings and register values will be loaded from Removable media to the OCS memory (regardless of AutoLoad settings) and then OCS resets for the settings to take effect.

**NOTE:** For security enabled files, Load clone asks for password validation before loading the application.

Load Clone can also be triggered by setting %SR164.10 bit to "1" from Ladder program or graphics. Once the operation is completed, this bit is made zero by the firmware. When Load Clone operation is triggered by this SR bit, it does not ask the user for confirmation for loading clone. The success / failure of the operation is also not notified on screen to the user.

In case of failure of "Load Clone" operation, %SR164.12 bit is set to "1" by the firmware and never reset.

# Fail-Safe System



## Chapter 19: Fail-Safe System for the XL Prime Series

19.1: For the XL Prime Series .....	179
19.2: Fail-Safe System Overview .....	179
19.3: Settings .....	180
19.4: Backup/Restore Data .....	180
19.5: Clear Backup Data .....	182
19.6: AutoLoad .....	184
19.7: AutoRun .....	186

### 19.1: For the XL Prime Series


The Fail-Safe System is a set of features that allow an application to continue running in the event of certain types of "soft" failures, including but not limited to retentive register or application flash corruption due to an excessive Electromagnetic Interference (EMI) event.

### 19.2: Fail-Safe System Overview


The Fail-Safe System has the following capabilities:

- Manually backup the current retentive register settings into flash memory.
- Manually restore register settings from the values previously backed up in flash memory to retentive registers.
- Detect corrupted register settings at power-up and then automatically restore them from flash.
- Detect corrupted or empty application in flash memory at power-up and then automatically load the AUTOLOAD.PGM application file from Removable Media (Compact flash or microSD).
- If an automatic Register Restore or Application Load occurs, the OCS can automatically be placed in RUN mode.

The Fail-Safe system can be accessed from the System Menu of the OCS; see the **Fail-Safe System** option on the main System Menu.



Selecting the **Fail-Safe System** menu opens the following submenu screen:



### 19.3: Settings


To use the Fail-Safe feature, the following steps are required:

1. From Cscope, create AUTOLOAD.PGM for the application program using **Export to Removable Media**.
2. Place the Removable Media with AUTOLOAD.PGM in the device.
3. Set the **Enable AutoLoad** option in the device to **YES**.
4. Set the **Enable AutoRun** option to **YES** if the controller needs to be placed in RUN mode automatically after automatic restore of data or AutoLoad operation.
5. Backup the current primary memory/register contents in the onboard flash memory using the System Menu options.

### 19.4: Backup/Restore Data


Use this option to display a screen with the following four operations:

- Backup OCS Data
- Restore OCS Data
- Clear Backup Data
- Exit



#### 19.4.1: Backup OCS Data

When initiated, the user can manually copy register contents onto the an alternate section of onboard flash memory of the OCS. This will have result in backing up all the registers and controller settings (Network ID, etc.) that would otherwise be lost due to a memory failure. %SR164.4 is set to 1 when backup operation is performed.




#### 19.4.2: Restore OCS Data

When initiated, the user can manually copy the backed-up data from the onboard flash to the primary memory.

A restore operation will be automatically initiated if 1) a backup has been previously created and 2) on power-up the primary memory registers fail their check.

The following steps are required:

1. Place the controller in IDLE mode.
2. Copy data from onboard flash memory to OCS primary memory
3. Reset the OCS.
4. Put the controller in RUN mode if the AutoRun setting is 'Yes', or else it will remain in IDLE mode.




%SR164.3 is set to 1 only when an automatic restore operation is performed, not on a manual one. This bit is reset to the value of "0" when a new backup is created.

Restoring of data can be manually performed by selecting **RESTORE** option from the Backup / Restore Data menu. This causes the controller to reset.


## 19.5: Clear Backup Data

When initiated, the backup data is erased from the onboard flash and no backup will exist. %SR164.4 and %SR164.3 is reset to 0 when backed up data is erased.



**Exit:** Returns to the previous screen.

The OCS follows the following sequence in execution of Automatic Restore:



## 19.6: AutoLoad

This System Menu option permits the user to specify whether the OCS automatically loads the application AUTOLOAD.PGM located in Removable Media.

When the AutoLoad setting is enabled (set to YES), it can either be manually initiated or automatically initiated at power-up.

The automatic initiation will happen only in the following two cases:


- When there is no application program in the OCS and a valid AUTOLOAD.PGM is available in the removable media of the device.
- When the program residing in onboard memory is corrupted and a valid AUTOLOAD.PGM is available in the removable media of the device.

AutoLoad can be manually initiated when the SYS-F3 key is pressed (OCS can be in any of the following mode – Idle/Run/DOIO). This also requires a valid AUTOLOAD.PGM to be present in the removable media of the device.

When the AutoLoad setting is not enabled (set to NO), OCS will be in IDLE mode and the application is not loaded.


If the AUTOLOAD.PGM is security enabled, the user will be prompted to enter the password before loading the application. The application will be loaded from the Removable media only after getting the correct password.

%SR164.6 can be set to enable AutoLoad feature.



Enable AutoLoad	<p><b>No</b> = Does not load AUTOLOAD.PGM automatically when application program is absent or corrupted.</p> <p><b>Yes</b> = Loads AUTOLOAD.PGM file automatically from Removable Media when application program is absent or corrupted.</p>
-----------------	--

The OCS follows the following sequence in execution of AutoLoad:



HG-026


## 19.7: AutoRun

This System Menu option, when enabled (YES), allows the user to automatically place the OCS into RUN mode after the AutoLoad operation or automatic Restore Data operation.

When the AutoRun setting is disabled (NO), the OCS remains in the IDLE mode after a Restore Data or AutoLoad operation.

%SR164.5 can be set by putting the system into RUN mode automatically, once an AutoLoad has been performed or an Automatic Restore has occurred.

If for any reason the AutoLoad-Run (Loading the AUTOLOAD.PGM automatically and OCS put in RUN mode) sequence does not succeed, a pop-up message box saying "AUTO-LOAD-RUN SEQUENCE FAILED" will be displayed. It will also show the reason for its failure. On acknowledging this message box, the AutoLoad-Run sequence will be terminated, controller will return to the first user-screen and will be placed in IDLE mode.



Enable AutoRun	<b>No</b> = OCS will be in IDLE mode after AutoLoad or Automatic Restore. <b>Yes</b> = OCS will automatically be placed into RUN mode after AutoLoad or Automatic Restore.
----------------	---

"Enable AutoLoad" displays the following options:

Enable AutoLoad	<b>No</b> = Does not load AUTOLOAD.PGM automatically when application program is absent or corrupted. <b>Yes</b> = Loads AUTOLOAD.PGM file automatically from Removable Media when application program is absent or corrupted.
-----------------	---

# Modbus Communications



## Chapter 20: Modbus Communications

---

<b>Modbus Slave Overview</b> .....	<b>188</b>
<b>Modbus Master Overview</b> .....	<b>189</b>
<b>Modbus Addressing Table</b> .....	<b>190</b>

**For complete Modbus instructions, please refer to the Help file in Cscape.**

Modbus (serial) is a popular, de-facto standard protocol that allows industrial devices from multiple manufacturers to easily share data in real-time. For Modbus serial communications, the XL15 Prime can act as either a Master or a Slave.

Modbus protocol (serial) allows for one master and multiple slaves. The master always initiates the conversation by sending a request to a particular slave. Only the addressed slave will send a response when the request is completed. Should the slave be unable to complete the request, it returns the appropriate error response. Should the slave be unable to respond, the master's timeout timer expires to provide an indication of No Response.

### Modbus Slave Overview

**For complete Modbus Slave instructions, please refer to the Help file in Cscape.**

The Modbus slave function block, when used with the appropriate Modem and/or Open Function Blocks, allows the primary serial port on the controller to act as a Modbus slave. The Modbus function supports both ASCII and RTU modes of operation across a range of baud rates and protocol frames. Also supported is port activity status, an inactivity timer, support for call-on exception, and support for store and forward (repeater) operation for radio modems.

The "Modbus Addressing Table" on page 190 section describes the supported Modbus Commands as well as the Modbus Map for XL15 Prime References (%R, %M, etc.).

## Modbus Master Overview

For complete Modbus Master instructions, please refer to the Help file in Cscape.

When acting as a Modbus master, there are two primary mechanisms used by the XL15 Prime to allow the user to specify the data to be read/written from/to the slaves.

**Modbus Master Function Block**—This is for serial only. This is an advanced feature that should only be used in rare occasions.

**Protocol Config**—The Protocol Config is configured in the Hardware Configuration dialog box in Cscape (serial). Refer to "Modbus Addressing Table" on the next page. This is the preferred method in most applications.

After the protocol has been selected from the dropdown menu, the Network, Devices, and Scan List become available. The Protocol Config is configured on three different levels:

- **Network**—Parameters, such as the polling rate of the data scan, are specified along with timeout values, retry, and re-acquisition settings. Serial configuration, baud rate, parity, etc. are also set here.
- **Devices**—For every slave to be polled, configuration details are added in the Devices dialog box. This includes Slave ID (serial). Under Device Type, the Modbus addressing style matching that specified in the slave's user documentation may be selected. For instance, some slaves specify Modbus addresses (i.e. 40,001), and others specify offsets (i.e. 0000).
  - **Hex or Decimal**—Some specify addresses in hex, and others in decimal. By allowing the user to select the Modbus addressing style for each slave on the network, minimal address conversion is required. Also, if the slave is another Horner product (i.e. another OCS), the "Native Addressing" option can be selected (i.e. %R1, %M17, etc.), and this skips the conversion to Modbus style altogether.
- **Scan List**—This is where the specific Modbus addresses to be read/written from/to each slave are specified. Up to 32 words of data can be read at the same time.

**NOTE:** Once configuration has been completed on the Network and Devices level, Modbus data can be directly read/written from graphics objects in the Cscape screen editor. This is available even if the Modbus register is not listed on the scan list.

## Modbus Addressing Table

To access XL15 Prime registers, a Modbus Master must be configured with the appropriate register type and offset. This is usually accomplished with one of two methods:

**Method 1:** The first method uses Traditional Modbus References, in which the high digit represents the register type, and the lower digits represent the register offset (starting with Register 1 for each type). Since only four register types can be represented in this manner, XL15 Prime Modbus Function Blocks pack several XL15 Prime register types into each Modbus register type. Starting addresses of each XL15 Prime register type are shown in the Traditional Modbus Reference column of the Modbus Table.

**Method 2:** The second method requires the Modbus Master to be configured with a specific Modbus Command and Modbus Offset. The supported Modbus commands and the associated offsets are also illustrated in Modbus Table.

XL15 Prime Modbus Master Mapping					
Reference	Maximum Range	Trad. Modbus Reference (5 Digits)	Expanded Modbus Ref. (6 Digits)	Modbus Command(s)	Modbus Offset
%I1	2048	10001	010001	Read Input Status (2)	0
%IG1	256	13001	013001		3000
%S1	256	14001	014001		4000
%K1	7	15001	015001		5000
%Q1	2048	00001	000001	Read Coil Status (1) Force Coil (5) Force Multiple Coils (15)	0
%M1	2048	03001	003001		3000
%T1	2048	06001	006001		6000
%QG1	256	09001	009001		9000
%AI1	512	30001	030001	Read Input Register (4)	0
%AIG1	32	33001	033001		3000
%SR1	256	34001	034001		4000
%AQ1	512	40001	040001	Read Holding Register (3) Load Register (6) Load Multiple Registers (16)	0
%R1	2488	40513	040513		512
%R1	2048	43001	043001		3000
%AQG1	32	46001	046001		6000
%R1	9999	--	410001		10000

# Prime Series Backup Battery



## Chapter 21: Prime OCS Battery

21.1: Safety .....	192
21.2: Replacing the Battery .....	193

### 21.1: Safety

**ALERT:** This does not include the XL Series, only the Prime Series.

The Prime OCS has an improved memory architecture that does not require a battery for program or register retention. The onboard lithium coin-cell battery runs the **real time clock** and is user replaceable with an expected lifetime of seven (7) to ten (10) years.

Environmental conditions, including extreme temperatures and humidity, can affect battery life. If the battery older than seven (7) to ten (10) years old, it is recommended that it be replaced as preventative maintenance. NOTE: Use only the proper battery type listed.

**NOTE:** Use only the proper battery type listed.

**WARNING:** DO NOT USE IF BATTERY IS LEAKING OR HAS BEEN DAMAGED.

**WARNING:** LITHIUM BATTERIES MAY EXPLODE OR CATCH FIRE IF MISTREATED.

**WARNING:** DO NOT RECHARGE, DISASSEMBLE, HEAT ABOVE 100° C (212° F) INCINERATE, OR PUNCTURE.

**WARNING:** EXPLOSION HAZARD – BATTERIES MUST BE ONLY BE CHANGED IN A AREA KNOWN TO BE NON-HAZARDOUS.


**WARNING:** Disposal of lithium batteries must be done in accordance with federal, state, and local regulations. Be sure to consult with the appropriate regulatory agencies before disposing batteries. In addition, do not recharge, disassemble, heat or incinerate lithium batteries.

**WARNING:** Do not make substitutions for the battery. Be sure to only use the authorized part number to replace the battery.

## 21.2: Replacing the Battery

The Prime OCS uses a lithium coin-type battery with part number **HE-BAT013**, with harness and connector available from Horner APG.

**WARNING:** Replacing the battery is a delicate procedure. If unsure about the procedure, please contact Horner Tech Support via [Horner Contact Us](#).



HG-031

Below are the steps to replace the battery:

1. Make sure the user program and any data stored in retentive memory is backed up.
2. Disconnect all power from the Prime OCS unit including I/O power.
3. On the back of the Prime OCS model, remove the back cover by removing four screws found in the corners of the panel.

**NOTE:** In some models, a board must also be removed.

4. Remove the three screws holding the main board in place. Turn the main board up to access the battery and harness.
5. Connect the new battery into the adjacent connector first and then carefully remove the old battery. With a small piece of tape provided, attach the new battery to the board.
6. Dispose of the old battery properly; see the above warning on disposal regulations.
7. Carefully place the back panel (and board if necessary) and replace the four screws.
8. Apply power to the unit. Check that the battery error is no longer reported. If the unit still reports the error, remove the battery immediately and contact Technical Support.

# Firmware Update



## Chapter 22: Firmware Updates


Check for Current Firmware Revision .....	195
Firmware Update Details .....	196
Download Firmware .....	196

The XL15 Prime OCS products contain field updatable firmware to allow new features to be added to the product. Firmware updates should only be performed when a new feature or correction is required.

**WARNING:** Firmware updates should only be performed when the equipment being controlled by the OCS is in a safe, non-operational state. Communication or hardware failures during the firmware update process can cause the controller to behave erratically resulting in injury or equipment damage. Make sure the functions of the equipment work properly after a firmware update before returning the device to an operational mode.

### Check for Current Firmware Revision

To check the firmware revision on a controller, open **System Menu > View Status**.



## Firmware Update Details

**NOTE:** Updating firmware clears the application program, screens, configurations, and register data. If required, backup the program and register data before updating firmware. The controller's user manual contains instructions for doing backups, but for additional instructions, see

- See **MAN1011:** Firmware Update Manual / Boot Loader Manual
- See **MAN1362:** Firmware Update Manual: Prime Series Only

## Download Firmware

In North America, visit <https://hornerautomation.com>. Then click **Support > Downloads > Controller Firmware** and download the most recent firmware set with the correct communication protocol.

**-OR-**

In Europe, visit <http://www.hornerautomation.eu> and click **Support > Firmware** tab and download the desired firmware (an account is required to access firmware updates, create one if necessary).

# Troubleshooting & Tech Support



## Chapter 23: Troubleshooting

23.1: Connecting to the OCS .....	198
23.2: Local Controller and Local I/O .....	200
23.3: CsCAN Network .....	200
23.4: USB Interfaces .....	201
23.5: Basic Troubleshooting .....	202
23.6: Technical Support Contacts .....	202

### 23.1: Connecting to the OCS

Cscape connects to the local controller automatically when the serial connection is made. The status bar below shows an example of a successful connection. This status bar is located in the bottom right-hand corner of the Cscape window.



In general, the **Target** number should match the **Local** number. The exception to this is when the controller is being used as a "pass through" unit where other controllers on a CsCAN network could be accessed through the local controller. See Cscape Help File for more details.

Determine connection status by examining feedback next to Local & Target in the status bar of Cscape.

Cscape Target & Local Numbers	
<b>Local: ###</b>	If a number shows next to <b>Local</b> then communication is established to the local controller.
<b>Local: No Port</b>	Cscape is unable to access the COM port of the PC. This could mean that Cscape is configured for a COM port that is not present or that another program has control of the COM port. Only one Cscape window can access a port at a time. Subsequent instances of Cscape opened will indicate No Port.
<b>Local: No Com</b>	Cscape has accessed a PC COM port but is not communicating with the controller. This typically occurs when the controller is not physically connected.
<b>Local: ???</b>	Unknown communication error. Close Cscape, power cycle the controller and reopen Cscape with a blank project. Check Local.
<b>Target: #(I,R,D)</b>	If I (idle), R (run), or D (do I/O) shows next to <b>Target number</b> , then communication is established to the target controller.
<b>Target: #(?)</b>	Communication is not established to the target controller. Check node ID of controller and set Target to match. Make sure <b>local</b> connection is established.

### 23.1.1: Serial Port – MJ1 Programming

1. Controller must be powered up.
2. Ensure that the correct COM port is selected in Cscope. **Tools > Applications Settings > Communications.**
3. Ensure that a cable with proper pinout is being used between PC and controller port MJ1.
4. Check that a Loaded Protocol or ladder is not actively using MJ1. Taking the controller out of Run Mode from the System Menu on the controller will make MJ1 available to Cscope.
5. Successful communications with USB-to-serial adapters vary. If in doubt, Horner APG offers a USB to serial adapter: part number [HE-CPK](#).

### 23.1.2: USB Port - Type C Programming

1. Power-up the controller.
2. Ensure that the correct COM port is selected in Cscope. **Tools > Applications Settings > Communications > Configure.**
3. Confirm that the USB cable is connected between the PC and the controller.
4. Examine the Windows Device Manager to confirm that the USB driver is correctly installed and to verify the port number.
5. The Type C USB port driver installs.

### 23.1.3: ETN Port Programming

1. Controller must be powered up.
2. Ensure that the correct IP address is given in the Ethernet field and correct Mode is selected, in Cscope: **Tools > Applications Settings > Communications.**
3. Ensure that an Ethernet connection has been established by pinging the controller from the Windows DOS prompt.

## 23.2: Local Controller and Local I/O

The System Menu provides the following status indications that are useful for troubleshooting and system maintenance. To view the System Menu, press the **System** key.

- Self-test results, diagnostics.
- RUN and OK status
- Network status and usage
- Average logic scan rate
- Application memory usage
- Loaded firmware versions
- Loaded protocols
- Removable media access

### 23.2.1: Local I/O Troubleshooting Checklist

1. Verify the controller is in RUN mode.
2. Check diagnostics to ensure controller passed self-tests. View Diags in System Menu or in Cscape, click Controller/Diagnostics.
3. Check data sheets to ensure proper wiring.
4. Ensure that hardware jumpers and software configuration for I/O match.
5. Check data sheets for voltage and current limits.
6. Take ladder out of the picture. From Cscape set controller to “Do I/O” mode. In this mode inputs can be monitored, and outputs set from a data watch window in Cscape without interference from the ladder program. Some I/O problems are only a result of a mistake in the ladder program.

**WARNING:** Setting outputs ON in Do I/O mode can result in injury or cause machinery to engage in an unsafe manner depending on the application and the environment.

## 23.3: CsCAN Network

For complete information on setting up a CsCAN network, refer to CAN Networks manual (MAN0799) by using Horner's [Documentation Search](#) page.

Network status, node ID, errors, and baud rate in the controller System Menu are all in reference to the CsCAN network. These indications can provide performance feedback on the CsCAN network and can also be used to aid in troubleshooting.

### 23.3.1: CsCAN Network Troubleshooting Checklist

1. Use the proper Belden wire type or equivalent for the network as specified in the [CAN Networks Manual](#), MAN0799.
2. The Horner OCS does not provide 24VDC to the network. An external voltage source must be used for other devices such as SmartStix I/O.
3. Check voltage at both ends of the network to ensure that voltage meets specifications of attached devices.
4. Proper termination is required. Use 121 $\Omega$  (or 120 $\Omega$ ) resistors at each end of the network. The resistors should be placed across the CAN\_HI and CAN\_LO terminals.
5. Measure the resistance between CAN\_HI and CAN\_LO. If the network is properly wired and terminated, there should be around 60 $\Omega$ .
6. Check for duplicate node ID's.
7. Keep proper wires together. One twisted pair is for V+ and V- and the other twisted pair is used for CAN\_HI and CAN\_LO.
8. Make sure the baud rate is the same for all controllers on the network.
9. Assure shields are connected at one end of each segment—they are not continuous through the network.
10. Do not exceed the maximum length determined by the baud rate and cable type.
11. Total drop length for each drop should not exceed 6m (20'). A drop may include more than one node. The drop length adds to the overall network length.
12. Network should be wired in "straight line" fashion, not in a "star" pattern.
13. In applications requiring multiple power supplies, make sure the V- of all supplies is connected and to earth ground at one place only.
14. In some electrically noisy environments, it may be necessary to add repeaters to the network. Repeaters can be used to add additional nodes and/or distance to the network and protect the signal against noisy environments.

### 23.4: USB Interfaces

- Plugging and unplugging USB devices while the OCS is powered up can cause the OCS to reset. In general, branded USB memory sticks will not cause this problem, however, with the advent of USB 3.0 and larger / faster memory devices this cannot be guaranteed.
- Larger USB devices such as hard-drives etc. should only be attached and removed when the OCS is powered down.
- The resets are caused by short sharp current spikes when devices are added or removed from the OCS, these spikes can exceed the USB specification but are usually very short and mostly do not cause problems. Some devices however draw a longer larger current as they power up causing a brief dip in the OCS internal supplies leading to a reset.
- Standard SanDisk and Kingston ranges with read times less than 120MB/sec. should not cause resets. The display will flicker when a device is added or removed.

## 23.5: Basic Troubleshooting

Description	Action
OCS does not read media card.	The media card should be formatted with the controller.
OCS will not download project file.	Make sure the project file is saved as a .pgm file and not a .csp file. In addition, the file must be .pgm. The file's I/O configuration must match the controller configuration for it to download.

## 23.6: Technical Support Contacts

For manual updates and assistance, contact Technical Support at the following locations:

**North America:**

Tel: (317) 916-4274

Fax: (317) 639-4279

Website: <https://hornerautomation.com>

Email: [APGUSATechSupport@heapg.com](mailto:APGUSATechSupport@heapg.com)

**Europe:**

Tel: (+) 353-21-4321-266

Fax: (+353)-21-4321826

Website: <https://www.hornerautomation.eu>

Email: [technical.support@horner-apg.com](mailto:technical.support@horner-apg.com)